Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BN0032WHBKG

Braun BN0032 Male Round Analog Watch User Manual

Model: BN0032WHBKG

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Braun BN0032 Male Round Analog Watch. Please read this manual carefully before using your watch to ensure proper function and longevity.

Product Overview





Figure 1: Front view of the Braun BN0032 Male Round Analog Watch. This image displays the watch face with its minimalist design, including hour markers, minute markers, and the date window at the 6 o'clock position.





Figure 2: Angled view of the Braun BN0032 Male Round Analog Watch. This perspective highlights the watch's case thickness, the texture of the genuine leather strap, and the crown used for setting time and date.

The Braun BN0032 is a 3-hand analog watch featuring a date display. It is designed with a 40 mm matt stainless steel case, a scratch-resistant mineral glass, and a genuine leather strap. The watch is water-resistant up to 5 ATM.

Setup

1. Initial Inspection

Upon unboxing, inspect the watch for any visible damage. Ensure the crown is fully pushed in to prevent water ingress and to ensure the watch is running.

2. Setting the Time

1. Pull the crown out to the first click position.
2. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position.

3. Setting the Date

1. Pull the crown out to the first click position.
2. Rotate the crown counter-clockwise to adjust the date. Adjust the date to the day before the current date.
3. Pull the crown out to the second click position.
4. Rotate the crown clockwise to advance the time past 12 AM until the date changes to the current date. Continue rotating to set the correct time, ensuring AM/PM is correctly set.
5. Push the crown back into its original position.

4. Adjusting the Strap

The genuine leather strap features a buckle clasp. Adjust the buckle to the desired hole for a comfortable and secure fit on your wrist. Ensure the watch is not too tight to allow for proper circulation, nor too loose to prevent excessive movement.

Operating Your Watch

Timekeeping

Your Braun BN0032 watch is equipped with a quartz date movement, providing accurate timekeeping. The iconic yellow second hand sweeps around the dial, indicating seconds.

Water Resistance

The watch has a water resistance rating of 5 ATM (50 meters). This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. It is **not** suitable for swimming, diving, or showering, as prolonged exposure to water pressure or steam can compromise the seals. Always ensure the crown is fully pushed in when the watch is exposed to water.

Maintenance

Cleaning

- Wipe the watch case and crystal with a soft, dry, lint-free cloth.
- For the leather strap, avoid excessive moisture. If it gets wet, dry it gently with a soft cloth and allow it to air dry naturally, away from direct heat or sunlight.
- Do not use chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish or strap.

Battery Replacement

The watch is powered by 1 LR44 battery. When the second hand begins to skip or the watch stops, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure the water resistance is

maintained and to prevent damage to the movement.

Storage

When not in use, store your watch in a cool, dry place, away from direct sunlight, extreme temperatures, and strong magnetic fields. Keeping it in its original box or a watch case can protect it from dust and scratches.

Troubleshooting

Problem	Possible Cause	Solution
Watch not running or running intermittently.	Low battery; Crown not fully pushed in.	Replace battery (professional service recommended); Push crown fully in.
Date not changing at midnight.	Time set incorrectly (AM/PM issue).	Reset the time, ensuring you pass 12 AM for the date to change.
Condensation under crystal.	Exposure to extreme temperature changes; Compromised water resistance.	Avoid extreme temperature changes. If condensation persists, seek professional service immediately to prevent internal damage.
Strap discomfort or irritation.	Strap too tight; Allergic reaction to material; Lack of cleaning.	Adjust strap for comfort; Consult a doctor if irritation persists; Clean strap regularly.

If the problem persists after attempting these solutions, please contact Braun customer support or an authorized service center.

Specifications

- **Model Number:** BN0032WHBKG
- **Movement:** Quartz Date Movement
- **Case Material:** Matt Stainless Steel
- **Case Diameter:** 40 mm
- **Crystal:** Scratch Resistant Mineral Glass
- **Water Resistance:** 5 ATM (50 meters)
- **Strap Material:** Genuine Leather Calfskin
- **Clasp Type:** Buckle
- **Battery Type:** 1 x LR44 (included)
- **Product Dimensions (packaging):** 2.36 x 3.94 x 3.94 inches; 0.01 ounces

Warranty and Support

Warranty Information

Your Braun BN0032 watch comes with a **2-year guarantee** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear of the strap or battery.

Customer Support

For warranty claims, service, or technical assistance, please contact Braun customer support. Refer to the official Braun website or your purchase documentation for the most current contact information.
You can visit the official Braun Store for more information:Braun Official Store

© 2024 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004X4KVZI

More documents and user manuals: **https://manuals.plus/**