Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BNC002BKBK

Braun BNC002BKBK Classic Analog Quartz Alarm Clock - Instruction Manual

Model: BNC002BKBK

1. Introduction

The Braun BNC002BKBK Classic Analog Quartz Alarm Clock is designed for reliable timekeeping and easy alarm functions. Rooted in Braun's design philosophy of functionality, quality, and aesthetics, this compact clock offers a pure and highly functional experience without superfluous details.

Key features include a quiet quartz mechanism, a large, easy-to-locate alarm switch, and a sweep second hand for precise time display. Its elegant black design makes it a versatile addition to any space.



Figure 1: Front view of the Braun BNC002BKBK Classic Analog Quartz Alarm Clock.

2. Package Contents

- Braun BNC002BKBK Classic Analog Quartz Alarm Clock
- 1 x AA Battery (included)
- Instruction Manual

3. Setup

3.1 Battery Installation

1. Locate the battery compartment cover on the back of the clock.
2. Slide the cover open.
3. Insert one AA battery, ensuring the polarity (+ and -) matches the indicators inside the compartment.
4. Close the battery compartment cover securely.



Figure 2: Back view of the clock showing the battery compartment and setting dials.

3.2 Setting the Time

1. On the back of the clock, locate the time setting dial (usually marked with a clock icon).
2. Rotate the dial in either direction to move the hour and minute hands to the correct current time.

3.3 Setting the Alarm

1. On the back of the clock, locate the alarm setting dial (usually marked with an alarm icon).
2. Rotate this dial to move the alarm hand (often a shorter, distinct hand) to your desired wake-up time.

4. Operating Instructions

4.1 Activating and Deactivating the Alarm

- To **activate** the alarm, slide the alarm switch (often a prominent lever on the top or side) to the 'ON' position. A small indicator (e.g., green dot) may become visible.

- To **deactivate** the alarm, slide the alarm switch to the 'OFF' position. The indicator will disappear.

4.2 Snooze Function

When the alarm sounds, press the snooze/light button (typically located on the top of the clock) to temporarily silence the alarm. The alarm will sound again after approximately 5 minutes.

4.3 Light Function

To illuminate the clock face in low-light conditions, press the snooze/light button. The backlight will activate for a few seconds, allowing you to read the time without fully waking yourself or others.

4.4 Alarm Sound

The alarm features a crescendo sound, starting quietly and gradually increasing in volume to ensure you wake up gently but effectively.

▶ **Watch video online**
Braun BC22 Alarm Clock

Video 1: Demonstration of the Braun BC22 Alarm Clock's features, including alarm sound and light function. Note: This video features a similar Braun alarm clock model.

5. Maintenance

5.1 Battery Replacement

When the clock's timekeeping becomes inaccurate or the alarm/light functions weaken, it is time to replace the AA battery. Follow the battery installation steps in Section 3.1.

5.2 Cleaning

To clean the clock, use a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these may damage the finish or internal components.

6. Troubleshooting

- **Clock not keeping accurate time:** Replace the AA battery. Ensure the time is set correctly.
- **Alarm not sounding:** Ensure the alarm is activated (switch in 'ON' position) and the alarm hand is set to the desired time. Replace the AA battery if necessary.
- **Light not working:** Replace the AA battery.
- **Loud ticking noise:** This model features a quiet quartz mechanism. If you experience unusually loud ticking, ensure the clock is on a stable, flat surface. If the issue persists after battery replacement, contact customer support.

7. Specifications

Feature	Detail
Brand	Braun
Model Number	BNC002BKBK
Color	Black

Feature	Detail
Display Type	Analog
Power Source	Battery Powered
Battery Type	1 AAA battery (included)
Material	Acrylonitrile Butadiene Styrene (Plastic)
Item Weight	14.1 ounces (0.4 Kilograms)
Product Dimensions	1.22 x 2.2 x 2.2 inches
Alarm Clock	Yes
Operation Mode	Hand
Clock Form	Travel

8. Warranty and Support

This Braun alarm clock comes with a manufacturer's warranty. For specific warranty details, including coverage period and terms, please refer to the documentation provided with your product or visit the official Braun website.

For technical support, troubleshooting assistance, or warranty claims, please contact Braun customer service through their official channels. Contact information can typically be found on the product packaging or their website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004XK1L7Y

More documents and user manuals: **https://manuals.plus/**