**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Truper 30261**

# Truper 30261 Steel Handle Bow Saw User Manual

Model: 30261 | Brand: Truper

## Introduction

This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your Truper 30261 Steel Handle Bow Saw. Please read this manual thoroughly before operation and retain it for future reference.

The Truper 30261 is a 30-inch steel handle bow saw designed for cutting larger branches. It features a cam-lever tension system for maintaining blade tightness during use.

## Safety Information

**WARNING: Always wear appropriate personal protective equipment (PPE) including safety glasses, gloves, and sturdy footwear when operating the bow saw.**

- Keep hands and body clear of the blade during operation.
- Ensure the work area is clear of obstructions and bystanders.
- Do not use the saw if the blade is dull, bent, or damaged. Replace damaged blades immediately.
- Store the saw in a dry, secure location out of reach of children.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

## Product Overview

The Truper 30261 Bow Saw consists of a durable steel frame, a comfortable handle, and a replaceable 30-inch blade. The cam-lever system allows for quick and secure blade tensioning.




Figure 1: Overall view of the Truper 30261 Steel Handle Bow Saw, showing the orange steel frame and the 30-inch blade.



Figure 2: Close-up of the saw's handle and the cam-lever tensioning mechanism, which secures the blade.



Figure 3: Detail of the blade attachment point at the front of the bow saw frame.



Figure 4: The Truper brand logo prominently displayed on the orange steel frame of the bow saw.




Figure 5: The quick-release mechanism for detaching and replacing the saw blade.




Figure 6: Close-up of the saw blade, showing the sharp teeth and the Truper logo etched onto the blade surface.

## Setup and Blade Replacement

The Truper 30261 Bow Saw comes pre-assembled with a blade. If you need to replace the blade, follow these steps:

1. **Release Tension:** Locate the cam-lever tension system near the handle. Push the lever to release the tension on the blade.
2. **Remove Old Blade:** Carefully unhook the blade from both ends of the frame. Be cautious as the blade teeth are sharp.
3. **Insert New Blade:** Align the holes on the new 30-inch replacement blade (e.g., Truper 30-Inch Replacement Blade, ASIN B0052X7Z9O) with the pins on the saw frame. Hook one end of the blade onto its pin.
4. **Tension Blade:** Hook the other end of the blade onto its pin. Engage the cam-lever to apply tension. Ensure the blade is taut and straight.

*For optimal performance, use genuine Truper replacement blades.*

## Operating Instructions

The Truper 30261 Bow Saw is designed for cutting wood, particularly branches and logs.

1. **Secure Workpiece:** Ensure the branch or log you are cutting is stable and secured to prevent movement during cutting.
2. **Grip:** Hold the saw firmly with both hands, one on the main handle and the other on the front grip (if applicable) or the frame for stability.
3. **Starting the Cut:** Place the blade on the material to be cut. Apply light pressure and begin with short, controlled strokes to create a kerf (groove).
4. **Cutting Stroke:** Use long, even strokes, allowing the saw's teeth to do the work. Apply pressure on the push stroke and relieve pressure on the pull stroke (or vice-versa, depending on blade type, but generally bow saws cut on both).
5. **Avoid Binding:** If the saw binds, slightly adjust the angle or use wedges to open the cut. Never force the saw.
6. **Finishing the Cut:** As you near the end of the cut, support the falling piece to prevent it from splitting or pinching the blade.

## Maintenance

Proper maintenance ensures the longevity and performance of your bow saw.

- **Cleaning:** After each use, clean the blade and frame to remove sap, sawdust, and debris. A stiff brush and warm soapy water can be used. Dry thoroughly.
- **Lubrication:** Apply a light coat of rust-preventative oil to the blade and metal parts of the frame after cleaning, especially before storage.
- **Blade Sharpening/Replacement:** A dull blade requires more effort and can be dangerous. Sharpen the blade with a suitable file or replace it when it becomes dull or damaged.
- **Storage:** Store the saw in a dry environment, away from direct sunlight and extreme temperatures. Consider using a blade guard for safety.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Saw binds in cut | Wood closing on blade; dull blade | Use wedges to open cut; ensure blade is sharp and properly tensioned. |
| Blade wobbles or is loose | Insufficient blade tension; incorrect blade installation | Engage cam-lever fully to tension blade; re-install blade correctly. |
| Difficulty cutting | Dull blade; incorrect cutting technique | Replace or sharpen blade; review operating instructions for proper technique. |
| Rust on blade/frame | Improper storage; lack of lubrication | Clean and apply rust-preventative oil; store in a dry environment. |

## Specifications

| | |
|---|---|
| **Model:** | Truper 30261 |
| **Blade Length:** | 30 Inches |
| **Handle Material:** | Steel (Frame), Wood (Handle) |
| **Blade Material:** | High Speed Steel |
| **Power Source:** | Manual |
| **Item Weight:** | 2.31 Pounds |
| **Product Dimensions:** | 21"L x 30"W x 21"H |
| **UPC:** | 755625005236 |

## Warranty and Support

Truper tools are manufactured with high-quality materials and processes. For warranty information or technical support, please contact Truper customer service directly or visit their official website. Keep your purchase receipt as proof of purchase.
For general inquiries or to find authorized service centers, please refer to the contact information provided with your product packaging or on the official Truper website.
*Note: Warranty terms may vary by region and product.*

© 2024 Truper. All rights reserved.
This manual is for informational purposes only. Truper reserves the right to make changes to products and specifications at any time without notice.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0052X7YIQ**

More documents and user manuals: **https://manuals.plus/**