Manuals+
Q & A | Deep Search | Upload

Invicta 23915

Invicta Bolt Model 23915 Quartz Watch User Manual

Your guide to setup, operation, and care.

1. Introduction

Thank you for choosing the Invicta Bolt Model 23915 Quartz Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.
The Invicta Bolt Model 23915 features a robust stainless steel construction, a precise quartz movement, and chronograph functionality, designed for durability and accurate timekeeping.

2. Setup

2.1 Setting the Time and Date

1. **Unscrew the Crown:** The watch features a screw-down crown for enhanced water resistance. Gently rotate the crown counter-clockwise until it is free from the case.
2. **Pull the Crown to Position 2 (Date Setting):** Pull the crown out to the first click position. Rotate the crown clockwise or counter-clockwise to set the date. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.
3. **Pull the Crown to Position 3 (Time Setting):** Pull the crown out to the second click position. Rotate the crown to set the hour and minute hands. To ensure accurate time, synchronize with a reliable time source.
4. **Push and Screw Down the Crown:** Once the time and date are set, push the crown back into the normal operating position. While gently pushing, rotate the crown clockwise to screw it back into the watch case until it is securely tightened. This maintains the watch's water resistance.

Figure 2.1: Invicta Bolt Model 23915 watch. Note the crown and pushers on the side.

2.2 Adjusting the Bracelet

The stainless steel bracelet may require adjustment to fit your wrist comfortably. This typically involves removing or adding links. It is recommended to have this procedure performed by a qualified watchmaker or jeweler to prevent damage to the bracelet or watch.

Figure 2.2: Invicta Bolt watch on a wrist, illustrating proper fit.

3. Operation

3.1 Timekeeping

Your Invicta Bolt watch is powered by a precise quartz movement, providing accurate timekeeping. The main hands display hours, minutes, and seconds.

3.2 Chronograph Function

The chronograph function allows for measuring elapsed time. The watch features pushers on the side of the case, typically above and below the crown.

1. **Start/Stop:** Press the upper pusher to start the chronograph. Press it again to stop.
2. **Reset:** With the chronograph stopped, press the lower pusher to reset all chronograph hands to their zero positions.

Note: Ensure the screw-down crown is fully tightened before operating the pushers, especially near water, to maintain water resistance.

3.3 Water Resistance

This watch is water resistant to 660 feet (200 meters). This rating makes it suitable for professional marine activity and serious surface water sports, but not scuba diving. Always ensure the crown is fully screwed down before any contact with water.

- Do not operate the crown or pushers while the watch is submerged in water.
- Avoid exposing the watch to extreme temperature changes, such as moving from a hot sauna to cold water, as this can compromise seals.
- Rinse the watch with fresh water after exposure to salt water to prevent corrosion.

4. Maintenance

4.1 Cleaning

To maintain the appearance of your watch, regularly wipe the case and bracelet with a soft, damp cloth. For stainless steel, a mild soap solution can be used, followed by a thorough rinse with fresh water and drying with a soft cloth. Avoid harsh chemicals or abrasive materials.

4.2 Battery Replacement

The quartz movement is powered by a battery. When the battery life is depleted, the watch will stop running or the second hand may jump in irregular intervals (End-of-Life indicator). Battery replacement should be performed by a qualified watch technician to ensure the proper sealing and water resistance of the watch are maintained.

4.3 Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box provides excellent protection.

Figure 4.3: The Invicta watch box, suitable for storage.

5. Troubleshooting

Problem	Possible Cause	Solution
Watch not running	Depleted battery	Replace battery (professional service recommended).
Incorrect time/date	Crown not fully screwed down or incorrectly set	Refer to Section 2.1 to reset time/date and ensure crown is securely screwed down.
Water inside watch	Crown not screwed down, seals compromised	Immediately take to a professional watch service center. Do not attempt to dry it yourself.
Chronograph hands not resetting to zero	Requires calibration	Consult a professional watch technician for adjustment.

6. Specifications

Feature	Detail
Model Number	23915
Brand	Invicta
Movement Type	Quartz
Display Type	Analog
Case Material	Stainless Steel

Feature	Detail
Band Material	Stainless Steel
Crystal Type	Mineral
Case Diameter	53 Millimetres
Case Thickness	21 Millimetres
Band Width	36.8 Millimetres
Water Resistance Depth	660 Feet (200 Meters)
Additional Features	Chronograph, Screw-down Crown
Item Weight	0.87 Pounds (394.63 g)
Batteries	1 Product Specific battery (included)

7. Warranty & Support

Invicta watches are manufactured to high standards and come with a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Invicta website.
For technical support, service, or inquiries regarding your Invicta Bolt Model 23915 watch, please contact Invicta customer service through their official channels. Always ensure that any service or repairs are carried out by authorized Invicta service centers to maintain the watch's integrity and warranty.

© 2023 Invicta Watch Group. All rights reserved.