Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dual P 390

Dual P 390 Portable Boombox User Manual

Model: P 390

Introduction

This manual provides detailed instructions for the operation and maintenance of your Dual P 390 Portable Boombox. This compact and portable boombox allows you to listen to your favorite music in various ways. The MP3-compatible CD player is located on the top. You can easily tune your preferred radio station using the control on the right side of the device. Thanks to the integrated USB port on the front, you can, for example, save your favorite audiobooks to a USB stick and play them through the device's speakers.

Package Contents

Please check that all items are present in the package:

- Main Unit (Dual P 390 Portable Boombox)
- Power Cable
- User Manual

Product Overview

Familiarize yourself with the various parts of your Dual P 390 Boombox.



Figure 1: Top-front view of the Dual P 390 Portable Boombox. Shows the CD compartment, control buttons, display, and USB port.



Figure 2: Angled top view of the Dual P 390 Portable Boombox. Highlights the overall design and speaker grilles.



Figure 3: Rear view of the Dual P 390 Portable Boombox. Shows the telescopic antenna and AC power input.



Figure 4: Side view of the Dual P 390 Portable Boombox. Displays the function selector switch and volume control.

Setup

Power Supply

The Dual P 390 Boombox can be powered by either AC mains power or batteries.

AC Mains Operation:

1. Ensure the unit is switched off.
2. Connect the supplied power cable to the AC IN socket on the rear of the boombox.
3. Plug the other end of the power cable into a standard wall outlet.

Battery Operation:

1. Ensure the unit is switched off and disconnected from AC power.
2. Open the battery compartment cover, usually located on the bottom or rear of the unit.
3. Insert 6 x Baby (C-size, LR14) batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

Note: Remove batteries if the unit will not be used for an extended period to prevent leakage.

Operating Instructions

General Operation

- **Power On/Off:** Use the FUNCTION switch to select a mode (RADIO, CD/MP3, USB) to turn the unit on. Set to OFF to power off.
- **Volume Control:** Rotate the VOLUME knob to adjust the sound level.
- **Headphone Jack:** Connect 3.5mm headphones to the headphone jack for private listening. Speakers will be muted automatically.

CD/MP3 Playback

1. Set the FUNCTION switch to "CD/MP3".
2. Open the CD compartment cover by gently lifting it.
3. Place a CD (CD-R, CD-RW, or MP3 CD) onto the spindle with the label side facing up.
4. Close the CD compartment cover. The unit will read the disc, and playback should begin automatically.
5. Use the **PLAY/PAUSE**, **STOP**, **SKIP FORWARD**, and **SKIP BACKWARD** buttons to control playback.

Radio Operation (FM/MW)

1. Set the FUNCTION switch to "RADIO".
2. Select the desired band (FM or MW) using the BAND switch.
3. Extend the telescopic antenna for optimal FM reception. For MW reception, rotate the unit for best signal.
4. Rotate the TUNING knob to search for your desired radio station.

USB Playback

1. Set the FUNCTION switch to "USB".
2. Insert a USB flash drive into the USB port on the front of the unit.
3. The unit will automatically detect and begin playing compatible audio files (e.g., MP3).
4. Use the **PLAY/PAUSE**, **STOP**, **SKIP FORWARD**, and **SKIP BACKWARD** buttons to control playback.
5. **Note:** Some USB drives or file formats may not be compatible. The unit may not support USB drives larger than 8GB.

Maintenance

- **Cleaning:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **CD Care:** Handle CDs by their edges. Keep them clean and free of scratches.
- **Storage:** Store the boombox in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you experience issues with your boombox, please refer to the following common solutions:

- **No Power:**
  - Check if the power cable is securely connected to both the unit and the wall outlet.
  - If using batteries, ensure they are inserted correctly and are not depleted.
  - Verify the FUNCTION switch is not set to OFF.
- **No Sound:**
  - Increase the VOLUME.

- Ensure headphones are not plugged in, as this will mute the speakers.
- Check the selected function (CD, Radio, USB) matches your source.

- **CD Not Playing/Skipping:**
  - Ensure the CD is clean and free of scratches.
  - Verify the CD is inserted correctly with the label side up.
  - Try a different CD to rule out disc issues.
- **Poor Radio Reception:**
  - Extend and adjust the telescopic antenna for FM.
  - Rotate the unit for better MW reception.
  - Move the unit away from other electronic devices that may cause interference.
- **USB Playback Issues:**
  - Ensure the USB drive is formatted correctly and contains compatible audio files (e.g., MP3).
  - Try a different USB drive. Note that some larger capacity USB drives (e.g., over 8GB) may not be supported.

Specifications

Brand	Dual
Model Number	P 390
Color	Pink
Connectivity Technology	USB
Speaker Type	Stereo
Power Source	AC Mains / Battery (6 x C-size LR14)
Item Weight	1200 Grams
Power Output	13 Watts
Number of Speakers	2
CD Playback	CD-R, CD-RW, MP3
Radio Bands	FM, MW
Headphone Jack	Yes

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or contact the manufacturer directly. Specific warranty terms may vary by region and retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0077BB2CK

More documents and user manuals: **https://manuals.plus/**