Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SCS Sentinel HCN0014 / S316-2 3600W

SCS Sentinel HCN0014 Wireless Remote Control Outlet Kit User Manual

Model: HCN0014 / S316-2 3600W
Brand: SCS Sentinel

1. Introduction

This manual provides comprehensive instructions for the safe and efficient use of your SCS Sentinel ControlPower Wireless Remote Control Outlet Kit. This kit allows you to remotely control electrical appliances up to 2300W or 10A, offering convenience and ease of use for various indoor applications.

Please read this manual thoroughly before operating the device and retain it for future reference.

2. Product Overview and Components

The SCS Sentinel ControlPower kit includes the following components:

- Two (2) Wireless Remote Control Outlets
- One (1) Simplified Remote Control
- One (1) LR23-A-12V Battery for the Remote Control (pre-installed or included)
- User Manual (this document)



Figure 2.1: Overview of the SCS Sentinel ControlPower Kit components, showing two remote-controlled outlets and their corresponding remote control.





Figure 2.2: Detailed view of the remote control, highlighting the ON/OFF buttons for controlling up to three separate outlets.

3. Setup and Installation

The SCS Sentinel ControlPower kit is designed for simple, plug-and-play installation. No complex configuration or pairing is required.

1. **Unpack Components:** Carefully remove all components from the packaging.
2. **Insert Remote Battery:** Ensure the LR23-A-12V battery is correctly installed in the remote control. The battery compartment is typically located on the back of the remote.
3. **Plug in Outlets:** Insert the remote control outlets into standard wall sockets.
4. **Connect Appliances:** Plug the electrical appliance(s) you wish to control into the remote control outlets. Ensure the appliance's power consumption does not exceed 2300W or 10A.
5. **Ready for Use:** The system is now ready for immediate operation.

Important Note: This product is designed for indoor use only. For optimal performance, maintain a maximum distance of 30 meters (approximately 98 feet) between the remote control and the outlets in an open field environment. Obstacles such as walls or furniture may reduce the effective range.

4. Operating Instructions

Using the remote control to operate your connected appliances is straightforward:

- Each remote control outlet corresponds to a numbered button pair (1, 2, or 3) on the remote control. The kit includes two outlets, so you will use button pairs 1 and 2.
- To turn an appliance **ON**, press the corresponding "ON" button (e.g., "ON 1" for the first outlet).
- To turn an appliance **OFF**, press the corresponding "OFF" button (e.g., "OFF 1" for the first outlet).

This allows for convenient control of hard-to-reach appliances, such as string lights or floor lamps.

5. Maintenance

The SCS Sentinel ControlPower kit requires minimal maintenance.

- **Cleaning:** Wipe the surfaces of the outlets and remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** If the remote control's range decreases significantly or it stops responding, the LR23-A-12V battery may need replacement. Refer to the remote control's battery compartment for instructions on how to open and replace the battery. Ensure correct polarity when inserting the new battery.
- **Storage:** When not in use for extended periods, store the kit in a cool, dry place away from direct sunlight and extreme temperatures.

6. Troubleshooting

If you encounter issues with your SCS Sentinel ControlPower kit, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Appliance does not turn ON/OFF via remote.	• Remote control battery is low or dead. • Outlet is not properly plugged in. • Appliance is not properly plugged into the outlet. • Appliance power switch is OFF. • Out of range or too many obstacles. • Appliance exceeds maximum power rating.	• Replace the LR23-A-12V battery in the remote control. • Ensure the remote control outlet is firmly seated in the wall socket. • Ensure the appliance is firmly plugged into the remote control outlet. • Turn the appliance's manual power switch to the ON position. • Move closer to the outlet or reduce obstacles between the remote and outlet. • Verify the appliance's power consumption is within 2300W/10A.
Reduced remote control range.	• Low remote control battery. • Interference from other wireless devices. • Physical obstacles (walls, metal objects).	• Replace the remote control battery. • Try operating the remote from a different location. • Ensure a clear line of sight or fewer obstacles.

7. Specifications

Feature	Detail
Model Number	S316-2 3600W (HCN0014)
Manufacturer	SCS Sentinel
Product Dimensions (L x W x H)	32.5 x 15.5 x 7.5 cm (12.8 x 6.1 x 3 inches)
Product Weight	300 grams (0.66 lbs)

Feature	Detail
Color	White
Material	Plastic
Max Power Rating	2300W / 10A
Wireless Range	Up to 30 meters (98 feet) in open field
Remote Control Battery	1 x LR23-A-12V (included)
Components Included	2 Remote Control Outlets, 1 Remote Control
Intended Use	Indoor use only

8. Warranty and Support

SCS Sentinel is committed to providing reliable and innovative technical products. Your satisfaction is our priority.

- **Warranty:** The product comes with a 2-year availability of spare parts. For specific warranty terms and conditions, please refer to the product packaging or contact SCS Sentinel customer service.
- **Technical Assistance:** For any questions regarding the installation or use of your product, technical assistance is available. Our technicians are based in France and are ready to provide personalized advice and support.

For further assistance, please visit the official SCS Sentinel website or contact their customer support directly.

© 2024 SCS Sentinel. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B007K4X498

More documents and user manuals: **https://manuals.plus/**