Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire FAFS4073NR_FASE7073NR

User Manual

Frigidaire Affinity Red Front Load Washer & Electric Dryer

Model: FAFS4073NR_FASE7073NR

1. Introduction

Thank you for choosing the Frigidaire Affinity Red Front Load Washer and Electric Dryer set. This manual provides important information for the proper installation, operation, and maintenance of your new appliances. Please read this manual thoroughly before using your washer and dryer to ensure safe and efficient operation. Keep this manual for future reference.



Image 1.1: Frigidaire Affinity Red Front Load Washer and Dryer Set. This image displays the two appliances side-by-side, both in a vibrant red color with front-loading doors and control panels.

2. Safety Information

Your safety and the safety of others are very important. This manual contains important safety messages that you must read and obey. All safety messages will alert you to what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

- **Electrical Safety:** Ensure the appliances are properly grounded. Do not use extension cords.
- **Flammable Materials:** Do not wash or dry items that have been soiled with flammable substances.
- **Child Safety:** Keep children away from the appliances during operation.
- **Ventilation:** Ensure proper ventilation for the dryer to prevent fire hazards.
- **Installation:** Installation must be performed by a qualified installer.

3. Setup and Installation

Proper installation is crucial for the performance and safety of your washer and dryer. Refer to the separate installation guide for detailed instructions. Below are general guidelines.

1. **Unpacking:** Remove all packaging materials and shipping bolts.
2. **Location:** Choose a level surface with adequate space for ventilation and door opening. Ensure the floor

can support the weight of the appliances.

3. **Leveling:** Adjust the leveling feet to ensure the washer and dryer are stable and level.
4. **Water Connections (Washer):** Connect hot and cold water supply hoses. Ensure connections are tight to prevent leaks.
5. **Drain Connection (Washer):** Securely attach the drain hose to a standpipe or laundry tub.
6. **Electrical Connection:** Connect the power cords to grounded electrical outlets. For the electric dryer, ensure it is connected to a dedicated 240V circuit.
7. **Ventilation (Dryer):** Connect the dryer vent hose to an external exhaust. Use rigid metal ducting for best performance and safety.

4. Operating Instructions

4.1. Washer Operation

1. **Loading:** Open the door and load clothes loosely. Do not overload.
2. **Detergent Dispenser:** Add appropriate detergent, fabric softener, and bleach to the designated compartments.
3. **Select Cycle:** Turn the cycle selector knob to choose the desired wash cycle (e.g., Normal, Delicates, Heavy Duty).
4. **Adjust Options:** Select temperature, spin speed, and other options as needed.
5. **Start:** Press the Start/Pause button to begin the wash cycle.

Ready Steam Feature: For cycles that include steam, ensure the water supply is connected and the feature is selected. Steam helps to remove tough stains and wrinkles.

4.2. Dryer Operation

1. **Loading:** Transfer washed clothes from the washer to the dryer. Do not overload.
2. **Lint Filter:** Clean the lint filter before every load.
3. **Select Cycle:** Turn the cycle selector knob to choose the desired dry cycle (e.g., Timed Dry, Sensor Dry, Delicates).
4. **Adjust Options:** Select temperature, dryness level, and other options as needed.
5. **Start:** Press the Start/Pause button to begin the dry cycle.

Ready Steam Feature: If your dryer has a steam refresh or wrinkle release option, ensure the water connection is active for this feature to function.

5. Maintenance and Care

Regular maintenance helps ensure the longevity and efficiency of your appliances.

- **Washer Drum Cleaning:** Run a "Clean Washer" cycle monthly using a washing machine cleaner or bleach.
- **Detergent Dispenser Cleaning:** Periodically remove and clean the dispenser drawers to prevent residue buildup.
- **Door Gasket (Washer):** Wipe the door gasket dry after each use to prevent mold and mildew.
- **Lint Filter (Dryer):** Clean the lint filter before every load.
- **Dryer Vent Cleaning:** Annually inspect and clean the dryer exhaust duct to prevent lint buildup and fire hazards.

- **Exterior Cleaning:** Wipe down the exterior surfaces with a soft, damp cloth.
- **Water Inlet Filters (Washer):** Periodically check and clean the screens on the water inlet valves.

6. Troubleshooting

Before calling for service, review this section for common issues and their solutions.

Problem	Possible Cause	Solution
Washer not starting	Door not closed properly; Power cord unplugged; Circuit breaker tripped.	Ensure door is latched; Check power connection; Reset breaker.
Dryer not heating	Lint filter clogged; Circuit breaker tripped; Heating element failure.	Clean lint filter; Check breaker; Contact service for element replacement.
Excessive vibration (Washer)	Uneven load; Not level; Shipping bolts not removed.	Redistribute load; Level appliance; Ensure shipping bolts are removed.
Clothes not drying completely	Overloaded dryer; Clogged vent; Incorrect cycle selection.	Reduce load size; Clean vent; Select appropriate dry cycle.

7. Specifications

Feature	Washer (FAFS4073NR)	Dryer (FASE7073NR)
Brand	Frigidaire	
Model	FAFS4073NR	FASE7073NR
Capacity	3.9 Cu. Ft.	7.0 Cu. Ft.
Access Location	Front Load	
Fuel Type	Electric	Electric
Color	Red	
Special Features	Ready Steam, Inbuilt Wool	

8. Warranty and Support

Frigidaire stands behind its products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Frigidaire website. Keep your proof of purchase for warranty claims.
For technical assistance, troubleshooting beyond this manual, or to schedule service, please contact Frigidaire Customer Support. You can typically find contact information on the manufacturer's website or in your product registration materials.

- **Online Support:** Visit the official Frigidaire website for FAQs, manuals, and support resources.
- **Phone Support:** Refer to your product documentation for customer service phone numbers.
- **Service:** If service is required, ensure it is performed by a qualified technician.

© 2023 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0081VEALU

More documents and user manuals: **https://manuals.plus/**