**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## SCS Sentinel SCS TF6W

# SCS Sentinel ElektroProg Weekly Programmable Electrical Outlet User Manual

## 1. Introduction

This manual provides detailed instructions for the installation, operation, and programming of your SCS Sentinel ElektroProg Weekly Programmable Electrical Outlet. This device is designed to automate the switching of electrical appliances, helping to manage energy consumption and enhance convenience.

The ElektroProg features up to 20 programmable settings, including countdown, random switching, and automatic adjustments for summer and winter time. It supports a maximum load of 16A or 3600W and is intended for indoor use only.

## 2. Safety Instructions

- **Indoor Use Only:** This device is designed exclusively for indoor environments. Do not expose it to moisture, water, or extreme temperatures.
- **Electrical Rating:** Do not exceed the maximum load capacity of 16A or 3600W. Overloading can cause damage to the device and pose a fire hazard.
- **Proper Connection:** Ensure the device is fully inserted into a properly grounded electrical outlet.
- **Cleaning:** Disconnect the device from the power supply before cleaning. Use a dry, soft cloth. Do not use liquid cleaners.
- **Children:** Keep out of reach of children.
- **Disassembly:** Do not attempt to disassemble or repair the device. Refer all servicing to qualified personnel.

## 3. Product Overview




**Figure 1:** SCS Sentinel ElektroProg Weekly Programmable Electrical Outlet. This image displays the front of the device, featuring a digital display at the top, an array of control buttons, and a standard European Type C 2-pin electrical socket at the bottom.

### Key Features:

- Weekly programming with up to 20 ON/OFF programs.
- Countdown function.
- Random switching function for security.
- Automatic summer/winter time adjustment.
- 12-hour or 24-hour time format selection.
- Maximum load: 16A / 3600W.
- Clear digital display and intuitive button layout.

## 4. Setup

### 4.1 Initial Power-Up

1. Plug the ElektroProg into a standard 220-240V electrical wall outlet.
2. The display will illuminate, and the device will be ready for configuration.

### 4.2 Resetting the Device

If the display is blank or shows erratic behavior, or if you wish to clear all previous settings, perform a reset:

- Locate the small **RESET** button (typically a recessed button requiring a pointed object like a pen tip).
- Press the **RESET** button firmly. The display will clear, and the device will return to its factory default settings.

## 5. Operating Instructions

### 5.1 Setting the Current Time

1. Press and hold the **CLOCK** button.
2. While holding **CLOCK**, press the **WEEK** button repeatedly to select the current day of the week (MO, TU, WE, TH, FR, SA, SU).
3. While holding **CLOCK**, press the **HOUR** button repeatedly to set the current hour (0-23 for 24H format, 1-12 for 12H format).
4. While holding **CLOCK**, press the **MIN** button repeatedly to set the current minute (0-59).
5. Release the **CLOCK** button to save the current time.

### 5.2 Switching Between 12H/24H Format

- Press the **CLOCK** and **TIMER** buttons simultaneously to toggle between 12-hour (AM/PM) and 24-hour time formats.

### 5.3 Summer Time Function (SUMEER)

- Press the **CLOCK** and **SUMEER** buttons simultaneously to activate or deactivate the summer time (Daylight Saving Time) function. When active, the time will advance by one hour.

### 5.4 Manual Override / Mode Selection

Press the **MODE** button repeatedly to cycle through the operating modes:

- **ON:** The connected appliance is continuously ON.
- **OFF:** The connected appliance is continuously OFF.
- **AUTO:** The connected appliance operates according to the programmed ON/OFF times.

## 6. Programming ON/OFF Times

The ElektroProg allows for up to 20 distinct ON/OFF programs. Each program consists of an ON time and an OFF time, and can be set for specific days or groups of days.

1. Press the **TIMER** button once. The display will show '1 ON' (Program 1 ON time).
2. Press the **WEEK** button repeatedly to select the desired day(s) for this program. Options include individual days (MO, TU, WE, etc.), weekdays (MO TU WE TH FR), weekend (SA SU), all days (MO TU WE TH FR SA SU), or various combinations.
3. Press the **HOUR** button to set the desired ON hour.
4. Press the **MIN** button to set the desired ON minute.
5. Press the **TIMER** button again. The display will show '1 OFF' (Program 1 OFF time).
6. Repeat steps 2-4 to set the desired OFF day(s), hour, and minute for Program 1.
7. Continue pressing the **TIMER** button to cycle through '2 ON', '2 OFF', up to '20 ON', '20 OFF', setting each program as needed.
8. After setting all desired programs, press the **CLOCK** button to exit programming mode and return to the current time display. Ensure the device is in **AUTO** mode for programs to execute.

### 6.1 Random Function

- Press the **RANDOM** button to activate or deactivate the random function. When active, the programmed ON/OFF times will be randomly delayed by a short interval (e.g., 2-30 minutes) to simulate occupancy, enhancing security.

### 6.2 Countdown Function

The countdown function allows you to turn an appliance ON or OFF after a specified duration.

- While in **AUTO** mode, press the **CLEAR/CYCLE** button. The display will show 'd ON' or 'd OFF' and a countdown timer.
- Use the **HOUR** and **MIN** buttons to set the desired countdown duration.
- Press **CLEAR/CYCLE** again to start the countdown. The appliance will switch state (ON to OFF, or OFF to ON) once the countdown finishes.

### 6.3 Clearing Programs

- While in programming mode (after pressing **TIMER**), navigate to the specific program you wish to clear.
- Press the **CLEAR/CYCLE** button. This will clear the ON and OFF times for that specific program.

## 7. Maintenance

The SCS Sentinel ElektroProg requires minimal maintenance.

- **Cleaning:** Disconnect the device from the power outlet before cleaning. Wipe the exterior with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the device in water.
- **Storage:** If storing the device for an extended period, ensure it is kept in a dry, cool place away from direct sunlight.

## 8. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Display is blank. | No power; device needs reset. | Ensure the device is properly plugged into a live outlet. Press the **RESET** button. |
| Appliance does not turn ON/OFF at programmed times. | Device is not in **AUTO** mode; program error; appliance not working. | Press **MODE** until 'AUTO' is displayed. Recheck program settings. Test the appliance directly in a wall outlet. |
| Time is incorrect. | Time not set correctly; summer time activated. | Re-set the current time (Section 5.1). Check if summer time (SUMEER) is active (Section 5.3). |
| Random function not working. | Random function not activated. | Press the **RANDOM** button to activate it. |

## 9. Specifications

| Specification | Value |
|---|---|
| Model Number | SCS TF6W |
| Voltage | 230 Volts |

| Specification | Value |
|---|---|
| Maximum Wattage | 3600 Watts |
| Maximum Amperage | 16 A |
| Material | Plastic |
| Color | White |
| Dimensions (L x W x H) | 16.5 x 16 x 7.5 cm |
| Weight | 180 grams |
| Number of Programs | 20 |
| Power Plug Type | Type C – 2-pin (European plug) |
| Usage Environment | Indoor only |

## 10. Warranty and Support

This SCS Sentinel ElektroProg device comes with a manufacturer's warranty of**2 years** from the date of purchase.

For warranty claims, technical support, or further assistance, please refer to the contact information provided with your purchase documentation or visit the official SCS Sentinel website.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0085VL4A6**

More documents and user manuals: **https://manuals.plus/**