Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK RP500SP

LEXIBOOK Marvel Spider-Man Projector Alarm Clock - Instruction Manual

Model: RP500SP

Introduction

Thank you for purchasing the LEXIBOOK Marvel Spider-Man Projector Alarm Clock. This device is designed to provide time display, alarm functions, and a fun projection feature for children. It includes a built-in night light, time projection onto the ceiling, and various sound effects to enhance the user experience. Please read this manual carefully before use to ensure proper operation and to maximize the lifespan of your product.

Safety Information

- Keep the device away from water and moisture.
- Do not expose to direct sunlight or extreme temperatures.
- Use only the specified battery type (4 x LR6/AA batteries, not included).
- Do not mix old and new batteries, or different types of batteries.
- Dispose of batteries responsibly according to local regulations.
- This product is intended for children under adult supervision.
- Avoid looking directly into the projection light.

Package Contents

Please check the package contents to ensure all items are present:

- 1 x LEXIBOOK Marvel Spider-Man Projector Alarm Clock (Model: RP500SP)
- Instruction Manual

Product Overview

Familiarize yourself with the main components of your Spider-Man Projector Alarm Clock.



Figure 1: Front view of the Spider-Man Projector Alarm Clock.



Figure 2: Angled view of the Spider-Man Projector Alarm Clock.

- **Digital Display:** Shows time, day of the week, calendar, and room temperature.
- **Projection Lens:** Projects time and themes onto the ceiling.
- **Control Buttons:** For setting time, alarm, volume, and other functions.
- **Snooze Button:** Activates the snooze function for the alarm.
- **Night Light:** Integrated light feature.
- **Battery Compartment:** Located on the underside of the unit.

Setup

Battery Installation

1. Locate the battery compartment on the bottom of the alarm clock.
2. Using a small screwdriver, open the battery compartment cover.
3. Insert 4 new LR6/AA batteries (not included), ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

Once batteries are installed, the digital display should light up, indicating the device is ready for use.

Operating Instructions

Setting the Time and Date

Refer to the buttons on the device (usually labeled MODE, SET, UP, DOWN) to adjust the time, day of the week, and calendar. Press the MODE button to cycle through settings, and SET to confirm. Use UP/DOWN buttons to change values.

Setting the Alarm

To set the alarm, press the ALARM button (or MODE until alarm setting appears). Use the UP/DOWN buttons to set the desired alarm time. Press ALARM again to confirm. You can choose from 10 different ringtones and adjust the volume.

- **Snooze Function:** When the alarm sounds, press the "Snooze" button to temporarily silence it. The alarm will sound again after a short interval.

Time Projection and Night Light

The alarm clock features a projector that displays the time and 4 new "space" themes onto the ceiling. Activate the projection feature using the dedicated projection button. The built-in night light can be turned on or off as needed.



Figure 3: Time projection feature in action.



Figure 4: The alarm clock used as a night light and projector in a child's room.

Temperature Display

The device can display the room temperature. You can switch between Celsius and Fahrenheit using the appropriate button (refer to the device's specific button layout for temperature unit selection).

Sound Effects

The alarm clock includes various sound effects. Press the sound effect button to cycle through available sounds.

Product Demonstration Video

▶ **Watch video online**
"Lexibook Marvel Spider-Man Peter Parker Projector Radio clock, RP500SP

Video: An official demonstration of the Lexibook Marvel Spider-Man Projector Alarm Clock, showcasing its features and operation.

Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the display dims or functions become erratic. Always replace all batteries at once.
- **Storage:** If storing the device for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device does not turn on.	Batteries are dead or incorrectly inserted.	Check battery polarity or replace with new LR6/AA batteries.
Projection is dim or blurry.	Low batteries; projection lens is dirty or out of focus.	Replace batteries. Gently clean the projection lens. Ensure the room is dark for optimal projection.
Alarm does not sound.	Alarm is not set or volume is too low.	Verify alarm settings and increase volume.
Incorrect time or date displayed.	Time/date not set correctly.	Follow "Setting the Time and Date" instructions to reset.

Specifications



Figure 5: Product dimensions.

Feature	Detail
Brand	LEXiBOOK
Model Number	RP500SP
Display Type	Digital
Power Source	Battery Powered (4 x LR6/AA batteries, not included)
Product Dimensions	7.95"W x 7.52"H (approx. 20.2cm W x 19.1cm H)
Item Weight	0.44 Kilograms (15.5 ounces)
Material	Plastic, Acrylonitrile Butadiene Styrene
Special Features	Alarm, Snooze, Time Projection, Night Light, Sound Effects, Temperature Display (Celsius/Fahrenheit)
Ringtones	10 selectable ringtones with volume control

Feature	Detail
Projection Themes	4 easy-to-clip "space" themes

Warranty and Support

This LEXIBOOK product comes with a limited warranty. For specific warranty terms and conditions, please refer to the warranty information provided with your purchase or contact LEXIBOOK customer support.

- **Warranty Duration:** 2 years (as per available information).
- For technical assistance, troubleshooting beyond this manual, or warranty claims, please visit the official LEXIBOOK website or contact their customer service department.
- You can often find support contact information on the product packaging or the manufacturer's website: www.lexibook.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B008KXBPGC

More documents and user manuals: **https://manuals.plus/**