Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic DMC-LZ20E-K

Panasonic Lumix LZ20 Bridge Camera User Manual

Introduction

This manual provides essential instructions for the safe and effective use of your Panasonic Lumix LZ20 Bridge Camera (model DMC-LZ20E-K). It covers setup, basic operation, maintenance, and troubleshooting to help you get the most out of your camera's features, including its 16.1-megapixel sensor, 21x optical zoom, and 3-inch LCD screen.

Safety Information

Please read and understand all safety precautions before using the camera. Failure to follow these guidelines may result in injury or damage to the product.

- Do not expose the camera to water, moisture, or extreme temperatures.
- Use only the specified battery type (4 AA batteries) and ensure correct polarity during installation.
- Avoid pointing the lens directly at the sun or other strong light sources, as this can damage the image sensor.
- Keep the camera out of reach of small children.
- Do not attempt to disassemble or modify the camera. Refer servicing to qualified personnel.

What's in the Box

Upon opening your Panasonic Lumix LZ20 package, you should find the following items:

- Panasonic Lumix LZ20 Bridge Camera (DMC-LZ20E-K)
- 4 AA Batteries
- Shoulder Strap
- Lens Cap
- USB Connection Cable
- CD-ROM (Software/User Manual)

Setup

1. Battery Installation

The Lumix LZ20 operates on four AA batteries. For optimal performance, use high-quality alkaline or NiMH rechargeable batteries.

1. Open the battery compartment cover located on the bottom of the camera.
2. Insert four AA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
3. Close the battery compartment cover securely until it clicks into place.



Figure 1: Front view of the Panasonic Lumix LZ20 camera. The battery compartment is located on the bottom of the camera body.

2. Memory Card Installation

The camera supports SD, SDHC, and SDXC memory cards for storing photos and videos.

1. Locate the memory card slot, typically on the side or bottom of the camera.
2. Insert the memory card with the label facing the correct direction (usually towards the front of the camera) until it clicks into place.
3. To remove, gently push the card in until it springs out, then pull it out.



Figure 2: Side view of the Panasonic Lumix LZ20 camera. The memory card slot is typically located on one of the side panels.

3. Initial Power On

After installing batteries and a memory card, you can power on your camera.

1. Press the **ON/OFF** button located on the top of the camera.
2. The 3-inch LCD screen will illuminate. Follow any on-screen prompts to set the date, time, and language.



Figure 3: Top view of the Panasonic Lumix LZ20 camera, showing the ON/OFF button and mode dial.

Operating the Camera

1. Basic Photography

To capture still images:

1. Turn the mode dial to your desired shooting mode (e.g., Intelligent Auto, Program AE, or one of the Scene Modes like Sports or Sunset).
2. Frame your shot using the 3-inch LCD monitor.
3. Use the zoom lever around the shutter button to adjust the 21x optical zoom.
4. Press the shutter button halfway down to allow the camera to focus. The focus frame will turn green when focus is achieved.
5. Press the shutter button fully down to capture the image.



Figure 4: Front-angle view of the Panasonic Lumix LZ20 camera, highlighting the lens, flash, and grip.

2. Advanced Features

The Lumix LZ20 offers various settings for more control over your photography:

- **Exposure Control:** Utilize Aperture Priority AE or Manual exposure modes for creative control. Exposure compensation is available at ±3 EV in 1/3 EV steps.
- **ISO Sensitivity:** Adjust ISO from 100 up to 51200 (expanded) to manage image brightness in different lighting conditions.
- **White Balance:** The camera features an automatic white balance setting to ensure accurate color reproduction.
- **Focus Modes:** Choose between Autofocus (with Face Tracking) and Manual Focus (MF) depending on your subject and desired precision.

3. Video Recording

To record videos:

1. Set the camera to video recording mode (if applicable, or press the dedicated video record button).
2. Press the video record button to start recording. The camera supports MP4 format with resolutions of 1080p or higher.
3. Press the button again to stop recording.

4. Playback

To review your captured images and videos:

1. Press the **Playback** button (often indicated by a triangle icon).
2. Use the directional pad or control dial to navigate through your photos and videos.
3. Press the **MENU/SET** button to view options for deleting, protecting, or editing files.



Figure 5: Back view of the Panasonic Lumix LZ20 camera, displaying the 3-inch LCD screen and control buttons.

Maintenance

1. Cleaning

Proper cleaning helps maintain image quality and camera longevity.

- **Lens:** Use a soft, lint-free microfiber cloth specifically designed for optical surfaces. For stubborn smudges, use a small amount of lens cleaning fluid applied to the cloth, not directly to the lens.
- **Camera Body:** Wipe with a soft, dry cloth. For dirt, slightly dampen the cloth with water and then wipe dry. Avoid using harsh chemicals.
- **LCD Screen:** Clean gently with a soft, dry microfiber cloth.

2. Storage

When not in use, store your camera properly.

- Store the camera in a cool, dry place away from direct sunlight, high humidity, and dust.
- If storing for an extended period, remove the batteries to prevent leakage.
- Keep the lens cap on to protect the lens from dust and scratches.

Troubleshooting

If you encounter issues with your camera, try these basic troubleshooting steps:

Problem	Possible Cause / Solution
Camera does not power on	Check battery installation and ensure batteries are charged or replaced.
Images are blurry	Ensure proper focus. Check lighting conditions. Use image stabilization if available.
Memory card error	Reinsert the memory card. Try a different compatible memory card. Format the card (this will erase all data).
Flash does not fire	Check flash settings. Ensure flash is not set to 'forced off' or in a mode where flash is suppressed.

For more detailed troubleshooting, refer to the comprehensive user manual on the included CD-ROM or Panasonic's official support website.

Specifications

Feature	Specification
Model Name	Lumix DMC-LZ20
Model Number	DMC-LZ20E-K
Photo Sensor Resolution	16.1 MP
Optical Zoom	21x
Digital Zoom	4x
Screen Size	3 Inches
Image Stabilization	Yes
Battery Type	4 x AA (Nickel-Metal Hydride (NiMH) recommended)
Supported File Formats	JPEG (Stills), MP4 (Video)
Memory Card Compatibility	SD, SDHC, SDXC
Item Weight	390 Grams
Exposure Control	Aperture priority AE, Manual, ±3 EV (1/3 EV step)
ISO Range	100 - 51200 (Expanded)
Focus Type	Autofocus (Face Tracking), Manual Focus

Warranty and Support

For detailed warranty information, product registration, and technical support, please visit the official Panasonic website or contact your local Panasonic customer service center. Keep your purchase receipt as proof of

purchase for warranty claims.
You can find additional resources and frequently asked questions on the Panasonic support portal: Panasonic Global Support

© 2023 Panasonic Corporation. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B008MVLI2I

More documents and user manuals: **https://manuals.plus/**