Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UPBRIGHT HP Photosmart 7760 7450v 7268 7260w

UpBright 32V 16V AC/DC Adapter Instruction Manual

For HP Photosmart Printers (Models: 7760, 7450v, 7268, 7260w, 7260v, 9680, 9670, 9650, 9600, 5850, 7760v, 7760w, 7755, 1300, 1310, 1355, Q5534A, Q5763A, Q3492A, Q3493A, Q3500A, Q5587B, Q5767A, Q7288A, Q7290A, Q7292A, Q5598D)

1. Introduction

This manual provides essential instructions for the safe and effective use of your UpBright 32V 16V AC/DC Adapter. This power supply is designed to provide reliable power to compatible HP Photosmart printers, ensuring optimal performance. Please read this manual thoroughly before using the adapter and retain it for future reference.

2. Safety Information

To prevent electric shock, fire, or damage to the adapter or your printer, observe the following safety precautions:

- Use the adapter only with compatible HP Photosmart printers as specified.
- Ensure the power outlet voltage matches the adapter's input voltage range (100-240V AC).
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid placing heavy objects on the power cord or adapter.
- Do not attempt to open, modify, or repair the adapter. Refer servicing to qualified personnel.
- Disconnect the adapter from the power outlet during lightning storms or when unused for extended periods.
- Keep the adapter and cables away from children and pets.

3. Package Contents

Your UpBright AC/DC Adapter package includes the following items:

- UpBright 32V 16V AC/DC Adapter
- One (1) AC Power Cord suitable for your region (e.g., US, EU, UK, AU plug types).



Figure 3.1: Example of included AC power cords for different regions. Only one cord type is included per package.

4. Setup Instructions

Follow these steps to set up your UpBright AC/DC Adapter:

1. **Unpack the Adapter:** Carefully remove the adapter and the AC power cord from the packaging.
2. **Connect the AC Power Cord:** Plug the figure-8 end of the AC power cord into the corresponding input port on the UpBright AC/DC Adapter. Ensure it is firmly seated.
3. **Connect to Printer:** Locate the power input port on your HP Photosmart printer. Insert the barrel connector of the UpBright AC/DC Adapter into this port. Ensure a secure connection.
4. **Connect to Power Outlet:** Plug the other end of the AC power cord into a standard wall power outlet.



Figure 4.1: The UpBright AC/DC Adapter. Connect the AC cord to the adapter and the barrel connector to your printer.

5. Operating Instructions

Once the adapter is properly connected as described in the Setup section:

- Ensure all connections are firm.
- Power on your HP Photosmart printer using its dedicated power button. The adapter will automatically supply the necessary power.
- When not in use, it is recommended to power off your printer. For extended periods of inactivity, disconnect the adapter from the wall outlet.

6. Maintenance

Proper care can extend the life of your adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid wrapping the cord too tightly around the adapter to prevent damage.
- **Inspection:** Periodically inspect the adapter and power cord for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use and replace the adapter.

7. Troubleshooting

If you encounter issues with your UpBright AC/DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Printer does not power on.	◦ Adapter not properly connected. ◦ Power outlet not functioning. ◦ Adapter or printer fault.	◦ Ensure all cables are securely connected. ◦ Test the power outlet with another device. ◦ If possible, test with another compatible adapter or printer to isolate the issue.
Adapter feels unusually hot.	◦ Overload or poor ventilation. ◦ Internal fault.	◦ Ensure the adapter is in a well-ventilated area. ◦ Disconnect immediately and contact support if overheating persists.
Intermittent power to printer.	◦ Loose connection. ◦ Damaged cable.	◦ Check all connections for tightness. ◦ Inspect cables for visible damage. Replace if necessary.

If the problem persists after attempting these solutions, please refer to the Warranty and Support section for further assistance.

8. Specifications

Feature	Detail
Brand	UPBRIGHT
Model Compatibility	HP Photosmart 7760, 7450v, 7268, 7260w, 7260v, 9680, 9670, 9650, 9600, 5850, 7760v, 7760w, 7755, 1300, 1310, 1355, and others (Q5534A, Q5763A, Q3492A, Q3493A, Q3500A, Q5587B, Q5767A, Q7288A, Q7290A, Q7292A, Q5598D)
Input Voltage	100-240V AC (Global Compatibility)
Output Voltage	32V DC and 16V DC
Connector Type	Barrel Connector
Special Feature	Short Circuit Protection
Certification	CE Certified
Power Source	Corded Electric

Note: The "Wattage: 7268 watts" listed in some product data appears to be an error and is not representative of this product's actual power output.

9. Warranty and Support

This UpBright product comes with a limited warranty. Please refer to the included warranty certificate for specific terms, conditions, and duration of coverage. The warranty typically covers defects in materials and workmanship under normal use.



Figure 9.1: Representation of the UpBright Limited Warranty Certificate.

For technical support or warranty claims, please contact UpBright customer service through the retailer where the product was purchased or refer to the contact information provided on your warranty certificate.

© 2024 UPBRIGHT. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B009JHHL70

More documents and user manuals: **https://manuals.plus/**