Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coleman 2000012034

Coleman Triton Series InstaStart 2-Burner Stove Instruction Manual

Model: 2000012034

Introduction

The Coleman Triton Series InstaStart 2-Burner Stove is designed for outdoor cooking, offering reliable performance with two high-performance 11,000-BTU burners. This stove features InstaStart push-button matchless ignition for easy lighting, PerfectHeat Technology for consistent temperatures, and Wind Block Shields to protect flames. The spacious cooking surface accommodates a 10-inch and a 12-inch pan simultaneously, with independently adjustable controls for precise heat management. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your stove.

Important Safety Information

READ ALL INSTRUCTIONS BEFORE OPERATING THIS APPLIANCE.

- **Outdoor Use Only:** This appliance is for outdoor use only. Do not operate indoors, in enclosed areas, or under canopies.
- **Ventilation:** Ensure adequate ventilation. Operating this appliance in an unventilated space can be dangerous and may result in carbon monoxide poisoning.
- **Fuel:** Use only propane gas. Do not use any other fuel.
- **Leak Check:** Always perform a leak check after connecting the propane cylinder and before each use. Apply soapy water to connections; bubbles indicate a leak. Do not use if a leak is detected.
- **Clearance:** Maintain minimum clearances from combustible materials: 24 inches (61 cm) from sides and back, 48 inches (122 cm) from top.
- **Hot Surfaces:** Stove surfaces become extremely hot during operation. Use caution and wear protective gloves when handling. Allow the stove to cool completely before moving or storing.
- **Children and Pets:** Keep children and pets away from the stove during operation and while it is cooling.
- **Flammable Materials:** Keep flammable liquids and vapors away from the stove.
- **Cylinder Handling:** Always connect and disconnect the propane cylinder outdoors, away from ignition sources.

Setup Instructions

1. **Unpack the Stove:** Remove the stove from its packaging. Ensure all components, including the stove body, grates, and wind blocks, are present and undamaged.
2. **Position the Stove:** Place the stove on a stable, level, non-combustible surface outdoors. Ensure adequate clearance from combustible materials as specified in the safety section.
3. **Open the Stove and Set Up Wind Blocks:**

   Open the stove lid. The lid serves as a back wind block. Extend the side wind blocks by sliding them into the slots on the stove body. Ensure they are securely in place.



Image: The Coleman Triton Series InstaStart 2-Burner Stove is shown fully open with its lid acting as a back wind block and side wind blocks extended. A frying pan with food is on the left burner, and a propane cylinder is connected to the right side of the stove.

4. **Place Grates:** Position the cooking grates over the burners.
5. **Connect Propane Cylinder:**

   Ensure both burner control knobs are in the OFF position. Connect a 16.4-oz. propane cylinder (sold separately) to the regulator on the side of the stove. Hand-tighten until snug. Do not overtighten.

   Perform a leak check: Apply a soapy water solution to all connections. If bubbles appear, there is a leak. Tighten connections or replace parts as necessary. Do not operate the stove if a leak is present.

Operating Instructions

1. **Igniting a Burner:**
   - Ensure the propane cylinder is connected and the stove is set up correctly.
   - Turn the desired burner control knob slowly to the HIGH position.
   - Immediately press the InstaStart ignition button (red button) until the burner ignites. You may hear a clicking sound.
   - If the burner does not ignite within 5 seconds, turn the control knob to OFF, wait 5 minutes for gas to dissipate, and repeat the ignition process.
2. **Adjusting Flame:** Once ignited, turn the control knob to adjust the flame intensity from HIGH to SIMMER as

needed for cooking.

3. **Cooking:** Place cookware on the grates over the lit burners. The stove can accommodate a 10-inch pan and a 12-inch pan simultaneously.
4. **Shutting Down:**
    - When finished cooking, turn both burner control knobs to the OFF position.
    - Allow the stove to cool completely before disconnecting the propane cylinder or moving the stove.
    - Disconnect the propane cylinder by unscrewing it from the regulator.

Maintenance

- **Cleaning Grates:** The heavy-duty, nickel-chrome grates are removable for easy cleaning. Wash with warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry before reassembling.
- **Stove Body:** Wipe down the stove body with a damp cloth. For stubborn stains, use a mild detergent. Avoid abrasive cleaners that could damage the finish.
- **Burner Ports:** Periodically inspect burner ports for blockages. Use a small wire or needle to clear any debris.
- **Storage:** Ensure the stove is completely cool and clean before storing. Disconnect the propane cylinder. Close the lid and secure any latches. Store in a dry, protected area.

Troubleshooting

Problem	Possible Cause	Solution
Burner does not light with InstaStart.	No fuel, ignitor not sparking, gas not reaching burner, ignitor button stuck.	Check propane cylinder connection and fuel level. Ensure ignitor button is fully pressed and released. Clean ignitor electrode if dirty. If ignitor fails, use a long match or lighter to ignite manually.
Low flame or inconsistent flame.	Low fuel, partially clogged burner, regulator issue, wind interference.	Replace propane cylinder if empty. Clean burner ports. Ensure wind blocks are properly deployed. Check regulator for damage or blockages.
Gas leak detected (smell of gas, hissing sound, bubbles during leak test).	Loose connections, damaged hose/regulator, faulty cylinder valve.	Immediately turn off gas at the cylinder. Tighten all connections. If leak persists, do not use the stove. Replace faulty components or contact Coleman customer service.
Stove does not heat up sufficiently.	Low fuel, improper flame adjustment, extreme cold weather.	Ensure propane cylinder has sufficient fuel. Adjust flame to HIGH. In very cold conditions, propane pressure can be reduced; consider using a larger cylinder or warmer environment if possible.

Specifications

- **Model:** 2000012034
- **Brand:** Coleman
- **Fuel Type:** Propane

- **Burners:** 2
- **BTU per Burner:** 11,000 BTU
- **Total BTU:** 22,000 BTU
- **Ignition:** InstaStart Push-Button Matchless Ignition
- **Construction Material:** Alloy Steel
- **Cooking Surface:** Accommodates one 10-inch (25.4 cm) pan and one 12-inch (30.48 cm) pan simultaneously
- **Features:** PerfectHeat Technology, Wind Block Shields, PerfectFlow Pressure Control System, Independently-adjustable controls
- **Included Components:** Coleman 2 Burner Triton Series Stove Silver/Black 2000020954

Warranty Information

This Coleman Triton Series InstaStart 2-Burner Stove is covered by a Manufacturer Warranty. For specific details regarding the warranty period, coverage, and claims process, please refer to the warranty documentation included with your purchase or visit the official Coleman website. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, replacement parts, or further inquiries regarding your Coleman Triton Series InstaStart 2-Burner Stove, please contact Coleman customer service. You can typically find contact information, including phone numbers and online support portals, on the official Coleman website or within the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00AU6GHCY

More documents and user manuals: **https://manuals.plus/**