Bestway 67438

Bestway 67438 Pop-Up Beach Tent User Manual

Model: 67438 | Brand: Bestway

1. Introduction

Thank you for choosing the Bestway Pop-Up Beach Tent. This manual provides essential information for the safe and effective setup, use, and maintenance of your beach tent. Please read these instructions carefully before use and retain them for future reference.

2. Safety Information

WARNING:

- Do not puncture the tent material.
- Do not expose the tent to open flames or extreme heat sources.
- Ensure the tent is securely anchored to prevent it from blowing away in windy conditions.
- Keep children under supervision when near or inside the tent.
- This tent provides UV protection (UPF 40+), but prolonged exposure to direct sunlight should still be avoided.

3. Package Contents

Verify that all components are present before assembly:

- 1 x Bestway Pop-Up Beach Tent
- 1 x Carry Bag
- Ground stakes (quantity may vary, typically 4-6)

Image 1: Packaging of the Bestway Pop-Up Beach Tent, highlighting its features and compact folded size. The packaging also displays the UPC: 06942138911015.

4. Setup Instructions

The Bestway Pop-Up Beach Tent features a quick and easy pop-up design for instant setup.

1. **Unpack:** Remove the tent from its carry bag.
2. **Unfold:** The tent is designed to spring open automatically. Hold it away from your face and body as it unfolds.
3. **Position:** Place the tent in your desired location, ensuring the entrance faces away from the prevailing wind if possible.
4. **Secure:** Use the provided ground stakes to anchor the tent firmly to the ground, especially in sandy or windy conditions. Utilize any attached guy ropes for additional stability.

Image 2: The Bestway Pop-Up Beach Tent fully deployed, showcasing its spacious interior and stable structure.

5. Operating Instructions (Usage)

Your Bestway Pop-Up Beach Tent is designed for temporary outdoor use, providing shade and shelter.

- Use the tent primarily for shade and protection from light wind.
- The tent offers UPF 40+ UV protection, reducing exposure to harmful sun rays.
- Do not use in severe weather conditions, heavy rain, or strong winds.
- Ensure adequate ventilation, especially on hot days.

Image 3: A family enjoying the shade provided by the Bestway Pop-Up Beach Tent on a sunny beach, demonstrating its practical use.

6. Folding and Storage

Folding the pop-up tent requires a specific technique to return it to its compact size.

1. **Clear the Tent:** Remove all items from inside the tent.
2. **Clean:** Ensure the tent is clean and dry before folding to prevent mold or mildew.
3. **Collapse:** Gently push the top of the tent downwards, allowing the flexible frame to begin collapsing.
4. **Twist and Fold:** Follow the natural bend of the frame. Typically, this involves twisting the tent into a figure-eight shape and then folding it into a smaller circle. Refer to the diagrams on the carry bag or product packaging for visual guidance.
5. **Secure:** Once folded, use any attached straps or elastic bands to keep it compact.
6. **Store:** Place the folded tent back into its carry bag. Store in a cool, dry place away from direct sunlight and extreme temperatures.

7. Maintenance

- **Cleaning:** Wipe down the tent fabric with a damp cloth and mild soap if necessary. Rinse thoroughly and allow to air dry completely before storage. Do not use harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check the tent fabric, seams, and frame for any signs of wear, tear, or damage.
- **Repairs:** Small tears in the fabric can be repaired with a tent repair kit. Damaged frame components may require professional repair or replacement.

8. Troubleshooting

Problem	Possible Cause	Solution
Tent does not pop up correctly.	May be stuck or folded incorrectly from previous use.	Gently manipulate the frame to help it unfold. Ensure no fabric is snagged.
Tent is unstable.	Not properly anchored; windy conditions.	Ensure all ground stakes are firmly in place. Use guy ropes if available. Relocate to a less windy spot if possible.
Difficulty folding the tent.	Incorrect folding technique.	Refer to the folding instructions (Section 6) and any diagrams on the carry bag. Practice the twist-and-fold method.

9. Specifications

Feature	Detail
Model Number	67438
Manufacturer Product ID	8321205
Brand	Bestway
Assembled Dimensions (L x W x H)	193 x 119 x 84 cm (76 x 47 x 33 inches)
Material	170T Polyester Fabric
UV Protection	UPF 40+
Weight	Approximately 1.40 kg (3.09 lbs)
Assembly Required	Yes (Pop-up mechanism)
GTIN (UPC)	06942138911015

10. Legal Disclaimer

UNDER NO CIRCUMSTANCES SHALL Bestway BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES OF ANY KIND ARISING OUT OF BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY, OR OTHERWISE UNDER THIS AGREEMENT OR OTHERWISE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

11. Support

For further assistance, product information, or to report any issues, please contact Bestway customer support. Visit the official Bestway website for contact details and FAQs.
You can find more information about Bestway products at:Bestway Official Store

© 2023 Bestway. All rights reserved.