Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Briggs & Stratton 799538

Briggs & Stratton 799538 Piston Ring Installation and Maintenance Guide

Genuine Original Equipment Manufacturer (OEM) Part

Introduction

This manual provides essential instructions for the proper installation and maintenance of the Briggs & Stratton 799538 Piston Ring. This component is a genuine Original Equipment Manufacturer (OEM) part, designed to meet the exact specifications and quality standards of Briggs & Stratton engines. Using genuine OEM parts ensures optimal performance, reliability, and longevity of your equipment.

The piston ring plays a critical role in an engine's combustion process by sealing the combustion chamber, transferring heat from the piston to the cylinder wall, and regulating engine oil consumption. Correct installation is crucial for engine efficiency and preventing premature wear.

Important Safety Information

Always observe the following safety precautions when working with engine components:

- **Disconnect the Spark Plug:** Before performing any service, always disconnect the spark plug wire to prevent accidental engine starting.
- **Allow Engine to Cool:** Ensure the engine is completely cool before handling any parts to avoid burns.
- **Wear Protective Gear:** Use appropriate personal protective equipment, including safety glasses and gloves.
- **Work in a Well-Ventilated Area:** Ensure adequate ventilation to avoid inhaling fumes.
- **Refer to Engine Manual:** Consult your specific engine's service manual for detailed disassembly and reassembly procedures.

Compatibility Check

It is critical to verify that this piston ring (Part Number 799538) is compatible with your specific Briggs & Stratton engine model. Many replacement parts may appear similar but are designed for different engine specifications. Always cross-reference the part number with your engine's model and serial number before proceeding with installation.



Figure 1: Importance of verifying part compatibility with your engine model. Always check your engine's model number to ensure the correct fit for replacement parts.

Refer to your engine's owner's manual or the Briggs & Stratton website for assistance in locating your engine's model and type numbers.

Setup and Preparation

Required Tools:

- Socket wrench set
- Screwdrivers (flathead and Phillips)
- Piston ring compressor (recommended)
- Feeler gauges
- Clean rags
- Engine oil

- Service manual for your specific engine model

Engine Preparation:

1. Ensure the engine is cool and clean.
2. Disconnect the spark plug wire and secure it away from the spark plug.
3. Drain the engine oil and fuel (if necessary for engine removal).
4. Remove any components obstructing access to the cylinder head and piston assembly (e.g., air filter, carburetor, muffler, cylinder head cover).

Installation Instructions

The following steps provide a general guide for piston ring installation. Always refer to your specific engine's service manual for precise torque specifications and detailed procedures.

1. **Disassembly:** Carefully disassemble the engine to access the piston. This typically involves removing the cylinder head, oil pan, and connecting rod cap to remove the piston from the cylinder bore.
2. **Remove Old Rings:** Using a piston ring expander or by hand, carefully remove the old piston rings from the piston grooves. Note the orientation of each ring.
3. **Clean Piston Grooves:** Thoroughly clean the piston grooves to remove carbon deposits. Ensure the grooves are free of debris to allow the new rings to move freely.
4. **Inspect Piston and Cylinder:** Inspect the piston for wear or damage. Check the cylinder bore for scoring or excessive wear. Replace damaged components as necessary.
5. **Install New Rings:**
    - Start with the oil control ring (bottom ring), then the second compression ring, and finally the top compression ring.
    - Ensure the "TOP" mark (if present) on the compression rings faces upwards towards the piston crown.
    - Stagger the ring end gaps according to your engine's service manual, typically 90 or 120 degrees apart, to prevent blow-by.
    - Lightly lubricate the piston rings and cylinder bore with clean engine oil.
6. **Install Piston into Cylinder:** Use a piston ring compressor to carefully guide the piston and rings into the cylinder bore. Ensure the connecting rod is aligned correctly.
7. **Reassembly:** Reassemble the engine components in reverse order of disassembly, ensuring all fasteners are torqued to the manufacturer's specifications.



Figure 2: The Briggs & Stratton 799538 Piston Ring. This genuine OEM part is designed for precise fit and function within compatible Briggs & Stratton engines.

Post-Installation Checks and Initial Operation

After completing the installation, perform the following checks before starting the engine:

- **Fluid Levels:** Refill engine oil to the proper level and ensure fuel tank is adequately filled.
- **Connections:** Verify all hoses, wires, and fasteners are securely connected and tightened.
- **Spark Plug:** Reconnect the spark plug wire.
- **Initial Start:** Start the engine and allow it to run at a moderate speed for a few minutes. Listen for unusual noises and check for leaks.
- **Break-in Period:** Follow any recommended engine break-in procedures outlined in your engine's owner's manual, especially after major internal engine work.

Maintenance

Proper engine maintenance is essential for the longevity and performance of your Briggs & Stratton engine, including the piston rings. Adhere to the maintenance schedule provided in your engine's owner's manual. Key maintenance points include:

- **Regular Oil Changes:** Change engine oil at recommended intervals using the specified oil type. Clean oil helps prevent carbon buildup on piston rings.
- **Air Filter Maintenance:** Keep the air filter clean to ensure proper air-fuel mixture and prevent contaminants from entering the engine.
- **Spark Plug Inspection:** Inspect and replace spark plugs as needed to ensure efficient combustion.
- **Fuel System Care:** Use fresh, clean fuel and consider fuel stabilizers for storage to prevent fuel system issues that can indirectly affect engine performance.

Troubleshooting Common Issues

If you experience issues after piston ring replacement, consider the following:

Symptom	Possible Cause	Action
Excessive Blue Smoke from Exhaust	Improperly installed oil control ring, damaged oil ring, worn cylinder bore, incorrect oil level.	Recheck oil ring installation, inspect cylinder bore, verify oil level.
Loss of Engine Power / Compression	Incorrectly installed compression rings, broken rings, worn cylinder bore, improper ring end gap.	Verify ring orientation and end gaps, check for ring damage, perform compression test.
Engine Overheating	Piston rings not transferring heat effectively due to poor contact or carbon buildup.	Ensure proper ring seating, check for adequate lubrication and cooling system function.

If troubleshooting does not resolve the issue, it is recommended to consult a certified Briggs & Stratton service technician.

Specifications

- **Part Number:** 799538
- **Type:** Piston Ring
- **Manufacturer:** Briggs & Stratton
- **Status:** Genuine Original Equipment Manufacturer (OEM) Part
- **Weight:** Approximately 2 ounces (0.06 kg)

Warranty and Support

Warranty Information:

Genuine Briggs & Stratton OEM parts are typically covered by a limited warranty against defects in material and workmanship. For specific warranty terms and conditions applicable to the 799538 Piston Ring, please refer to the official Briggs & Stratton warranty statement or contact their customer service. Keep your proof of purchase for warranty claims.

Customer Support:

For further assistance, technical support, or to locate an authorized service dealer, please visit the official Briggs & Stratton website or contact their customer service department. Always provide your engine's model, type, and code numbers when seeking support.
Briggs & Stratton Official Website: www.briggsandstratton.com

© 2023 Briggs & Stratton. All rights reserved. This document is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00CNWW3KI

More documents and user manuals: **https://manuals.plus/**