Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

InSinkErator Evolution Plus 750 SR

InSinkErator Evolution Plus 750 SR Waste Disposer User Manual

Model: Evolution Plus 750 SR (80383T-ISE)

1. Introduction

Thank you for choosing the InSinkErator Evolution Plus 750 SR Waste Disposer. This powerful and quiet food waste disposer is designed to efficiently grind food scraps into fine particles, which are then flushed away with water. This manual provides essential information for the safe installation, operation, maintenance, and troubleshooting of your new appliance.

Image 1: Front view of the InSinkErator Evolution Plus 750 SR Waste Disposer. This image shows the main body of the disposer, featuring the InSinkErator logo and "Evolution Plus 750 SR" branding on its grey casing.

2. Safety Information

WARNING: Read all instructions carefully before using this appliance to reduce the risk of injury, electric shock, fire, or damage to property.

- Always ensure the disposer is properly grounded.
- Do not put hands or utensils into the disposer while it is operating.
- Do not dispose of non-food items such as glass, plastic, metal, or large bones.
- Always run cold water when operating the disposer.
- If the disposer jams, turn off the power before attempting to clear the jam.
- Keep children away from the disposer during operation.



Image 2: Rear view of the InSinkErator Evolution Plus 750 SR Waste Disposer. A caution label is visible, indicating safety warnings in multiple languages, emphasizing the importance of safe handling.

3. What's in the Box

Your InSinkErator Evolution Plus 750 SR package includes:

- InSinkErator Evolution Plus 750 SR Waste Disposer Unit
- Installation Material (mounting assembly, drain elbow, etc.)

- Stainless Steel Strainer Basket and Stopper
- Air Switch Button (integrated)
- User Manual (this document)



Image 3: Contents of the InSinkErator Evolution Plus 750 SR Waste Disposer box. The image displays the disposer unit, various plumbing components, power cord, and the instruction manual laid out in the packaging.

4. Setup and Installation

The InSinkErator Evolution Plus 750 SR is designed for easy installation in both new and existing kitchens and is suitable for most sinks. A standard sink opening diameter of 89 mm is required.

4.1 Pre-Installation Checks

- Ensure you have adequate space under the sink for the disposer unit.
- Verify that your sink drain opening is 89 mm in diameter.
- Confirm access to a grounded electrical outlet under the sink.

4.2 Installation Steps (Overview)

1. **Prepare the Sink:** Remove any existing sink flange and drain assembly. Clean the sink opening thoroughly.
2. **Install Mounting Assembly:** Apply plumber's putty around the sink flange and insert it into the sink opening. Secure the mounting assembly from underneath the sink according to the detailed instructions provided with the installation material.
3. **Connect Disposer to Mounting Assembly:** Lift the disposer unit and align its discharge outlet with the drain pipe. Attach the disposer to the mounting assembly by twisting or using the provided locking mechanism until it is securely in place.
4. **Connect Plumbing:** Attach the discharge elbow to the disposer and connect it to your household drain line. Ensure all connections are tight to prevent leaks.
5. **Electrical Connection:** Plug the disposer into a grounded electrical outlet. If hardwiring, ensure it is done by a qualified electrician.
6. **Test for Leaks:** Run water through the sink and check all connections for any leaks.



Image 4: The InSinkErator Evolution Plus 750 SR Waste Disposer installed neatly under a kitchen sink cabinet. The unit is connected to the sink drain and plugged into an electrical outlet, demonstrating a typical installation setup.

4.3 Dimensions

Refer to the diagram below for detailed dimensions to ensure proper fit under your sink.



Image 5: Dimensional diagram of the InSinkErator Evolution Plus 750 SR Waste Disposer. This technical drawing provides key measurements (e.g., height, width, drain pipe connections) necessary for installation planning.

5. Operating Instructions

The InSinkErator Evolution Plus 750 SR efficiently grinds most organic kitchen waste without blades. Food waste is pressed against a stationary grind ring by centrifugal force from a rotating disk, reducing it to fine particles.

1. **Turn on Cold Water:** Before operating the disposer, turn on a medium flow of cold water. This helps flush food particles and keeps the grinding chamber cool.
2. **Turn on Disposer:** Press the integrated air switch button to activate the disposer.
3. **Feed Food Waste:** Gradually feed food scraps into the sink opening. The Evolution Plus 750 SR can handle a wide range of food waste, including fruit and vegetable scraps, meat, fish, poultry bones, nut shells, and fruit pits.
4. **Continue Running Water:** Allow the disposer to run until all food waste is ground and flushed away. You will hear the motor sound change as the grinding chamber empties.
5. **Turn off Disposer:** Press the air switch button again to turn off the disposer.
6. **Turn off Water:** Let the cold water run for a few seconds after turning off the disposer to ensure all particles are flushed down the drain.



Image 6: A person's hand pressing the air switch button on the countertop next to a kitchen sink, indicating the activation of the InSinkErator waste disposer.



Image 7: Various food scraps, including vegetable peels and seeds, being fed into the sink drain opening where the InSinkErator waste disposer is installed, with water running.

Note: *The Evolution Plus 750 SR features MultiGrind 3-stage technology for efficient grinding of even difficult and fibrous food waste, and SoundSeal technology for quiet operation. It also has an automatic reverse grinding action to prevent jams.*

6. Maintenance

Regular maintenance helps ensure the longevity and efficient operation of your waste disposer.

- **Regular Cleaning:** Grind small bones (like chicken bones) or ice cubes periodically. This helps to scour the grinding chamber and remove any buildup.
- **Odor Control:** To eliminate odors, grind a lemon or orange peel with cold water. This will freshen the disposer and drain.
- **Avoid Grease Buildup:** Do not pour grease or oil down the drain. Allow it to solidify and dispose of it in the trash.
- **Keep it Clear:** Never use chemical drain cleaners in your disposer, as they can damage internal components.

7. Troubleshooting

If you encounter issues with your InSinkErator Evolution Plus 750 SR, try these common troubleshooting steps:

7.1 Disposer Does Not Start

- **Check Power:** Ensure the disposer is plugged in and the circuit breaker has not tripped.
- **Reset Button:** Locate the red reset button on the bottom of the disposer. Press it firmly. If it trips again, the motor may be overloaded or jammed.

7.2 Disposer Hums but Does Not Grind

- **Clear Jam:** This usually indicates a jam. Turn off the disposer and power. Use the provided hex wrench (or an Allen wrench) to insert into the center hole on the bottom of the disposer and turn it back and forth to free the grinding plate. Remove any foreign objects with tongs or pliers (never your hand).

7.3 Leaks

- **Check Connections:** Ensure all plumbing connections (sink flange, discharge elbow, dishwasher inlet) are tight and properly sealed.
- **Cracks:** If the disposer housing is cracked, it may need replacement. Contact customer support.

If these steps do not resolve the issue, please contact InSinkErator customer support.

8. Specifications

Feature	Specification
Model Number	80383T-ISE
Motor Power	0.75 HP (380 W)
Grinding Stages	3-stage MultiGrind Technology
Grind Chamber Capacity	980 ml (Stainless Steel)
Noise Reduction	SoundSeal Technology
Dimensions (Product)	28 x 28 x 32 cm
Weight	8.8 kg
Power Boost Circuit	Yes, with microprocessor
Integrated Air Switch	Yes
Automatic Reverse Grinding	Yes

9. Warranty and Support

The InSinkErator Evolution Plus 750 SR comes with a manufacturer's warranty of up to 7 years. To activate and validate your warranty, device registration on the manufacturer's website is required. This warranty applies exclusively to non-commercial use.
For technical support, warranty claims, or further assistance, please visit the official InSinkErator website or contact their customer service department.
Please retain your proof of purchase for warranty purposes.

© 2023 InSinkErator. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00CWXP08K

More documents and user manuals: **https://manuals.plus/**