Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Briggs & Stratton 591583

Briggs & Stratton 591583 Engine Air Filter

Genuine Original Equipment Manufacturer (OEM) Part

Model: 591583

Introduction

This instruction manual provides essential information for the proper installation and maintenance of your Briggs & Stratton 591583 Engine Air Filter. Regular maintenance of your air filter is crucial for ensuring the longevity and optimal performance of your lawn and garden equipment engine.
The Briggs & Stratton 591583 air filter is a genuine OEM part designed to meet the specific requirements of compatible Briggs & Stratton engines, ensuring proper fit and filtration efficiency.

Specifications

- **Brand:** Briggs & Stratton
- **OEM Part Number:** 591583
- **Product Dimensions:** 3 x 3 x 4 inches
- **Item Weight:** 0.01 ounces
- **Global Trade Identification Number (GTIN):** 00024847670165
- **EU Spare Part Availability Duration:** 5 Years
- **Automotive Fit Type:** Vehicle Specific Fit

Setup and Installation

Proper installation of the air filter is vital for protecting your engine from dust and debris. Always refer to your equipment's specific service manual for detailed instructions and safety precautions.

General Installation Steps:

1. **Locate the Air Filter Housing:** The air filter is typically located in a housing on the engine, often secured with clips or screws.
2. **Remove the Old Filter:** Carefully open the housing and remove the old air filter and any pre-cleaner foam. Note the orientation for correct installation of the new filter.
3. **Clean the Housing:** Wipe away any dust or debris from inside the air filter housing to prevent contamination of the new filter.
4. **Install the New Filter:** Place the new Briggs & Stratton 591583 air filter into the housing, ensuring it fits snugly. If your engine uses a pre-cleaner, install it over the new filter as directed by your equipment's manual.
5. **Secure the Housing:** Close and secure the air filter housing. Ensure all clips or screws are properly fastened to prevent air leaks.

For a visual guide on air filter replacement, please refer to the relevant videos in the Media Section.

Operating Principles

The Briggs & Stratton 591583 air filter plays a critical role in your engine's operation by preventing harmful contaminants such as dirt, dust, and debris from entering the carburetor and engine cylinders. A clean air filter ensures a proper air-to-fuel mixture, which is essential for efficient combustion, optimal engine power, and reduced emissions. Operating an engine with a dirty or clogged air filter can lead to reduced performance, increased fuel consumption, and premature engine wear.

Maintenance

Regular inspection and replacement of your air filter are key to maintaining engine health. The frequency of replacement depends on operating conditions and hours of use.

Recommended Maintenance Schedule:

- **Routine Inspection:** Check the air filter every 25 hours of operation or annually, whichever comes first. More frequent checks may be necessary in dusty or dirty environments.
- **Replacement:** Replace the air filter if it appears dirty, clogged, or damaged. A dirty filter can restrict airflow, causing the engine to run rich, lose power, and potentially overheat.
- **Pre-Cleaner (if applicable):** If your filter includes a foam pre-cleaner, it can often be cleaned with warm, soapy water, rinsed thoroughly, and allowed to air dry before reinstallation. Do not oil the paper filter element.

For practical demonstrations of air filter replacement, refer to the instructional videos in the Media Section.

Troubleshooting

Many common engine performance issues can be linked to a neglected air filter. If you experience any of the following, inspect your air filter:

- **Loss of Engine Power:** A clogged air filter restricts airflow, leading to a reduction in engine power and efficiency.
- **Increased Fuel Consumption:** An engine struggling to draw air through a dirty filter will consume more fuel.
- **Engine Running Rough or Stalling:** Inconsistent airflow can cause the engine to run unevenly or stall.
- **Excessive Smoke from Exhaust:** A rich fuel mixture due to insufficient air can result in black smoke.
- **Difficulty Starting:** A severely clogged filter can make the engine hard to start.

If these symptoms persist after replacing the air filter, consult a qualified service technician.

Warranty Information

Briggs & Stratton genuine parts are manufactured to high standards and are typically covered by a limited warranty against defects in material and workmanship. For specific warranty terms and conditions, please refer to the documentation provided with your original equipment or contact Briggs & Stratton customer service. Using non-genuine parts may void your equipment's warranty.

Customer Support

For further assistance, technical support, or to locate authorized service centers, please visit the official Briggs & Stratton website or contact their customer service department. Have your equipment's model and serial numbers ready for efficient service.

Product Media



Image: Briggs & Stratton 591583 Air Filter with pre-cleaner, showcasing its pleated paper element and foam pre-filter.



Image: Side view of the Briggs & Stratton 591583 Air Filter, highlighting the robust construction and mesh outer layer.

Instructional Videos

Watch video online

591583 Air Filter 796032 Pre-Filter Cleaner Compatible with B S 5429K

Video: This video provides a detailed overview of the Briggs & Stratton 591583 air filter and its accompanying pre-filter, highlighting their design and components.

Watch video online

591583 air filter replacement

Video: Watch this video for a step-by-step guide on replacing the 591583 air filter in a Husqvarna riding lawn mower, demonstrating the removal of the old filter and installation of the new one.

Watch video online

796032 591583 Air Filter Short Type Replace BS 5429K, 591383, 796032

Video: This video showcases the Briggs & Stratton 591583 air filter, emphasizing its premium design and construction for optimal engine performance.

© 2025 Briggs & Stratton. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00D6FFDUI

More documents and user manuals: **https://manuals.plus/**