**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## handy can opener 502182P

# Handy Can Opener Automatic One Touch Electric Can Opener

**Model: 502182P**

## Introduction

This manual provides instructions for the safe and efficient use of your Handy Can Opener Automatic One Touch Electric Can Opener. Please read all instructions carefully before first use and retain this manual for future reference. This device is designed to open standard-sized cans with a smooth, automatic operation.

## Safety Information

- Keep out of reach of children.
- Do not immerse the can opener in water or any other liquid.
- Ensure hands are clear of the cutting blade during operation.
- Remove batteries if the device will not be used for an extended period.
- Do not attempt to open bent or irregularly shaped cans, as this may damage the device or cause injury.
- The can opener removes the entire top rim of the can. Exercise caution when handling opened cans and lids, as edges may be sharp.

## Setup: Battery Installation

1. Turn the can opener upside down.
2. Locate the battery compartment cover.
3. Slide or unclip the cover to open the compartment.
4. Insert two (2) AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
5. Replace the battery compartment cover, ensuring it clicks securely into place.




HANDY
CAN-OPENER



Image: Top-down view of the Handy Can Opener, illustrating the location for battery installation.

## Operating Instructions

1. **Prepare the Can:** Place the can on a flat, stable surface. Ensure the can is not dented or damaged around the rim.
2. **Position the Opener:** Place the Handy Can Opener on top of the can, aligning the cutting wheel with the can's rim. The internal magnet will help secure it.
3. **Start Operation:** Press the single button on top of the can opener. The device will automatically grip the can and begin rotating, cutting along the outer edge of the lid.
4. **Automatic Stop:** The can opener will automatically stop once it has completed a full rotation around the can. Do not attempt to stop it manually during operation.
5. **Remove the Opener:** Once the cutting process is complete and the device has stopped, carefully lift the can opener from the can. The lid will remain attached to the opener via a magnet.
6. **Release the Lid:** Gently detach the lid from the can opener. Dispose of the lid safely.




Image: The Handy Can Opener placed on a can, ready for operation.






Image: A hand initiating the can opening process by pressing the start button.




Image: The can opener in action, demonstrating its automatic cutting mechanism.




Image: The can opener lifting the lid, which is held by the integrated magnet.

## Cleaning and Maintenance

- After each use, wipe the exterior of the can opener with a damp cloth.
- Do not use abrasive cleaners or scourers.
- Never rinse the can opener under running water or immerse it in water.
- Ensure the cutting wheel area is free from food debris. Use a small brush if necessary.
- Store the can opener in a dry place.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Can opener does not start. | Dead or incorrectly inserted batteries. | Check battery polarity or replace with fresh AA batteries. |
| Can opener gets stuck or stops mid-cycle. | Can is dented or irregularly shaped; cutting wheel is obstructed. | Ensure the can is standard and undamaged. Clean any debris from the cutting wheel. If stuck, gently lift the opener off the can. |
| Lid is not fully cut or detaches improperly. | Improper placement on can; weak batteries. | Reposition the opener carefully on the can. Replace batteries if they are low. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Can opener slides off the can. | Can surface is greasy or wet; can is not stable. | Ensure the can and the opener's contact points are clean and dry. Place the can on a stable, non-slip surface. |

## Specifications

- **Model:** 502182P
- **Brand:** handy can opener
- **Operation Mode:** Automatic
- **Material:** Plastic, Stainless Steel
- **Blade Material:** Stainless Steel
- **Power:** 2 AA batteries (not included)
- **Product Dimensions:** 7 x 3 x 5 inches
- **Item Weight:** 8.8 ounces
- **UPC:** 589476502190, 856788003463, 757445835888, 735343246487

## Warranty and Support

For warranty information or technical support, please refer to the retailer where the product was purchased or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

© 2023 Handy Can Opener. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

## Answered questions about this manual

**How do I open the battery compartment on the Handy Can Opener 502182P?**

To open the battery compartment on your Handy Can Opener (Model 502182P), follow these steps: Turn the device over: Flip the can opener upside down so the underside is facing you. Locate the cover:...

**Read full answer**

---

**Open the live page**

**https://manuals.plus/asin/B00DY8Q4Z0**

More documents and user manuals: **https://manuals.plus/**