Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire 318919501

Wall Oven Door Handle Instruction Manual

Model: 318919501 | Brand: Frigidaire

FRIGIDAIRE
Official Frigidaire brand logo.

1. Introduction

This instruction manual provides essential information for the proper installation, maintenance, and troubleshooting of your Frigidaire Wall Oven Door Handle, Part Number 318919501. This is a Genuine Original Equipment Manufacturer (OEM) part designed for specific Frigidaire wall oven models. Please read this manual thoroughly before proceeding with installation or any maintenance.

2. Safety Information

Your safety and the safety of others are very important. Always observe the following safety precautions when installing or servicing appliance parts:

- **Disconnect Power:** Before attempting any installation or repair, always ensure the appliance is disconnected from its power source to prevent electric shock.
- **Wear Protective Gear:** **Wear work gloves to protect your hands** from sharp edges or pinch points when installing this part.
- **Professional Assistance:** If you are unsure about any step or procedure, consult a qualified appliance technician.
- **Use Genuine Parts:** Only use genuine OEM replacement parts to ensure proper fit, function, and safety.

3. Product Overview

The Frigidaire Wall Oven Door Handle (Part Number 318919501) is a black, curved handle made from Acrylonitrile Butadiene Styrene (ABS) plastic. It is designed to be a direct replacement for the original handle on compatible Frigidaire wall ovens.



Image of the Frigidaire Wall Oven Door Handle, Part 318919501. The handle is black and has a sleek, curved design.

3.1. Included Components

- 1 x Wall Oven Door Handle (Part Number 318919501)
- Screws (typically pre-installed or included with the handle)

4. Compatibility and Setup

This door handle is specifically designed for Frigidaire wall ovens. It is crucial to verify compatibility with your specific oven model before installation. Many replacement parts may look similar but are not interchangeable.



Important reminder to check your appliance's model number to ensure part compatibility.

4.1. Compatible Models

This part is compatible with various Frigidaire wall oven models, including but not limited to:

- FGET2745KBA
- FGET2745KBB
- FGET2745KWB
- FGEW2745KBB
- FGEW2745KBA
- FGEW2745KWB
- FGET2745KWA
- FGEW2745KWA

Always refer to your appliance's owner's manual or the manufacturer's official website for a complete list of compatible models.

4.2. Installation Instructions

Follow these steps carefully to install the new door handle:

1. **Prepare:** Ensure the wall oven is completely cool and disconnected from the power supply.
2. **Access Screws:** Open the oven door. The handle mounting screws are typically located on the inside edge of the oven door, often concealed by plastic caps or a trim piece. Carefully remove any covers to expose the screws.
3. **Remove Old Handle:** Using a screwdriver, carefully loosen and remove the screws holding the old handle in place. Once the screws are removed, the old handle should detach easily.
4. **Install New Handle:** Align the new Frigidaire 318919501 door handle with the mounting holes on the oven door. Insert the provided screws (or the original screws if they are in good condition) into the mounting holes.
5. **Secure Handle:** **Carefully tighten the screws.** Do not overtighten, as this can strip the screw threads or damage the handle material. Tighten until the handle is firmly secured and does not wobble.
6. **Replace Covers:** If applicable, replace any plastic caps or trim pieces that were removed to conceal the screws.
7. **Test:** Gently open and close the oven door a few times to ensure the handle is securely attached and functions correctly.

5. Operating (Usage)

Once installed, the door handle functions as the primary means to open and close your wall oven door. Always grasp the handle firmly and apply even pressure when opening or closing the door. Avoid using excessive force or twisting the handle, as this can cause stress on the mounting points.

6. Maintenance

To ensure the longevity and appearance of your Frigidaire Wall Oven Door Handle:

- **Cleaning:** Clean the handle regularly with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage the finish.
- **Drying:** After cleaning, wipe the handle dry with a clean, soft cloth to prevent water spots.
- **Periodic Check:** Periodically check the handle's mounting screws to ensure they remain tight. If they become loose, gently tighten them, being careful not to overtighten.

7. Troubleshooting

If you encounter issues with your new door handle, consider the following:

- **Handle Feels Loose:** If the handle feels loose after installation, gently tighten the mounting screws. Ensure you are not overtightening, which can strip the threads or crack the plastic.
- **Handle Broke/Plastic Disintegrated:** This can occur if screws are overtightened during installation, causing stress fractures in the plastic. Ensure screws are tightened only until snug, not forced. If the handle is damaged, it will need to be replaced.

- **Handle Does Not Fit:** Double-check your oven's model number against the compatible models list. If your model is not listed, this handle may not be the correct replacement part.

8. Specifications

Specification	Detail
Part Number	318919501
Brand	Frigidaire
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Black
Exterior Finish	Black
Specific Uses For Product	Wall Oven Door
Included Components	Handle, Screws
Special Feature	Easy to Install
Package Dimensions	Approximately 24.95 x 2.8 x 2.5 inches

9. Warranty and Support

For information regarding the warranty of your Frigidaire Genuine OEM part, please refer to the documentation provided with your original appliance or contact Frigidaire customer support directly. You can typically find contact information on the official Frigidaire website or in your appliance's owner's manual.
When contacting support, please have your appliance's model number and the part number (318919501) readily available.

© 2024 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00E0047RI

More documents and user manuals: **https://manuals.plus/**