Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EcoAqua EFF-6013A

EcoAqua Supco WF287 Refrigerator Water Filter Cartridge (EFF-6013A) Instruction Manual

1. Introduction

The EcoAqua Supco WF287 Refrigerator Water Filter Cartridge (Model EFF-6013A) is designed to provide clean, filtered water for your refrigerator. This manual provides essential information for the proper installation, operation, and maintenance of your new water filter, ensuring optimal performance and water quality.

2. Important Safety Information

- Use this filter only with potable (safe to drink) water.
- Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.
- Replace the filter cartridge every 6 months or 500 gallons, whichever comes first, to maintain optimal filtration and prevent potential health risks.
- After installation, check for leaks around the filter housing. If leaks occur, ensure the filter is properly seated and tightened.
- Keep this manual for future reference.

3. Product Overview

The EcoAqua EFF-6013A water filter significantly reduces common contaminants found in tap water, including chlorine taste and odor, cysts, and lead. It is designed to fit specific refrigerator models, providing a reliable and effective filtration solution.



Image 3.1: The EcoAqua Supco WF287 Refrigerator Water Filter Cartridge (Model EFF-6013A).

Compatibility

This filter is compatible with GE and Hotpoint refrigerators that utilize a round white plastic filter mounted inside the refrigerator compartment, typically above the top shelf. It is a replacement for the GE MWF filter model.



Image 3.2: Visual guide for identifying compatible filter models, showing the EcoAqua EFF-6013A as a replacement for MWF.

Filtration Technology

The filter utilizes healthy and organic coconut shells to achieve efficient and effective filtration, improving water taste and clarity.



Image 3.3: Cross-section diagram illustrating the coconut shell filtration media used in the filter.

Certifications

The EcoAqua EFF-6013S (a variant of this model) is tested and certified by NSF International against NSF/ANSI Standards 42 and 372 for the reduction of chlorine, taste, and odor.



Image 3.4: NSF certification details for the EcoAqua filter, confirming compliance with standards 42 and 372.

4. Setup and Installation

The EcoAqua water filter is designed for easy installation and quick replacement. Follow these steps to install your new filter:

1. **Locate the Old Filter:** The filter is typically located inside the refrigerator compartment, often above the top shelf.
2. **Twist to Remove:** Grasp the old filter and twist it counter-clockwise until it unlocks from the housing. Pull it straight out. Some water may drip, so have a towel ready.
3. **Prepare New Filter:** Remove the protective cap from the new EcoAqua filter.
4. **Insert New Filter:** Align the new filter with the filter housing. Push it firmly into the housing.
5. **Twist to Secure:** Twist the new filter clockwise until it locks into place. You may feel a slight click or resistance when it is fully seated.
6. **Check for Leaks:** After installation, visually inspect the area around the filter for any signs of water leakage.



Image 4.1: The filter is designed for a secure fit, minimizing the risk of leaks.

5. Operating Instructions

After installing the new water filter, it is important to flush the system to remove any air and loose carbon particles. This ensures optimal water quality and flow.

1. **Flush the System:** Dispense approximately 2-3 gallons (7.5-11 liters) of water through the refrigerator's water dispenser. This process helps to clear any trapped air and fine carbon dust from the new filter.
2. **Initial Water Quality:** The first few glasses of water may appear cloudy or contain black specks. This is normal and will clear up as the system is flushed.
3. **Enjoy Fresh Water:** Once flushed, your refrigerator will dispense fresh, filtered water.



Image 5.1: The filter helps maintain and ensure the freshness of your drinking water.

6. Maintenance

Regular maintenance is crucial for the continued performance and safety of your water filter.

Filter Replacement

- **Replacement Schedule:** Replace your EcoAqua water filter every 6 months or after filtering 500 gallons of water, whichever comes first. This ensures optimal filtration efficiency and prevents bacterial growth.
- **Indicator Light:** Many refrigerators have a filter indicator light that signals when it's time to replace the filter. Refer to your refrigerator's owner's manual for specific instructions on how to reset this light after replacement.

7. Troubleshooting

If you encounter any issues with your water filter, refer to the following common troubleshooting tips:

- **Slow Water Flow:** This can be caused by air trapped in the system or a clogged filter. Ensure the filter is properly installed and flush the system with 2-3 gallons of water. If the issue persists, the filter may be past its service life and require replacement.
- **Water Leaking:** Check that the filter is fully inserted and twisted clockwise until it is securely locked in place. Remove and re-install the filter if necessary.
- **Bad Taste or Odor After Replacement:** This is usually due to residual carbon fines. Continue flushing the system with water until the taste and odor improve. If the problem persists after flushing several gallons, ensure the filter is correctly installed and not defective.
- **Filter Indicator Light Not Resetting:** Consult your refrigerator's owner's manual for specific instructions on how to reset the filter indicator light for your model. The reset procedure varies by manufacturer.

8. Specifications

Attribute	Detail
Brand	EcoAqua
Model Number	EFF-6013A
Part Number	EFF-6013A
Product Dimensions	7.94 x 7.94 x 13.97 cm
Item Weight	345 g
Filter Life	6 months or 500 gallons (whichever comes first)
Material	Plastic
Certifications	NSF/ANSI 42 & 372 (for EFF-6013S)
Compatibility	GE and Hotpoint refrigerators using MWF filter

9. Warranty Information

Specific warranty details for the EcoAqua Supco WF287 Refrigerator Water Filter Cartridge (Model EFF-6013A) are not provided in this manual. For comprehensive warranty information, please refer to the product packaging, the manufacturer's official website, or contact EcoAqua customer support directly.

10. Support

If you require further assistance, have questions about installation, or need to report an issue, please contact EcoAqua customer service. Contact information can typically be found on the product packaging or the official EcoAqua website.

© 2026 EcoAqua. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00E37TR6E

More documents and user manuals: **https://manuals.plus/**