Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HCDZ LYSB00EQ1W7IC-ELECTRNCS

HCDZ Projector Remote Control User Manual

Model: LYSB00EQ1W7IC-ELECTRNCS

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your HCDZ replacement projector remote control. This remote is designed to be compatible with various Hitachi projector models, offering a direct replacement for your original remote.
Compatible Hitachi Projector Models: CP-X275WT, CP-X275WA, CP-X300, CP-X301, CP-X3010, CP-X3011, CP-X3W, CP-X3030WN.

Setup

1. Battery Installation

The remote control requires two (2) AA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.



Image: Rear view of the remote control with the battery cover removed, illustrating the correct orientation for AA battery insertion.

Once batteries are installed, the remote control is ready for use. No programming is required.

Operating Instructions

Basic Functionality

This remote control functions as a direct replacement for your original Hitachi projector remote. Point the remote control directly at the projector's infrared (IR) receiver window and press the desired function button.



Image: Front view of the HCDZ projector remote control, displaying the layout of its buttons for various functions.

- **Power Button:** Turns the projector on or off.
- **Input Select:** Cycles through available input sources (e.g., HDMI, VGA).
- **Menu/Navigation Buttons:** Access and navigate the projector's on-screen menu.
- **Volume Control:** Adjusts the audio output if the projector has built-in speakers.
- *Specific button functions may vary slightly based on your projector model. Refer to your projector's manual for detailed function descriptions.*

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.

Troubleshooting

- **Remote not responding:**
  - Ensure fresh AA batteries are correctly installed.
  - Check for any obstructions between the remote and the projector's IR receiver.
  - Verify that the remote is pointed directly at the projector.
- **Intermittent response:**
  - Batteries may be low; replace them.
  - Ensure there are no strong light sources (like direct sunlight or fluorescent lights) interfering with the IR signal.

Specifications

Brand	HCDZ
Model Number	LYSB00EQ1W7IC-ELECTRNCS
Compatible Devices	Hitachi Projectors (CP-X275WT, CP-X275WA, CP-X300, CP-X301, CP-X3010, CP-X3011, CP-X3W, CP-X3030WN)
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Maximum Range	10 Meters
Batteries Required	2 x AA (not included)
Special Feature	Ergonomic design

Warranty

This HCDZ remote control comes with a**90-day warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for any warranty claims.

Support

For any questions, concerns, or technical assistance regarding your HCDZ projector remote control, please contact the seller or manufacturer directly through your purchase platform. Provide your model number (LYSB00EQ1W7IC-ELECTRNCS) and a detailed description of the issue for efficient support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00EQ1W7IC

More documents and user manuals: **https://manuals.plus/**