Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Home-X SH196

Home-X SH196 Desktop Mug and Candle Warmer Instruction Manual

Model: SH196

1. Introduction

Thank you for choosing the Home-X SH196 Desktop Mug and Candle Warmer. This device is designed to keep your coffee, tea, or other beverages warm, and can also be used to melt scented wax or candles, providing a pleasant aroma without an open flame. Please read this manual thoroughly before use to ensure safe and optimal operation.

2. Important Safety Instructions

- Read all instructions before using this appliance.
- This appliance is for household use only. Do not use outdoors.
- Always place the warmer on a flat, stable, heat-resistant surface.
- Do not immerse the warmer, cord, or plug in water or other liquids.
- Unplug from outlet when not in use and before cleaning. Allow to cool before handling.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only with ceramic or glass mugs/containers that have a flat bottom for optimal heat transfer.
- Keep out of reach of children and pets.
- The heating surface becomes hot during operation. Avoid direct contact with the heating plate.
- Do not place flammable materials on or near the warmer.
- This product is UL listed 120V 60Hz 17W.

3. Package Contents

- 1 x Home-X SH196 Desktop Mug and Candle Warmer
- 1 x Integrated Power Cord with On/Off Switch

4. Setup

1. Unpack the mug warmer and remove all packaging materials.
2. Place the warmer on a stable, flat, and heat-resistant surface, such as a desk or countertop.
3. Ensure the power cord is easily accessible and not obstructed.
4. Plug the power cord into a standard 120V AC electrical outlet.

5. Operating Instructions

5.1 Keeping Beverages Warm

1. Place your ceramic or glass mug, filled with your desired beverage, onto the center of the heating plate. Ensure the mug has a flat bottom for maximum contact with the heating surface.
2. Locate the On/Off switch on the power cord. Flip the switch to the 'ON' position.
3. The red indicator light on the warmer will illuminate, indicating that the device is heating.
4. The warmer will maintain your beverage at a warm temperature.
5. To turn off, flip the On/Off switch to the 'OFF' position. The indicator light will turn off.



Image: The Home-X Mug Warmer keeping a white mug of coffee warm. The red indicator light is visible, showing the device is active.



Image: A grey mug with steam rising from it, placed on the Home-X Mug Warmer. A bright red indicator light is visible, signaling that the beverage is hot.

5.2 Melting Candles or Wax

1. Place your candle in a heat-safe container or a dish with wax cubes onto the center of the heating plate. Ensure the container has a flat bottom for optimal heat transfer.
2. Flip the On/Off switch on the power cord to the 'ON' position.
3. The red indicator light will illuminate.
4. The warmer will gently melt the wax, releasing the fragrance into the room.
5. To turn off, flip the On/Off switch to the 'OFF' position. The indicator light will turn off.



Image: A collage demonstrating the multiple uses of the Home-X Mug Warmer, including warming coffee, milk, tea, melting wax cubes in a bowl, and warming candles in jars.

Image: The Home-X Mug Warmer being used to warm a large candle jar, creating a fragrant atmosphere.

6. Maintenance

6.1 Cleaning

- Always unplug the warmer and allow it to cool completely before cleaning.
- Wipe the heating plate and exterior with a soft, damp cloth.
- Do not use abrasive cleaners or scouring pads, as these can damage the surface.
- Do not immerse the warmer in water or any other liquid.

7. Troubleshooting

7.1 Warmer Not Turning On

- Check if the power cord is securely plugged into a working electrical outlet.
- Ensure the On/Off switch on the cord is in the 'ON' position.
- Verify that the outlet is functional by plugging in another appliance.

7.2 Beverage/Wax Not Heating Sufficiently

- Ensure the mug or container has a flat bottom to maximize contact with the heating plate.
- Confirm that the mug or container material is ceramic or glass, as metal or plastic may not transfer heat effectively or safely.
- Allow sufficient time for the warmer to reach its operating temperature and for heat to transfer to the contents.

8. Specifications

Model Number	SH196
Brand	Home-X
Item Weight	6.4 ounces
Product Dimensions	5.25 x 5.25 x 1 inches
Heating Surface Diameter	3.5 inches
Voltage	120 Volts
Wattage	17 watts
Upper Temperature Rating	160 Degrees Fahrenheit
Material	Plastic
Color	White



Image: The Home-X Mug Warmer with its dimensions clearly labeled, showing a 3.5-inch heating surface diameter, 5.6-inch height, and 7-inch width. Also highlights anti-slip felt bottom and on/off switch on the cord.

9. Warranty and Support

For any questions, concerns, or support regarding your Home-X SH196 Desktop Mug and Candle Warmer, please contact the manufacturer, Home-X. Specific warranty details may vary; please refer to any documentation included with your purchase or contact Home-X directly for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00FL5V5NU

More documents and user manuals: **https://manuals.plus/**