Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Best Price Square BPSCA URC1910 - HS01765

One for All Samsung Replacement Remote Control URC 1910 User Manual

Model: URC 1910 (BPSCA URC1910 - HS01765)

Brand: Best Price Square

Introduction

This manual provides comprehensive instructions for the One for All URC 1910 Samsung Replacement Remote Control. It covers setup, operation, maintenance, troubleshooting, and product specifications to ensure optimal use of your remote control. This remote is designed to work seamlessly with a wide range of Samsung televisions.

Setup

The One for All URC 1910 remote control is pre-programmed for Samsung televisions and typically requires no setup. Simply insert batteries, and it should function immediately with your Samsung TV.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AA batteries, ensuring the positive (+) and negative (-) terminals align with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.





Figure 1: The One for All URC 1910 remote control, showing its ergonomic design and button layout. This image provides an overall view of the product.

Operating Instructions

The URC 1910 remote control provides all essential functions for your Samsung television. Point the remote directly at your TV's infrared receiver for optimal performance.

Button Functions





Figure 2: Front view of the URC 1910 remote control, highlighting the various buttons and their positions.

- **Power (●)**: Turns the TV on or off.
- **Source**: Selects input sources (HDMI, AV, etc.).
- **Number Buttons (0-9)**: Direct channel selection.
- **Volume (+/-)**: Adjusts the volume level.
- **Channel (CH +/-)**: Changes TV channels.
- **Mute**: Mutes or unmutes the TV sound.
- **Menu**: Accesses the TV's main menu.
- **Guide**: Displays the electronic program guide (EPG).
- **Tools**: Opens a quick menu for common functions.
- **Info**: Displays information about the current program or input.
- **Navigation Buttons (Up, Down, Left, Right)**: Navigates through menus and options.
- **OK**: Confirms selections.
- **Return**: Goes back to the previous screen or menu.
- **Exit**: Exits the current menu or application.
- **Color Buttons (A, B, C, D)**: Functions vary depending on the TV model and content.
- **P.MODE** / **S.MODE** / **P.SIZE** / **DUAL**: Picture mode, Sound mode, Picture size, and Dual view functions.
- **Playback Controls (Rewind, Play/Pause, Fast Forward, Record)**: Controls media playback on compatible devices or TV functions.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

Cleaning

- Wipe the remote control with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not spray cleaner directly onto the remote.
- Avoid using harsh chemicals, solvents, or abrasive cleaning materials, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Refer to the "Battery Installation"

section under "Setup" for detailed steps.

- Always replace both batteries at the same time.
- Use new AA alkaline batteries for best performance.
- Dispose of old batteries responsibly according to local regulations.

Troubleshooting

If you experience issues with your remote control, try the following solutions:

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Make sure you are within the effective operating range (typically up to 10 meters) and pointing the remote directly at the TV.
- **Specific buttons not working:**
  - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris that might be preventing proper contact.
  - If the remote has been dropped or damaged, internal components might be affected.
- **Remote works intermittently:**
  - This often indicates low battery power. Replace the batteries.
  - Ensure consistent line of sight to the TV.

If the issue persists after trying these steps, contact customer support or refer to the manufacturer's website for further assistance.

Specifications

Feature	Detail
Brand	Best Price Square (Manufacturer: One For All)
Model	BPSCA URC1910 - HS01765 (URC 1910)
Compatible Devices	Television (Samsung TVs)
Connectivity Technology	Infrared
Special Features	Ergonomic design
Batteries Required	Yes (2 AA batteries)
Batteries Included	No
Product Dimensions	20.6 x 5.1 x 2.4 cm
Item Weight	100 g
First Available Date	October 6, 2013

Warranty and Support

For information regarding product warranty, please refer to the documentation included with your purchase or visit the official website of One For All or Best Price Square. For technical support or further assistance, please contact the manufacturer's customer service department.
Keep your purchase receipt as proof of purchase for warranty claims.

© 2023 Best Price Square. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00FLOQ1SA

More documents and user manuals: **https://manuals.plus/**