Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

QFX TV-LED1611

QFX 16" LED TV User Manual

Model: TV-LED1611

Introduction

Thank you for purchasing the QFX TV-LED1611 16-inch LED Television. This manual provides essential information for setting up, operating, and maintaining your new television. Please read this manual thoroughly before using the product to ensure proper operation and to maximize your viewing experience. Keep this manual for future reference.

Safety Information

Always observe the following safety precautions to avoid injury or damage to the unit:

- Do not expose the TV to rain or moisture.
- Do not block ventilation openings. Ensure adequate space around the TV for proper airflow.
- Use only attachments/accessories specified by the manufacturer.
- Unplug the TV during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.
- Do not place the TV on an unstable cart, stand, tripod, bracket, or table.
- Keep the TV away from direct sunlight, heat sources, and strong magnetic fields.

Package Contents

Please check that all items are included in your package:

- QFX TV-LED1611 16" LED TV
- Remote Control
- AC Power Adapter
- 12V Car Adapter
- User Manual (this document)

Product Overview

Familiarize yourself with the main components of your QFX TV-LED1611.



Figure 1: Front view of the QFX TV-LED1611. This image shows the television screen, the QFX logo at the bottom center, and the integrated stand. The screen displays a vibrant image of a clownfish amidst sea anemones, indicating its display capabilities.

Front Panel

- **LED Display:** The main screen for viewing content.
- **Power Indicator:** Illuminates when the TV is powered on.

Rear Panel / Side Ports

- **HDMI Port:** For connecting high-definition devices like Blu-ray players, game consoles, or set-top boxes.
- **USB Port:** For connecting USB storage devices to play media files.
- **AV In (Composite):** For connecting standard definition devices using RCA cables (yellow, white, red).
- **Component In (YPbPr):** For connecting devices using component video cables (red, green, blue) and audio cables.
- **PC (VGA) Input:** For connecting a computer.
- **PC Audio In:** For audio input when connecting a PC via VGA.
- **Headphone Output:** For connecting headphones.
- **RF Antenna Input:** For connecting an antenna or cable TV signal.
- **DC 12V Input:** For connecting the included AC power adapter or 12V car adapter.

Setup

1. Unpacking and Placement

- Carefully remove the TV from its packaging.
- Place the TV on a stable, flat surface or mount it securely using a compatible VESA mount (not included).
- Ensure there is adequate ventilation around the TV.

2. Connecting Power

- **For Home Use:** Connect the AC power adapter to the DC 12V input on the TV, then plug the adapter into a standard wall outlet.
- **For Car Use:** Connect the 12V car adapter to the DC 12V input on the TV, then plug the adapter into your vehicle's 12V power outlet.

3. Connecting External Devices

Connect your desired devices to the appropriate ports on the TV.

- **Antenna/Cable:** Connect an RF coaxial cable from your antenna or cable TV wall outlet to the RF Antenna input.
- **HDMI Devices:** Connect an HDMI cable from your device (e.g., DVD player, game console) to the HDMI port on the TV.
- **USB Devices:** Insert a USB flash drive into the USB port for media playback.

OPERATING

1. Power On/Off

- Press the **POWER** button on the remote control or on the TV to turn the TV on or off.

2. Initial Setup (First Time Use)

The first time you turn on the TV, a setup wizard may appear to guide you through basic settings:

- **Language Selection:** Choose your preferred language.
- **Time Zone/Region:** Set your local time zone.
- **Channel Scan:** Select 'Auto Scan' to search for available digital and analog channels. This process may take several minutes.

3. Input Source Selection

To switch between connected devices:

- Press the **SOURCE** or **INPUT** button on the remote control.
- Use the arrow keys to navigate and select the desired input (e.g., HDMI, AV, USB, TV).
- Press **OK** or **ENTER** to confirm.

4. Menu Navigation

Use the remote control to access and adjust TV settings:

- Press the **MENU** button to open the main menu.
- Use the **UP/DOWN** arrow keys to select a menu category (e.g., Picture, Sound, Channel, Setup).
- Use the **LEFT/RIGHT** arrow keys to adjust settings or enter sub-menus.
- Press **EXIT** or **MENU** again to close the menu.

5. Media Playback (USB)

To play media files from a USB device:

- Insert your USB flash drive into the USB port.
- Select 'USB' as the input source.
- Navigate through the folders and files using the arrow keys.
- Press **OK** or **ENTER** to play a selected file.

MAINTENANCE

Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and cabinet.
- For stubborn marks, dampen the cloth lightly with water or a mild, non-abrasive screen cleaner. Never spray cleaner directly onto the screen.
- Avoid using abrasive cleaners, waxes, or solvents.

Storage

- If storing the TV for an extended period, disconnect all cables and store it in a cool, dry place.
- It is recommended to use the original packaging for storage and transport.

Troubleshooting

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cord not connected; Power outlet not working	Ensure power cord is securely plugged in; Test outlet with another device.
No picture, but sound is present	Incorrect input source selected; Loose video cable connection	Press SOURCE/INPUT button to select correct input; Check video cable connections.
No sound, but picture is present	Volume is muted or too low; Incorrect audio settings	Press MUTE or increase volume; Check audio settings in the menu.
Remote control not working	Batteries are dead or inserted incorrectly; Obstruction between remote and TV	Replace batteries; Ensure clear line of sight to TV's IR sensor.
Cannot find channels	Antenna not connected or positioned correctly; Channel scan not performed	Connect antenna and adjust position; Perform an auto channel scan.

Specifications

Feature	Specification
Model Number	TV-LED1611
Screen Size	16 Inches (Visible screen diagonal: 41 cm)
Display Technology	LCD, LED
Resolution	1366 x 768 (Supports 1080p input)
Aspect Ratio	16:9
TV Tuner	ATSC/NTSC

Feature	Specification
Connectivity	1x HDMI, 1x USB, AV In, Component In, PC In, PC Audio In, Headphone Out, RF Antenna In
Power Input	12 Volts DC (AC adapter and 12V car adapter included)
Product Dimensions (L x W x H)	52.07 x 17.15 x 44.45 cm (with stand)
Item Weight	1.42 kg (3.14 Pounds)
Model Year	2016

Warranty and Support

For warranty information, please refer to the warranty card included with your product. If you require technical support or have questions not covered in this manual, please contact QFX customer service through the contact information provided on the warranty card or the official QFX website.
Please retain your proof of purchase for warranty claims.

© 2024 QFX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00G6K8A50

More documents and user manuals: **https://manuals.plus/**