Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Babycakes MT-6

Babycakes 3-in-1 Removable Plate Treat Maker (Model MT-6)

Instruction Manual

1. Introduction

The Babycakes 3-in-1 Removable Plate Treat Maker, Model MT-6, is a versatile mini kitchen appliance designed for baking cake pops, cupcakes, and donuts. This manual provides essential information for safe and efficient operation, maintenance, and care of your new treat maker.



Image 1: The Babycakes 3-in-1 Removable Plate Treat Maker.

2. Product Features

- **Easy-to-Clean Baking Appliances:** This baking gadget comes with 3 dishwasher-safe, nonstick baking plates and a convenient cord wrap for hassle-free maintenance.
- **Bake Cake Pops & More:** Bake up to 12 cake pops, 7 cupcakes, or 7 donuts with this unique baking tool, perfect for various occasions.
- **Unique Cake Pop Maker:** Enjoy baking mini cupcakes, mini donuts, and cake pops all in one versatile appliance with interchangeable plates.
- **Easy-to-Use Baking Gadget:** This treat maker features an easy-lift latching handle, non-skid rubber feet, and a convenient cord wrap for user convenience.
- **Recipe Booklet Included:** The appliance includes a recipe booklet with hints and suggestions to get you started.



Image 2: The 3-in-1 Treat Maker showcasing its interchangeable plates for different treats.

3. Specifications

Feature	Detail
Model Number	MT-6
Wattage	760 watts
Voltage	120.0 V
Product Dimensions (D x W x H)	8.35"D x 10.35"W x 4.65"H
Item Weight	4 Pounds
Material	Plastic
Color	Red
Included Components	Multi-Treat Base Unit, 3 Sets of Interchangeable Non-Stick Baking Plates



Image 3: Product dimensions and electrical specifications.

4. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, wipe the exterior of the unit with a damp cloth. Wash the removable baking plates in warm, soapy water, rinse thoroughly, and dry completely.
3. **Insert Plates:** Choose the desired baking plates (cake pop, cupcake, or donut) and securely insert them into the base unit. Ensure they click into place.
4. **Placement:** Place the treat maker on a stable, heat-resistant surface near an electrical outlet.



Image 4: Components of the Babycakes Treat Maker.

5. Operating Instructions

1. **Preheat:** Close the lid and plug in the appliance. The power indicator light will illuminate, signaling that the unit is preheating. Wait until the ready indicator light turns on (or off, depending on the model's specific indicator behavior, refer to the included manual for exact light indications) to confirm preheating is complete.
2. **Prepare Batter:** Use your preferred recipe for cake pops, cupcakes, or donuts. A recipe booklet is included

with the product for guidance.

3. **Fill Plates:** Open the lid. Carefully pour or spoon batter into each cavity of the baking plates. Do not overfill to prevent overflow.
4. **Bake:** Close the lid. Baking times will vary depending on the recipe and desired doneness, typically 5-7 minutes. Refer to your recipe for specific baking durations.
5. **Remove Treats:** Once baked, carefully open the lid. Use a non-metallic utensil (such as a wooden skewer or silicone spatula) to gently remove the treats from the non-stick plates.
6. **Repeat:** Close the lid to allow the unit to reheat between batches, if necessary, and continue baking until all batter is used.



Image 5: Step-by-step baking process.



Image 6: Baked cake pops in the maker.

Your browser does not support the video tag.

Video 1: Official Babycakes 3-in-1 Treat Maker MT-6 Features. This video demonstrates the interchangeable plates and the baking process for mini donuts, cake pops, and cupcakes.

6. Cleaning and Maintenance

1. **Unplug and Cool:** Always unplug the appliance from the electrical outlet and allow it to cool completely before cleaning.
2. **Remove Plates:** Once cool, carefully remove the baking plates from the unit.
3. **Wash Plates:** The non-stick baking plates are dishwasher-safe. Alternatively, they can be washed by hand in warm, soapy water using a soft sponge. Rinse thoroughly and dry completely before storing or re-inserting.
4. **Clean Base Unit:** Wipe the exterior of the base unit with a damp cloth. Do not immerse the base unit in water or any other liquid.
5. **Storage:** Use the convenient cord wrap feature to store the power cord neatly. Store the appliance and plates in a dry place.

7. Troubleshooting

- **Appliance Not Heating:** Ensure the unit is properly plugged into a working electrical outlet. Check if the power indicator light is on.
- **Treats Sticking:** Although the plates are non-stick, a light spray of cooking oil or butter can be applied before each batch to ensure easy release. Ensure plates are clean and free of residue.
- **Uneven Baking:** Ensure the batter is evenly distributed in each cavity. Avoid opening the lid frequently during baking, as this can cause heat loss and uneven cooking.
- **Overflowing Batter:** Do not overfill the cavities. Start with a smaller amount of batter and adjust as needed for your specific recipe.

8. Safety Information

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use appliance for other than intended use.

9. Warranty and Support

This Babycakes 3-in-1 Removable Plate Treat Maker comes with a**1-Year Limited Manufacturer Warranty**. For warranty claims, technical support, or any questions regarding your appliance, please refer to the contact information provided in the original packaging or visit the official Babycakes website.

© 2023 Babycakes. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00GJ9MA2W

More documents and user manuals: **https://manuals.plus/**