Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Weiser GAC531 Y15 SMT MS 6LR1

Weiser Yukon Entry Knob (GAC531 Y15 SMT MS 6LR1) User Manual

Satin Nickel Finish

Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Weiser Yukon Entry Knob. Designed for standard doors, this knob features a satin nickel finish and offers secure entry with key access from the exterior and a turn button for locking/unlocking from the interior. Please read these instructions carefully before beginning installation or use.

Safety Information

- Always wear appropriate safety gear, such as gloves and eye protection, during installation.
- Keep small parts away from children to prevent choking hazards.
- Use only the tools specified in this manual.
- Do not attempt to modify the product. Any modifications may void the warranty and compromise security.

Package Contents

Verify that all components are present before beginning installation:

- Exterior Knob Assembly (with key cylinder)
- Interior Knob Assembly (with turn button)
- Adjustable Latch (2-3/8" or 2-3/4" backset)
- Strike Plate
- Mounting Screws
- Keys (typically 2)

Tools Required

The following tools are typically required for installation:

- Phillips Head Screwdriver
- Measuring Tape
- Pencil

Setup (Installation)

Follow these steps to install your Weiser Yukon Entry Knob:

1. **Prepare the Door:** Ensure your door has standard bore holes (typically 2-1/8" diameter for the knob and 1" diameter for the latch). Measure the backset (distance from the door edge to the center of the knob hole). The adjustable latch supports both 2-3/8" and 2-3/4" backsets.
2. **Install the Latch:** Insert the latch into the edge of the door. Ensure the bevel of the latch bolt faces the door frame. If necessary, adjust the latch to the correct backset by twisting the housing. Secure the latch with the provided screws.
3. **Install Exterior Knob:** Insert the exterior knob assembly (with the key cylinder) through the larger hole in the door, ensuring the spindle passes through the latch mechanism.
4. **Install Interior Knob:** Align the interior knob assembly (with the turn button) with the exterior knob. Ensure the mounting posts from the exterior knob pass through the holes in the interior knob's mounting plate.
5. **Secure the Knobs:** Fasten the interior and exterior knobs together using the provided mounting screws. Tighten securely, but do not overtighten, to avoid damaging the door or knob mechanism.
6. **Install Strike Plate:** Install the strike plate on the door frame, aligning it with the latch bolt. Secure with screws.
7. **Test Operation:** Close the door and test the locking and unlocking functions from both the interior and exterior using the key and turn button. Ensure the latch retracts smoothly and the knob turns freely.



Image of the Weiser Yukon Entry Knob, showcasing its satin nickel finish and the keyhole for external access.

Operating Instructions

The Weiser Yukon Entry Knob provides secure access and privacy:

- **Locking from Exterior:** Insert the key into the keyway and turn to the locked position. Remove the key.
- **Unlocking from Exterior:** Insert the key into the keyway and turn to the unlocked position.
- **Locking from Interior:** Rotate the turn button on the interior knob to the locked position.
- **Unlocking from Interior:** Rotate the turn button on the interior knob to the unlocked position.

Maintenance

Proper care will ensure the longevity and performance of your door knob:

- **Cleaning:** Clean the knob with a soft, damp cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Lubrication:** Periodically (e.g., once a year), apply a small amount of graphite-based lubricant to the key cylinder and the latch mechanism to ensure smooth operation. Do not use oil-based lubricants.
- **Tightening:** If the knob feels loose, gently tighten the mounting screws located on the interior side of the door. Do not overtighten.

Troubleshooting

Problem	Possible Cause	Solution
Knob is loose	Mounting screws are loose.	Tighten the mounting screws on the interior knob assembly.
Key does not turn or is difficult to insert	Incorrect key, debris in keyway, or lack of lubrication.	Ensure you are using the correct key. Check for and remove any debris. Apply graphite lubricant to the keyway. Note: Older Weiser keys may not be compatible with newer SmartKey cylinders.
Latch bolt does not retract or extend smoothly	Latch is misaligned or requires lubrication.	Check the alignment of the latch with the strike plate. Lubricate the latch mechanism with graphite.
Door does not latch properly	Strike plate is misaligned or latch bolt is not fully extending.	Adjust the strike plate position on the door frame. Ensure the latch bolt extends fully when the door is open.

Specifications

- **Model Number:** GAC531 Y15 SMT MS 6LR1
- **Brand:** Weiser
- **Material:** Zinc
- **Finish:** Satin Nickel
- **Lock Type:** Key Lock
- **Adjustable Latch:** 2-3/8" and 2-3/4" backset
- **Door Thickness:** Standard

- **Item Weight:** Approximately 1.3 pounds
- **Product Dimensions:** 2.5 x 4.5 x 8.7 inches
- **UPC:** 059184280531

Warranty and Support

For warranty information or technical support, please refer to the official Weiser website or contact Weiser customer service directly. Keep your proof of purchase for warranty claims.

© 2023 Weiser. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00GRSVZ6C

More documents and user manuals: **https://manuals.plus/**