Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Giochi Preziosi NCR02245

VIOLETTA LUCCHETTO Instruction Manual

Model: NCR02245

Introduction

Welcome to the instruction manual for your new Giochi Preziosi VIOLETTA LUCCHETTO. This collectible padlock is designed for decorative purposes and light security for small personal items. Please read this manual carefully to understand the proper use and care of your V-Lock.



This image displays the retail packaging for the Disney Violetta V-Lock. The main box features a large image of Violetta and the 'V-Lock' branding. Inside the box, several individually packaged locks are visible. In the foreground, two open locks are shown: one purple with a character image and a key, and another light blue with a smiley face and a key. The packaging indicates '12 characters to collect'.

Setup

1. **Unboxing:** Carefully remove the VIOLETTA LUCCHETTO from its packaging. Ensure all components are present.
2. **Identify Components:** Each V-Lock package contains one padlock and one corresponding key. Verify that you have both items.
3. **Initial Inspection:** Before first use, inspect the lock and key for any visible damage or manufacturing defects.

Operating Instructions

1. **Opening the Lock:** Insert the key fully into the keyhole of the padlock. Turn the key clockwise until the shackle (the U-shaped part) springs open. Remove the key.
2. **Closing the Lock:** Align the shackle with the lock body. Press the shackle down firmly until you hear a click. The lock is now secured. You do not need the key to close the lock.
3. **Usage:** The VIOLETTA LUCCHETTO is ideal for securing small diaries, journals, decorative boxes, or as a collectible item. It is not intended for high-security applications.

Maintenance

- **Cleaning:** To clean your V-Lock, gently wipe it with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or internal mechanism.
- **Storage:** Store the padlock and its key in a dry place, away from direct sunlight and extreme temperatures. Keep the key separate from the lock to prevent accidental loss.
- **Avoid Force:** Do not force the key or shackle. If you encounter resistance, re-check alignment or ensure the correct key is being used.

Troubleshooting

- **Key Not Turning:**
  - Ensure the key is fully inserted into the keyhole.
  - Check for any debris or obstructions in the keyhole.
  - Verify that you are using the correct key for your specific V-Lock.
- **Lock Not Closing:**
  - Ensure the shackle is properly aligned with the opening in the lock body.
  - Press the shackle down firmly until it clicks into place.

Specifications

Attribute	Detail
Manufacturer	GIOCHI PREZIOSI
Model Number	NCR02245
Material	Metal
Color	Purple
Lock Type	Key Lock
Included Components	1 Padlock, 1 Key
Number of Pieces	1

Warranty and Support

Specific warranty information for the VIOLETTA LUCCHETTO is not provided in the product data. For any warranty claims, product support, or inquiries, please contact the manufacturer, Giochi Preziosi, directly through their official

customer service channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00I45L3UE

More documents and user manuals: **https://manuals.plus/**