Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXIBOOK K7000DP

LEXIBOOK Disney Princess K7000DP Portable CD Karaoke Player User Manual

Model: K7000DP

1. Introduction

The LEXIBOOK Disney Princess K7000DP is a portable CD player designed for karaoke entertainment. It features a top-loading CD compartment, a microphone for singing along, and various vocal effects. The unit also supports CD+G discs, allowing lyrics to be displayed on a connected television. An Aux-In port provides connectivity for external audio devices, expanding your music options.

This manual provides essential information for the safe and effective use of your karaoke player. Please read it thoroughly before operation and retain it for future reference.

2. Safety Information

WARNING: This product is not suitable for children under 3 years of age due to small parts that may present a choking hazard. Adult supervision is recommended during use.

- Do not expose the unit to rain or moisture.
- Do not block ventilation openings.
- Use only attachments/accessories specified by the manufacturer.
- Unplug the unit during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

3. Package Contents

Please check that all items are present and in good condition:

- 1 x LEXIBOOK Disney Princess K7000DP Karaoke Player Unit
- 1 x Microphone
- 1 x AC Power Adapter (may vary by region)

4. Setup

4.1 Power Connection

1. Ensure the unit is switched off.
2. Connect the AC power adapter to the DC IN jack on the back of the karaoke player.
3. Plug the other end of the adapter into a standard wall outlet.

4.2 Microphone Connection

1. Locate the microphone input jack(s) on the front of the unit.
2. Insert the microphone cable plug firmly into the microphone jack.

4.3 Connecting to a Television (for CD+G)

To display song lyrics from CD+G discs on your television, you will need an appropriate audio/video cable (not included) to connect the karaoke player to your TV.

1. Locate the Audio/Video output jacks on the back of the karaoke player.
2. Connect the corresponding cables (e.g., RCA yellow for video, red/white for audio) from the karaoke player to the input jacks on your television.
3. Select the correct input source on your television (e.g., AV1, Video 1) to view the lyrics.



Figure 1: Front view of the LEXIBOOK Disney Princess K7000DP Karaoke Player, showing the main unit and connected microphone. This image illustrates the overall design and primary components.

5. Operating Instructions

5.1 Power On/Off

Press the **POWER** button (usually located on the front or top panel) to turn the unit on or off.

5.2 CD Playback

1. Gently open the CD compartment lid located on the top of the unit.
2. Place a CD (audio CD or CD+G) onto the spindle with the label side facing up.
3. Close the CD compartment lid firmly.
4. Press the **PLAY/PAUSE** button to start playback.
5. Use the **STOP** button to halt playback.
6. Use the **SKIP FORWARD** (▶▶|) and **SKIP BACKWARD** (|◀◀) buttons to navigate between tracks.
7. Adjust the **MASTER VOLUME** knob to control the overall sound level.

5.3 Karaoke Features

Once a microphone is connected and a CD is playing, you can utilize the karaoke functions:

- **Microphone Volume:** Use the **MIC VOLUME** knob to adjust the loudness of your voice through the microphone.
- **Vocal Effects (Echo/Balance):** The unit features controls for vocal effects. Adjust the **ECHO** knob to add an echo effect to your voice. The **BALANCE** control allows you to mix the microphone sound with the music.
- **Automatic Voice Control (AVC):** This feature automatically reduces the main vocal track on a CD when you sing into the microphone, allowing your voice to be more prominent.
- **CD+G Lyrics:** If you are playing a CD+G disc and the unit is connected to a television (as described in Section 4.3), the lyrics will appear on your TV screen, guiding your performance.



Figure 2: Top view of the karaoke player, highlighting the CD compartment, display, and various control knobs for volume, microphone, and vocal effects.

5.4 Aux-In Connection

You can connect an external audio device (e.g., smartphone, MP3 player) to play music through the karaoke player's speakers.

1. Connect one end of a 3.5mm audio cable (not included) to the **AUX-IN** jack on the front of the karaoke player.
2. Connect the other end of the audio cable to the headphone jack or audio output of your external device.
3. Select the AUX-IN mode on the karaoke player (if applicable, refer to unit controls).
4. Start playback on your external device.
5. Adjust the volume on both your external device and the karaoke player for optimal sound.



Figure 3: The karaoke player demonstrating an Aux-In connection with a tablet, illustrating how external devices can be integrated for music playback.

6. Maintenance

- **Cleaning:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.

- **CD Care:** Handle CDs by their edges. Keep them clean and free of scratches. Store them in their cases when not in use.
- **Microphone Care:** Avoid dropping the microphone. Store it properly to prevent cable damage.
- **Storage:** When not in use for extended periods, unplug the unit and store it in a cool, dry place away from direct sunlight.

7. Troubleshooting

Problem	Possible Cause	Solution
Unit does not power on.	Power adapter not connected or faulty.	Ensure the power adapter is securely connected to the unit and a working wall outlet. Test the outlet with another device.
No sound from speakers.	Volume too low; incorrect mode selected; faulty CD/Aux-In connection.	Increase MASTER VOLUME. Ensure correct mode (CD/Aux-In) is selected. Check CD for damage or ensure Aux-In cable is fully inserted.
Microphone not working.	Microphone not connected; MIC VOLUME too low; microphone faulty.	Ensure microphone is fully plugged into the jack. Increase MIC VOLUME. Test with another microphone if available.
CD skips or does not play.	CD is dirty, scratched, or inserted incorrectly.	Clean the CD with a soft, lint-free cloth. Check for deep scratches. Ensure the CD is placed correctly in the compartment.
Lyrics not appearing on TV (CD+G).	Unit not connected to TV; incorrect TV input selected; not a CD+G disc.	Verify the audio/video cables are correctly connected between the unit and TV. Select the correct AV input on your TV. Ensure you are using a CD+G compatible disc.

8. Specifications

Feature	Detail
Model Number	K7000DP
Brand	LEXIBOOK
Dimensions (L x W x H)	22.4 x 23.7 x 17.1 cm
Weight	2.12 kg
Media Type	CD, CD+G
Connectivity	Aux-In, Microphone Input, Audio/Video Output (for TV)
Vocal Effects	Echo, Balance, Automatic Voice Control (AVC)
Components Included	1 speaker unit, 1 microphone
UPC	791743304233

9. Warranty and Support

This product is covered by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact the retailer. For technical support or service inquiries, please contact

LEXIBOOK customer service or your authorized dealer.
You can find more information and contact details on the official LEXIBOOK website: www.lexibook.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00IQ32DX0

More documents and user manuals: **https://manuals.plus/**