Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun FP3010

Braun FP3010 TributeCollection Food Processor Instruction Manual

Model: FP3010 | Brand: Braun

Product Overview

The Braun FP3010 TributeCollection Food Processor is a versatile kitchen appliance designed for various food preparation tasks. It features a powerful 600W motor and comes with multiple accessories for blending, slicing, grating, shredding, kneading, and beating. This model operates on 220/240 volts and is intended for use in countries with corresponding electrical standards.



Figure 1: Front view of the Braun FP3010 Food Processor with its main bowl and lid assembled.

Important Safety Information

- **Voltage Compatibility:** This appliance is designed for 220/240 volts and is for use overseas in Africa, Asia, Europe, Middle East, and other 220/240 volt countries. **It will NOT work in North America, USA, or Canada.**
- **Power Cord:** Ensure the power cord is not damaged. Do not operate the appliance if the cord is compromised.
- **Blade Safety:** Blades are sharp. Handle with extreme care. Always ensure the appliance is unplugged before assembling, disassembling, or cleaning.
- **Lid and Base Lock:** The appliance features security interlocks. The lid and base must be correctly locked into place before the food processor can be turned on. Do not attempt to bypass these safety features.
- **Cleaning:** Refer to the "Maintenance & Cleaning" section for proper cleaning instructions.
- **Children:** Keep the appliance out of reach of children.

Setup and Assembly

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Base Placement:** Place the motor base on a stable, flat, and dry surface.
3. **Bowl Attachment:** Place the 2-liter universal bowl onto the motor base. Rotate it clockwise until it locks securely into place.
4. **Blade/Accessory Insertion:** Select the desired blade or accessory (e.g., chopping blade, kneading tool, slicing disc) and carefully place it onto the central spindle inside the bowl.
5. **Lid Attachment:** Place the lid onto the bowl, aligning the tab on the lid with the slot on the bowl handle. Rotate the lid clockwise until it clicks securely into the locked position. The appliance will not operate if the lid is not properly secured.
6. **Power Connection:** Plug the power cord into a compatible 220/240 volt electrical outlet.



Figure 2: The food processor with its main components assembled, ready for use.

Operating Instructions

The Braun FP3010 features a simple control dial for power and speed selection. The appliance offers variable speed settings and a pulse function for precise control.



Figure 3: Side view highlighting the control dial and speed settings.

Control Panel Overview:

- **Off/On Dial:** The main dial controls the power. Turn it to 'P' for short bursts of power. This is ideal for chopping ingredients coarsely or for quick mixing.
- **Speed Settings (1-15):** Rotate the green dial to select a continuous speed from 1 (slowest) to 15 (fastest). The recommended speed for various tasks is indicated by icons below the main dial.

Using Accessories:

The FP3010 comes with 7 accessories, including 4 stainless steel disc inserts, a dough tool, a shredding/slicing tool, and a whipping/blending tool. The base of the unit provides visual guides for which attachment to use with which speed setting.

- **Chopping/Blending:** Use the main chopping blade for ingredients like eggs, cheese, or cream. For optimal results, use the pulse function or lower speeds for delicate mixtures.
- **Kneading:** Attach the dough tool for kneading dough. Refer to the speed guide on the appliance base for recommended settings.
- **Slicing/Shredding/Grating:** Use the appropriate stainless steel disc inserts for slicing, shredding, or grating vegetables. Ensure the food pusher is used to guide ingredients safely through the feed tube.
- **Whipping:** Utilize the whipping/blending tool for whipping cream or egg whites.

Maintenance & Cleaning

Proper cleaning ensures the longevity and hygiene of your Braun FP3010 Food Processor.

- **Before Cleaning:** Always unplug the appliance from the power outlet before cleaning.
- **Dishwasher Safe Parts:** The bowl, lid, and all accessories are dishwasher safe. Place them on the top rack of your dishwasher.
- **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
- **Blades:** Handle blades with extreme caution. Clean them immediately after use to prevent food from drying on them.
- **Storage:** Store all attachments and the main unit in a clean, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Lid or bowl not properly locked; power cord not plugged in; no power from outlet.	Ensure bowl and lid are securely locked. Check power cord connection and wall outlet.
Appliance "moves" or "walks" during operation, especially when grating.	Unstable surface; excessive load; incorrect speed setting for task.	Ensure the food processor is on a stable, non-slip surface. Reduce the amount of food being processed at once. Adjust speed according to the recommended settings for the specific task.
Ingredients are not uniformly processed.	Too much or too little food; incorrect blade/accessory; insufficient processing time.	Adjust ingredient quantity. Ensure the correct blade or disc is used for the desired consistency. Process for longer or use the pulse function for better control.

Specifications

Brand: Braun

Model Name: FP3010

Power: 600 watts

Voltage: 220 / 240 volts (Not for use in USA/Canada)

Bowl Capacity: 2 liters (1.5kg dough)

Color: White/Green

Product Dimensions: 13.39 x 9.45 x 12.59 inches

Item Weight: 8.14 pounds

Product Care: Dishwasher Safe parts

Special Features: Cord Storage, Electronic Overload Protection, Pre-Set Speed Function

Included Components: Chopping Blade, Container, Lid, 4 Stainless Steel Disc Inserts, Dough Tool, Shredding/Slicing Tool, Whipping/Blending Tool.

Warranty & Support

For warranty information and customer support, please refer to the documentation included with your product or visit the official Braun website. Ensure you retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00IYL2KYQ

More documents and user manuals: **https://manuals.plus/**