Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Flexson FLXS1CM1011

Flexson Ceiling Mount for Sonos One, One SL and Play:1

OFFICIAL USER MANUAL

Introduction

Thank you for choosing the Flexson Ceiling Mount. This mount is specifically designed to securely hold your Sonos One, Sonos One SL, or Sonos Play:1 speaker, allowing for optimal sound positioning and discreet cable management. Please read this manual carefully before installation and use to ensure proper setup and safe operation.



Image: The Flexson Ceiling Mount in white, designed to hold a Sonos speaker. The mount features a main vertical pole extending from the ceiling plate, with a speaker arm that can be adjusted.

What's in the Box

Please check the contents of your package:

- 1 x Flexson Ceiling Mount (Model: FLXS1CM1011)
- Installation Hardware (screws, wall anchors - specific types may vary by region)
- Instruction Leaflet (this manual)

If any components are missing or damaged, please contact Flexson customer support.

Setup and Installation

Important Safety Information: Installation should only be performed by a qualified individual. Ensure the mounting surface can safely support the weight of the mount and the speaker. Always use appropriate tools and safety equipment.

1. **Choose Location:** Select a suitable ceiling location that is structurally sound and allows for optimal speaker placement. Consider power access for your Sonos speaker.
2. **Mark Drilling Points:** Hold the ceiling plate of the mount against the ceiling at the desired location. Use a pencil to mark the drilling points for the mounting screws.
3. **Drill Pilot Holes:** Drill pilot holes at the marked points. The drill bit size will depend on the type of screws and wall anchors provided or required for your ceiling material.
4. **Secure Ceiling Plate:** Insert wall anchors (if necessary) into the pilot holes. Secure the ceiling plate of the mount to the ceiling using the provided screws. Ensure it is firmly attached and stable.
5. **Attach Speaker Arm:** Connect the main vertical pole to the ceiling plate assembly. Ensure all connections are tight and secure.
6. **Mount Sonos Speaker:** Carefully slide your Sonos One, One SL, or Play:1 speaker onto the speaker arm. The bespoke design ensures a secure fit. Ensure the speaker is fully seated and stable on the mount.
7. **Cable Management:** Route the speaker's power cable through the integrated cable management channels within the mount's pole. This helps to keep the installation tidy and discreet.



Image: The Flexson Ceiling Mount with a Sonos speaker securely attached, demonstrating the straight-down orientation.



Image: The Flexson Ceiling Mount with a Sonos speaker attached, angled to direct sound. This illustrates the adjustable nature of the mount.

Operating the Mount

The Flexson Ceiling Mount allows for flexible positioning of your Sonos speaker:

- **Speaker Angle Adjustment:** The speaker arm can be angled to direct sound precisely where desired. Gently adjust the angle of the speaker arm to achieve the optimal listening experience. Ensure the speaker remains securely seated after adjustment.

- **Cable Management:** The integrated cable management system ensures that the speaker's power cable is neatly hidden within the mount's structure, contributing to a clean aesthetic.

Maintenance

The Flexson Ceiling Mount requires minimal maintenance:

- **Cleaning:** To clean the mount, gently wipe it with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Periodic Checks:** Periodically check all screws and connections to ensure they remain tight and secure. Over time, vibrations or environmental factors may cause slight loosening.
- **Speaker Security:** Ensure the Sonos speaker remains securely seated on the mount. If you notice any looseness, re-seat the speaker.

Troubleshooting

Issue	Possible Cause	Solution
Mount feels loose or wobbly after installation.	Screws are not fully tightened, or mounting surface is not strong enough.	Ensure all mounting screws are fully tightened. Verify the structural integrity of the ceiling. If necessary, consult a professional for installation.
Speaker does not sit securely on the mount.	Speaker not correctly aligned or fully seated on the arm.	Remove the speaker and re-seat it carefully, ensuring it clicks into place or is firmly positioned on the bespoke base.
Cable management is not effective.	Cable not routed correctly through the internal channels.	Carefully re-route the speaker's power cable through the designated channels within the mount's pole.

If you encounter an issue not listed here, or if the suggested solutions do not resolve the problem, please contact Flexson customer support.

Specifications

Feature	Detail
Model Number	FLXS1CM1011
Compatible Devices	Sonos One, Sonos One SL, Sonos Play:1
Mounting Type	Ceiling Mount
Color	White
Product Dimensions	4.33 x 4.33 x 13.78 inches (11 x 11 x 35 cm)
Item Weight	2.77 pounds (1.26 kg)
Manufacturer	Flexson
Special Features	Adjustable speaker angle, integrated cable management, bespoke fit for Sonos speakers.

Warranty and Support

The Flexson Ceiling Mount is covered by a standard manufacturer's warranty. Please refer to the warranty information provided with your purchase or visit the official Flexson website for details regarding warranty terms and conditions.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Flexson customer service. You can find more information and contact details on the official Flexson store page:

Visit the Flexson Store

© 2024 Flexson. All rights reserved. Sonos is a trademark of Sonos, Inc.
This manual is for informational purposes only. Flexson is not responsible for any damage or injury caused by improper installation or use of this product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00JUQ65JA

More documents and user manuals: **https://manuals.plus/**