Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Philips Beauty HP6306/50

Philips SatinShave Essential Women’s Wet & Dry Electric Shaver

MODEL: HP6306/50

Introduction

The Philips SatinShave Essential electric shaver is designed for quick, easy, and safe hair removal on legs and body, suitable for sensitive skin. Its cordless, battery-powered design allows for convenient wet or dry shaving, providing a smooth finish without irritation.



Figure 1: Philips SatinShave Essential shaver and its packaging.

Important Safety Information

- Close supervision is necessary when this appliance is used by, on, or near children or invalids.
- Use this appliance for its intended household use as described in this manual. Do not use attachments not recommended by Philips Electronics North America Corporation.
- Never operate this appliance if it is not working properly, or if it has been dropped or damaged. For assistance call 1-800-243-7884.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Never put the appliance in direct sunlight or use, store at a temperature between 40 ℉ and 100 ℉.
- Always check shaving foil and trimmers before using. Do not use the appliance if the shaving foil or trimmers are damaged, as injury may occur.
- If appliance will not be used on a regular basis, remove the batteries to prevent possible damage due to chemical

leakage. If batteries do leak, remove carefully. Do not allow bare skin to touch leaking fluid.

Product Features

- Essential electric shaver for women and girls is designed for shaving sensitive skin on legs.
- Safe shaving system with hypoallergenic foil protects sensitive areas from nicks and cuts.
- Shave dry for convenience or wet with gel or foam for extra skin protection in the shower.
- Compact ergonomic design is perfect for travel.
- Cordless shaver for women includes 2 AA batteries, travel cap, and device cleaning brush.



Figure 2: The hypoallergenic foil ensures a smooth shave while protecting sensitive skin from irritation.



Figure 3: Ergonomic design with anti-slip grip for comfortable wet and dry use.





Figure 4: Cordless and battery-operated design allows for shaving anywhere, anytime.

Setup and First Use

Your Philips SatinShave Essential comes ready for use with included AA batteries.

1. **Battery Installation**: Locate the battery compartment at the bottom of the shaver. Twist or slide the cover to open. Insert two AA batteries, ensuring correct polarity (+/-). Close the cover securely.
2. **Initial Check**: Before first use, ensure the shaving foil and trimmers are free from damage.
3. **Protective Cap**: Remove the clear protective cap from the shaving head.

Operating Instructions

The Philips SatinShave Essential can be used for both wet and dry shaving.

1. **Power On**: Slide the power switch located on the front of the shaver upwards to turn it on.
2. **Dry Shaving**: For quick touch-ups, use the shaver on dry skin. Ensure skin is clean and free of oils or lotions.
3. **Wet Shaving**: For extra skin protection and a smoother glide, use the shaver with water, shaving gel, or foam in the shower or bath.
4. **Shaving Technique**: Gently glide the shaver over the skin against the direction of hair growth. The hypoallergenic foil system is designed to protect your skin from nicks and cuts.
5. **Target Areas**: Suitable for legs, underarms, and bikini line.
6. **Power Off**: Slide the power switch downwards to turn the shaver off after use.

Care and Maintenance

1. **Cleaning After Each Use**: After each use, especially for wet shaving, rinse the shaver head under running water.
2. **Deep Cleaning**: To remove accumulated hair, press the release buttons on the sides of the shaving head to detach it from the shaver body. Use the included cleaning brush to brush away any hair from the foil and the inner parts of the shaver.
3. **Drying**: Allow all parts to air dry completely before reassembling the shaver and storing it.
4. **Storage**: Store the shaver in a dry place, away from direct sunlight and extreme temperatures. Always replace the protective cap when not in use.
5. **Battery Replacement**: If the shaver's performance decreases, replace the two AA batteries. Remove old batteries carefully to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Shaver not turning on	Batteries are dead or incorrectly inserted.	Check battery polarity or replace with new AA batteries.
Shaver not cutting effectively	Shaving foil or trimmers are clogged with hair or damaged.	Clean the shaving head thoroughly. Inspect for damage and replace if necessary.
Skin irritation after shaving	Improper shaving technique or extremely sensitive skin.	Ensure gentle gliding motion. Try wet shaving with gel/foam. If irritation persists, consult a dermatologist.

For further assistance, please refer to the official user manual or contact Philips customer support.

Product Specifications

Feature	Detail
Brand	Philips Beauty

Feature	Detail
Model Name	HP6306/50
Power Source	Battery Powered
Batteries	2 AA batteries required (included)
Special Features	Dry Shave, Wet, Hypoallergenic, Cordless, Ergonomic Design
Recommended Uses	Arms, Armpit, Leg
Product Dimensions	5 x 7 x 6 inches; 7.7 ounces
Manufacturer	Norelco
UPC	075020040145
ASIN	B00K3FFIOA
Country of Origin	China

Warranty and Customer Support

For detailed warranty information, please refer to the documentation included with your product.

For additional support, frequently asked questions, or to download the full user manual, please visit the official Philips support website or contact their customer service at 1-800-243-7884.

You can also access the User Manual (PDF) directly:Philips SatinShave Essential User Manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00K3FFIOA

More documents and user manuals: **https://manuals.plus/**