Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SCHLAGE F51A ACC 622 BRK

SCHLAGE Accent Lever with Brookshire Trim Keyed Entry Lock

Model: F51A ACC 622 BRK
Brand: SCHLAGE

Product Overview

The SCHLAGE Accent Lever with Brookshire Trim Keyed Entry Lock in Matte Black is designed for exterior doors requiring keyed entry and security. This lock features an Accent lever, known for its wave-like design, paired with the Brookshire trim, which includes ornate details. The Matte Black finish provides a distinct aesthetic. This product is constructed from durable metal, offering strength and security, and is resistant to pick attacks. It is ANSI/BHMA Grade 2 Certified, indicating a good level of residential security.



Image: The SCHLAGE Accent Lever with Brookshire Trim Keyed Entry Lock in Matte Black, shown installed on a door.

1. Setup and Installation

Installation of the SCHLAGE Accent Lever with Brookshire Trim Keyed Entry Lock is designed to be straightforward. The lock features self-aligning screw holes to simplify the process.

Tools Required:

- Phillips screwdriver

Installation Steps:

1. Prepare the door: Ensure the door has standard bore holes for a cylindrical lockset.
2. Install the latch: Insert the latch into the door edge and secure it with screws.
3. Install the exterior lever assembly: Position the exterior lever and trim, ensuring the spindle aligns with the latch mechanism.
4. Install the interior lever assembly: Place the interior lever and trim, aligning the screw holes.

5. Secure the assemblies: Use a Phillips screwdriver to tighten the mounting screws, utilizing the self-aligning screw holes for ease.
6. Test operation: Verify that the lever operates smoothly and the lock engages correctly with the key and interior turn button.

The reversible lever design allows it to be used with both right and left swing doors, providing flexibility during installation.

2. Operating Instructions

Locking the Door:

- **From the exterior:** Insert the key into the cylinder and turn it to engage the lock. Remove the key.
- **From the interior:** Rotate the interior turn button to engage the lock.

Unlocking the Door:

- **From the exterior:** Insert the key into the cylinder and turn it to disengage the lock.
- **From the interior:** Rotate the interior turn button to disengage the lock.

A key feature of this keyed entry function is that the lock automatically unlocks when the door is opened from the inside. This allows for quick and convenient exit and easy re-entry without needing to re-lock from the inside.

3. Maintenance

To ensure the longevity and smooth operation of your SCHLAGE Accent Lever, regular maintenance is recommended.

- **Cleaning:** Wipe the lockset surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents, as these can damage the Matte Black finish.
- **Lubrication:** Periodically apply a small amount of graphite-based lubricant into the keyway to maintain smooth key insertion and turning. Do not use oil-based lubricants, which can attract dust and debris.
- **Fastener Check:** Occasionally check the mounting screws for tightness and re-tighten if necessary to prevent wobbling or misalignment.

4. Troubleshooting

If you encounter issues with your lock, consider the following common troubleshooting steps:

- **Stiff Key or Lever:** Ensure the keyway is clean and lubricated. Check for any obstructions around the latch or strike plate.
- **Lock Not Engaging:** Verify that the door is properly aligned with the door frame and that the strike plate is correctly positioned. Check if the latch bolt extends fully when the door is closed.
- **Loose Lever:** Re-tighten the mounting screws as described in the maintenance section.
- **Key Not Turning:** Ensure you are using the correct key. Check for debris in the keyway and lubricate if necessary.

For persistent issues, contact SCHLAGE customer support or a qualified locksmith.

5. Specifications

Feature	Detail
Model Number	F51A ACC 622 BRK

Brand	SCHLAGE
Material	Metal (Brass, Stainless Steel)
Color	Matte Black
Exterior Finish	Matte Black
Lock Type	Accent Lever, Keyed Entry
Hand Orientation	Universal (Reversible)
Item Weight	1.55 Pounds
Product Dimensions	2.72 x 5.16 x 2.75 inches
ANSI/BHMA Certification	Grade 2 Certified
Batteries Required	No
UPC	043156452033

6. Warranty and Support

SCHLAGE products are backed by the manufacturer's warranty. For specific warranty details, claims, or technical support, please refer to the official SCHLAGE website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Related Information

Video: Upgrade your home to Matte Black

Your browser does not support the video tag.

This video showcases various SCHLAGE products available in the Matte Black finish, including levers, knobs, and handlesets, demonstrating how to integrate this elegant finish into your home's entryways.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00K52R6GO

More documents and user manuals: **https://manuals.plus/**