**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**BRAUN MR430 CA**

# Braun Multi Quick Hand Blender 200W MR430CA

INSTRUCTION MANUAL

## Introduction

Thank you for choosing the Braun Multi Quick Hand Blender. This versatile appliance is designed to simplify your food preparation tasks, offering efficient blending, whisking, and chopping capabilities. Please read this instruction manual carefully before first use to ensure safe and optimal performance of your new appliance. Keep this manual for future reference.

## Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- To protect against risk of electrical shock, do not put the motor unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or electrical or mechanical adjustment.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter.
- Do not let cord contact hot surfaces, including the stove.
- Be careful when handling the sharp blades, emptying the bowl, and during cleaning.
- Always ensure the appliance is properly assembled before use.

## Package Contents

Your Braun Multi Quick Hand Blender package includes the following components:

- Hand Blender Motor Unit (200W)
- Detachable Blender Shaft
- Chopper Attachment
- Stainless Steel Whisk Attachment
- Beaker
- Two Lids




Image showing the Braun Multi Quick Hand Blender's soft touch grip, detachable blender shaft, dishwasher-safe parts, and included accessories like the chopper, stainless whisk, and beaker.

## Setup and Assembly

Before first use, wash all parts that will come into contact with food. Ensure the motor unit is unplugged from the power

outlet during assembly.

1. **Attaching the Blender Shaft:** Align the motor unit with the blender shaft and twist until it clicks securely into place. The shaft is detachable for easy cleaning and storage.
2. **Attaching the Whisk:** Insert the whisk into the whisk gear box, then attach the gear box to the motor unit by aligning and twisting until it clicks.
3. **Attaching the Chopper:** Place the chopper blade onto the center pin inside the chopper bowl. Add ingredients to the bowl. Place the chopper lid onto the bowl, then attach the motor unit to the chopper lid by aligning and twisting until it clicks.




Illustration showing the simple twist-and-lock mechanism for attaching the detachable blender shaft to the motor unit, ensuring secure assembly.

## Operating Instructions

Always ensure the appliance is correctly assembled and plugged into a suitable power outlet before operation.

## General Operation

- Plug the hand blender into a 120V AC power outlet.
- Press and hold the power button on the motor unit to activate the blender. Release the button to stop.
- For continuous operation, some models may have a lock button; refer to your specific model's features.

## Using the Blender Shaft

Ideal for blending soups, sauces, baby food, and smoothies directly in pots, bowls, or the included beaker.

- Immerse the blender shaft into the ingredients. Ensure the liquid level is below the maximum fill line of the beaker or container.
- Press the power button and move the blender up and down gently to ensure all ingredients are processed evenly.
- Do not operate the blender for more than 60 seconds continuously to prevent overheating.

## Using the Whisk Attachment

Perfect for whipping cream, beating egg whites, and mixing light batters.

- Attach the whisk to the motor unit as described in the Setup section.
- Place the whisk into the ingredients in a bowl.
- Press the power button and whisk until desired consistency is achieved.

## Using the Chopper Attachment

Use for chopping herbs, onions, carrots, nuts, and preparing breadcrumbs.

- Assemble the chopper as described in the Setup section.
- Add ingredients to the chopper bowl. Do not overfill.
- Place the motor unit onto the chopper lid. Press the power button in short pulses for coarse chopping, or continuously for finer results.




Various food preparation examples, including blending soups, making milkshakes, chopping herbs, and whisking cream, demonstrating the versatility of the Braun Multi Quick Hand Blender.

## Cleaning and Maintenance

Proper cleaning ensures the longevity and hygiene of your appliance.

- **Before Cleaning:** Always unplug the appliance from the power outlet before cleaning.
- **Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse it in water or any other liquid.
- **Blender Shaft, Whisk, Beaker, Chopper Bowl & Lids:** These parts are dishwasher safe. Alternatively, they can be washed by hand in warm soapy water. Rinse thoroughly and dry.
- **Chopper Blade:** Handle the chopper blade with extreme care as it is very sharp. Wash by hand with warm soapy water and rinse. Store safely.
- **Storage:** Store the appliance and its attachments in a dry place, away from direct sunlight and heat.




The image highlights that the blender shaft, chopper bowl, and beaker are dishwasher safe, simplifying the cleaning process after use.

## Troubleshooting

If you encounter any issues with your Braun Multi Quick Hand Blender, please refer to the following table for common problems and solutions.

| Problem | Possible Cause | Solution |
|---|---|---|
| Appliance does not turn on. | Not plugged in; power outlet not working; motor unit not properly attached to attachment. | Ensure the appliance is securely plugged into a working outlet. Check that the motor unit is correctly locked onto the desired attachment. |
| Poor blending/chopping results. | Too much food; ingredients too large; not enough liquid (for blending). | Reduce the quantity of ingredients. Cut larger ingredients into smaller pieces. Add more liquid when blending. |
| Motor stops during operation or overheats. | Overloaded; continuous operation for too long. | Unplug the appliance and let it cool down for at least 15-20 minutes. Reduce the load or processing time. Do not operate for more than 60 seconds continuously. |
| Loud noise or vibration. | Attachment not properly secured; foreign object in blade area. | Ensure all attachments are securely locked. Unplug and check for any obstructions around the blades. |

## Technical Specifications

- **Brand:** BRAUN
- **Model:** MR430 CA
- **Power:** 200W
- **Voltage:** 120 Volts
- **Blade Material:** Stainless Steel
- **Included Components:** Chopper, Stainless whisk, beaker, two lids
- **Item Weight:** 2.74 pounds
- **Package Dimensions:** 15.1 x 7.5 x 4.9 inches
- **UPC:** 069055821756

## Warranty and Customer Support

Braun products are manufactured to the highest standards of quality, reliability, and performance. For specific warranty information, please refer to the warranty card included with your purchase or visit the official Braun website. If you have any questions, require assistance, or need to order replacement parts, please contact Braun customer support.
You can often find contact information on the manufacturer's website or through the retailer where you purchased the product.

© 2023 Braun. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B00KL0B45E**

More documents and user manuals: **https://manuals.plus/**