Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Best Price Square EC-82504i

Best Price Square EC-82504i 4-in-1 Universal Remote Control User Manual

Introduction

Thank you for choosing the Best Price Square EC-82504i 4-in-1 Universal Remote Control. This remote is designed to simplify your home entertainment experience by consolidating up to four different device controls into one convenient unit. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance.



Image: The Best Price Square EC-82504i 4-in-1 Universal Remote Control, showcasing its compact design and button layout.

Setup Guide

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or outwards to open it.
3. Insert the required batteries (typically 2x AAA, not included) according to the polarity indicators (+ and -) inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.

Initial Programming

The EC-82504i remote uses infrared technology to communicate with your devices. Programming typically involves

entering a specific code for each device (TV, DVD, VCR, SAT/CBL) you wish to control. Refer to the code list provided with your remote (if applicable) or use the auto-search function.

1. Turn on the device you wish to program (e.g., your TV).
2. Press and hold the 'SET' button (or equivalent) on the remote until the indicator light illuminates.
3. Press the device button you want to program (e.g., 'TV'). The indicator light may flash.
4. Enter the 3 or 4-digit code for your device's brand from the provided code list. If the code is correct, the indicator light should turn off.
5. Test the remote by pressing the 'POWER' button. If the device turns off, the programming was successful. If not, repeat the process with the next code for your brand or use the auto-search method.
6. For auto-search: After step 3, repeatedly press the 'POWER' button until your device turns off. Then press 'SET' to save the code.

Operating Your Remote

Once programmed, your EC-82504i remote functions like your original device remotes. Select the desired device mode (TV, DVD, VCR, SAT/CBL) by pressing the corresponding button before issuing commands.

- **POWER:** Turns the selected device on or off.
- **VOL +/-:** Adjusts the volume of the selected audio device (usually TV).
- **CH +/-:** Changes channels on the selected TV or cable/satellite box.
- **MUTE:** Mutes the audio.
- **INPUT/SOURCE:** Changes the input source on your TV.
- **Number Buttons (0-9):** For direct channel entry or menu navigation.
- **Playback Controls (PLAY, PAUSE, STOP, FF, REW):** Controls playback for DVD/VCR devices.

Maintenance

Cleaning

To maintain the remote's appearance and functionality, clean it regularly. Use a soft, dry cloth to wipe the surface. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote.

Battery Replacement

Replace batteries when the remote's performance degrades or the indicator light fails to illuminate. Always replace all batteries at the same time with new ones of the same type. Do not mix old and new batteries, or different types of batteries, as this can cause leakage or damage.

Troubleshooting

If you encounter issues with your universal remote, refer to the following common problems and solutions:

Problem	Solution

Problem	Solution
Remote not working at all.	Check battery installation and ensure batteries are fresh. Make sure there are no obstructions between the remote and the device.
Device not responding to commands.	Ensure the remote is in the correct device mode (e.g., 'TV' button pressed for TV). Reprogram the remote with a different code for your device brand.
Only some functions work.	The current code may only partially match your device. Try programming with another code from the list for your device brand.
Indicator light does not illuminate during programming.	Ensure you are pressing and holding the 'SET' button correctly. Check batteries.

Product Specifications

- **Model:** EC-82504i
- **Brand:** Best Price Square
- **Manufacturer:** Advanced GBS ELETTRONICA
- **Connectivity Technology:** Infrared
- **Special Feature:** Universal (4-in-1)
- **Weight:** Approximately 0.2 units (unit not specified)
- **UPC:** 616268573684

Warranty and Support

Specific warranty details and direct support contact information are not provided within the product's available specifications. For warranty claims, technical assistance, or further support, please refer to the retailer where the product was purchased or contact the manufacturer, Advanced GBS ELETTRONICA, directly if their contact information is available through other channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00LRT5VI4

More documents and user manuals: **https://manuals.plus/**