Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Artago 582/B

Artago 582/B Car Steering Wheel Seat Anti-Theft Device

Model: 582/B

Introduction

The Artago 582/B is a flexible anti-theft device designed to secure your vehicle by locking the steering wheel to the car seat. Manufactured in Europe, this device prioritizes reliability, durability, and quality. It incorporates a high-security lock with an anti-drilling ball mechanism. Its unique design allows for integrated and secure transport, offering both flexibility and strength. The device features a universal size, making it suitable for a wide range of vehicles.

Product Features

- **High Quality:** This reinforced car anti-theft device anchors to the seat and locks onto the steering wheel. It is an ideal option if your vehicle has a bar under the seat for attachment. Designed and manufactured in Europe, it offers superior reliability, durability, and quality compared to other devices.
- **Practical Design:** The device is quick and simple to use for both locking and transporting. It can be conveniently placed next to the seat without occupying extra space or causing obstruction within the car.
- **Flexible and Resistant:** It features an internal armored steel cable, protected by articulated steel sleeves and balls. This construction ensures the ARTAGO 582 is both robust and flexible. Additionally, it includes a security lock with an anti-drilling ball for enhanced protection.
- **Universal Compatibility:** The device is suitable for height-adjustable steering wheels. Ensure the distance between the steering wheel and the seat attachment point is a maximum of 77 cm for proper fit.
- **European Manufacturing:** ARTAGO SECURE is a leading specialist in high-end anti-theft devices. Its advanced manufacturing facility in Valencia, Spain, ensures professional support and reliable, quality products.



Image: The Artago 582/B anti-theft device in use, securing the steering wheel to the car seat.



Image: The universal design of the Artago 582/B, suitable for vehicles with adjustable steering wheels.



Image: A detailed view of the flexible armored steel cable and the robust anchor point designed to secure the device to the car seat.



Image: A detailed view of the high-security lock, featuring an anti-drilling ball for enhanced protection against tampering.

Setup and Installation

1. **Identify Anchor Point:** Locate a suitable, sturdy bar or structure under your car seat to serve as the primary anchor point for the device.
2. **Attach to Seat:** Securely attach the seat anchor end of the Artago 582/B to the identified bar under the seat. Ensure it is firmly in place and cannot be easily dislodged.
3. **Position Steering Wheel:** Adjust your steering wheel to a suitable height. The device is designed for height-adjustable steering wheels.
4. **Measure Distance:** Verify that the distance between the steering wheel and the seat attachment point does not exceed 77 cm (approximately 30.3 inches). This ensures proper fit and tension.
5. **Engage Steering Wheel Lock:** Extend the flexible cable and loop the locking mechanism around a spoke of your steering wheel. Ensure the steering wheel is turned to an angle that prevents it from being fully rotated.
6. **Lock the Device:** Insert the key into the lock cylinder and turn it to secure the device. Remove the key.



Image: The flexible armored steel cable and the robust anchor point designed to secure the device to the car seat.

Operating Instructions

1. **Locking the Device:**
   - Ensure the device is properly anchored to the seat.
   - Position the steering wheel to an angle that restricts movement.
   - Wrap the flexible cable around a sturdy part of the steering wheel.
   - Insert the key into the lock and turn it to engage the locking mechanism.
   - Remove the key and store it in a safe place.
2. **Unlocking the Device:**
   - Insert the key into the lock cylinder.
   - Turn the key to disengage the lock.
   - Remove the device from the steering wheel and the seat anchor.

3. **Transport and Storage:**
    - When not in use, the Artago 582/B can be conveniently stored next to the car seat. Its flexible design allows it to be placed without taking up excessive space or causing inconvenience.



Image: The Artago 582/B stored beside the car seat when not in use, emphasizing its practical transport design.

Maintenance

To ensure the longevity and optimal performance of your Artago 582/B anti-theft device, follow these maintenance guidelines:

- **Lock Mechanism:** Periodically apply a small amount of graphite lubricant or a specialized lock lubricant to the keyhole and internal mechanism. This helps prevent stiffness and ensures smooth operation. Avoid using oil-based lubricants as they can attract dirt.
- **Cable and Connections:** Regularly inspect the armored steel cable and all connection points for any signs of wear, fraying, cuts, or damage. If significant damage is observed, discontinue use and contact customer support.

- **Cleaning:** Wipe the device with a damp cloth to remove dirt and grime. Avoid using harsh chemicals or abrasive cleaners that could damage the finish or materials.
- **Storage:** Store the device in a dry place when not in use to prevent rust or corrosion, especially if exposed to moisture.

Troubleshooting

If you encounter issues with your Artago 582/B, refer to the following troubleshooting tips:

- **Lock is Stiff or Difficult to Turn:**
  - Apply graphite lubricant or a specialized lock lubricant into the keyhole.
  - Ensure the key is fully inserted and oriented correctly.
  - Check for any debris in the keyhole and gently try to remove it.
- **Device Does Not Lock Securely:**
  - Verify that the seat anchor is correctly and firmly attached to a stable point under the seat.
  - Ensure the flexible cable is properly wrapped around a steering wheel spoke and the locking mechanism is fully engaged.
  - Check that the distance between the steering wheel and the seat anchor does not exceed 77 cm.
- **Key is Stuck or Broken:**
  - Do not force the key. Apply a small amount of lubricant to the keyhole.
  - If the key breaks inside the lock, contact a professional locksmith or Artago customer support.

Specifications

Feature	Detail
Model Number	582/B
Product Dimensions (L x W x H)	42.5 x 26.2 x 4 cm (16.7 x 10.3 x 1.6 inches)
Item Weight	1 Kilogram (2.2 lbs)
Manufacturer	Artago Secure
Country of Origin	Spain
Brand	Artago
Special Feature	Key unlocking
Lock Type	Key lock
Material	Alloy Steel
Recommended Uses	Car
Style	Steering Wheel-Seat
Color	Blue and Black
Number of Pieces	1
Finish Type	Painted

Included Components	Anti-theft device and keys
International Article Code	08423885005823
Product Type Name	Car Steering Wheel Seat Articulated Armored Universal Anti-Theft Bar

Warranty and Support

For information regarding warranty coverage, terms, and conditions, please refer to the documentation provided with your purchase or visit the official Artago website. If you require technical assistance, have questions about installation, or need to report a defect, please contact Artago customer support directly. Contact details can typically be found on the product packaging or the manufacturer's website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00M08VZ90

More documents and user manuals: **https://manuals.plus/**