Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire 137143800

Frigidaire 137143800 Dispenser Drawer Washing Machine Instruction Manual

Brand: Frigidaire | Model: 137143800

Introduction

This manual provides comprehensive instructions for the proper installation, operation, and maintenance of your Frigidaire 137143800 Dispenser Drawer. Please read this manual thoroughly before installing or using the product to ensure safe and efficient operation and to prolong the life of your appliance part.

Product Overview

The Frigidaire 137143800 Dispenser Drawer is a genuine replacement part designed for Frigidaire washing machines. Its primary function is to hold and accurately dispense liquid laundry detergent into the washing machine during the wash cycle, ensuring optimal cleaning performance.



Image: The Frigidaire 137143800 Dispenser Drawer, showing its main wash compartment and fill level indicators.

Key Features

- Genuine Replacement Part: Ensures compatibility and performance with Frigidaire washing machines.
- Manufacturer Model 137143800: Specific part number for accurate identification.
- Frigidaire Item: Designed and manufactured to Frigidaire's quality standards.

Setup and Installation

This dispenser drawer is a direct replacement part. Follow these steps for proper installation:

1. **Safety First:** Before beginning any installation, ensure the washing machine is completely unplugged from the electrical outlet to prevent electric shock.
2. **Remove Old Drawer:** Carefully locate and remove the existing dispenser drawer from your washing machine. This typically involves pressing a release tab or pulling the drawer firmly until it detaches.
3. **Inspect Housing:** Briefly inspect the dispenser housing inside the washing machine for any debris or residue that might hinder the new drawer's insertion. Clean if necessary.
4. **Insert New Drawer:** Align the new Frigidaire 137143800 Dispenser Drawer with the opening in the washing machine. Gently push the drawer into place until it is securely seated and slides smoothly. Ensure it clicks into position if applicable.
5. **Test Fit:** Pull the drawer out and push it back in a few times to confirm it moves freely and is properly installed.
6. **Restore Power:** Once the drawer is securely installed, plug the washing machine back into the power source.

Operating Instructions

Using the dispenser drawer is straightforward:

1. **Open Drawer:** Gently pull the dispenser drawer completely open.
2. **Add Detergent:** Pour the recommended amount of liquid laundry detergent into the compartment labeled 'Main Wash liquid only'. Ensure the detergent level does not exceed the 'MAX' fill line indicated on the drawer.
3. **Close Drawer:** Push the dispenser drawer firmly back into the washing machine until it is fully closed.
4. **Start Cycle:** Select your desired wash cycle and start the washing machine. The machine will automatically dispense the detergent from the drawer at the appropriate time during the wash cycle.

Maintenance

Regular cleaning of the dispenser drawer is essential to prevent detergent buildup and ensure proper dispensing. It is recommended to clean the drawer monthly or as needed.

1. **Remove Drawer:** Pull the dispenser drawer out of the washing machine.
2. **Rinse:** Rinse the drawer thoroughly under warm running water to remove any detergent residue.
3. **Clean Stubborn Buildup:** For dried or stubborn detergent buildup, use a soft brush (like an old toothbrush) or a cloth with a mild soap solution. Pay attention to all compartments, corners, and the small holes where water enters and detergent exits.
4. **Dry:** Ensure the drawer is completely dry before reinserting it into the washing machine.
5. **Clean Housing:** Periodically wipe down the inside of the dispenser housing in the washing machine to remove any residue that may have accumulated.

Troubleshooting

If you encounter issues with your dispenser drawer, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Water or detergent residue is always stuck in the chamber.	Clogged dispenser nozzles or drain holes; improper installation; insufficient water pressure.	Thoroughly clean the dispenser drawer and its housing as described in the Maintenance section, paying close attention to all small openings. Ensure the dispenser drawer is fully and correctly inserted into its slot. Verify that the water supply to your washing machine has adequate pressure.
Detergent is not dispensing.	Drawer not fully closed; clogged dispenser; incorrect detergent type.	Ensure the dispenser drawer is pushed in completely before starting the wash cycle. Clean the dispenser drawer and housing to remove any blockages. Confirm you are using liquid laundry detergent suitable for your washing machine.

Specifications

Attribute	Detail
Brand Name	Frigidaire

Attribute	Detail
Model Info / Item Model Number / Part Number	137143800
Item Weight	2.4 ounces
Product Dimensions	1 x 8 x 9 inches
Batteries Required?	No
Date First Available	July 22, 2014

Warranty and Support

This Frigidaire genuine replacement part is covered by the manufacturer's standard warranty. For specific warranty details, claims, or technical support, please refer to the documentation provided with your original washing machine or contact Frigidaire customer service directly through their official website or support channels.
Always use genuine Frigidaire replacement parts to ensure compatibility and maintain the validity of your appliance's warranty.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question