Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun JB3060

Braun JB3060 Tribute Collection Blender User Manual

Model: JB3060

1. Introduction

Thank you for choosing the Braun JB3060 Tribute Collection Blender. This powerful 800W kitchen appliance is designed for efficient blending, crushing, mashing, and pureeing. Featuring a unique triangular thermo-resist glass jug and multiple speed settings, it offers versatility for various culinary tasks. Please read this manual carefully before first use to ensure safe and optimal operation.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions thoroughly before use.
- Do not immerse the motor unit in water or other liquids.
- Unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts during operation.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer service for repair.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use the appliance outdoors.
- Do not let the power cord hang over the edge of a table or counter, or touch hot surfaces.
- Keep hands and utensils out of the container while blending to prevent the possibility of severe injury or damage to the blender. A scraper may be used, but only when the blender is not running.
- The blades are extremely sharp. Handle the blade assembly with extreme care during cleaning and assembly.
- Always operate the blender with the lid securely in place.
- Do not blend boiling hot liquids. Allow hot liquids to cool slightly before blending.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning

use of the appliance by a person responsible for their safety.

- Children should be supervised to ensure that they do not play with the appliance.

3. Product Components

Familiarize yourself with the parts of your Braun JB3060 Blender:

- **Motor Unit:** The base containing the 800W motor and control panel.
- **Glass Jug (1.75 Liters):** Thermo-resist glass jug with measurement markings and a handle.
- **Lid:** Seals the jug during operation, often with a removable measuring cup insert.
- **Blade Assembly:** Integrated into the base of the jug for efficient blending.
- **Control Dial:** For selecting speed settings (1-5) and the pulse function.
- **Start Button:** Initiates and stops blending at the selected speed.



Image: The Braun JB3060 blender showing the black motor unit, clear glass jug with lid, and the silver control panel with speed dial and start button.

4. Setup and Assembly

Follow these steps to set up your blender for first use:

1. **Unpack:** Carefully remove all parts from the packaging and dispose of packaging materials responsibly.
2. **Clean:** Before first use, wash the glass jug, lid, and blade assembly in warm soapy water. Rinse thoroughly and dry completely. The motor unit should only be wiped with a damp cloth. Never immerse the motor unit in water.
3. **Assemble Jug:** Ensure the blade assembly is securely attached to the bottom of the glass jug. Twist it firmly until it clicks into place.
4. **Place Jug on Motor Unit:** Position the assembled glass jug onto the motor unit. Ensure it is seated correctly and

locked into place. Some models may require a slight twist to engage the safety interlock.

5. **Secure Lid:** Place the lid firmly on the glass jug. Ensure it is properly sealed to prevent splashes during operation.
6. **Connect Power:** Plug the power cord into a suitable electrical outlet (230V).



Image: The Braun JB3060 blender assembled on a kitchen counter, ready for use, with fresh fruits nearby.

5. Operating Instructions

5.1. Basic Blending

1. **Prepare Ingredients:** Cut ingredients into small, manageable pieces (approximately 2-3 cm) before placing them into the glass jug. Do not overfill the jug beyond the maximum fill line (1.75 Liters).
2. **Add Liquid:** Always add some liquid when blending solid ingredients to ensure smooth operation and prevent motor strain.
3. **Secure Lid:** Ensure the lid is securely placed on the jug before starting the blender.
4. **Select Speed:** Turn the control dial to your desired speed setting (1-5). Start with a lower speed for initial processing and gradually increase if needed for finer results.
5. **Start Blending:** Press the 'Start' button to begin blending.
6. **Stop Blending:** Press the 'Start' button again or turn the dial to '0' to stop the blender.

5.2. Speed Settings and Pulse Function

The Braun JB3060 offers up to 5 speed settings and a pulse function for precise control over your blending tasks:

- **Speeds 1-5:** Use lower speeds for lighter ingredients, gentle mixing, or coarse chopping. Use higher speeds for tougher ingredients, finer purees, or faster blending.
- **Pulse Function:** For short bursts of maximum power, ideal for chopping, crushing ice, or achieving desired consistency. To use, turn the dial to the 'Pulse' setting and hold it. Release the dial to stop the pulse action.

5.3. Specific Applications

- **Smoothies:** Combine fruits, vegetables, and liquid. Start at a low speed and gradually increase to a higher speed until a smooth consistency is achieved.
- **Ice Crushing:** Place ice cubes (ensure they are not frozen together) into the jug. Use the pulse function in short, controlled bursts until the desired crushed ice consistency is reached. Do not overload the jug with ice.
- **Soups and Purees:** The thermo-resist glass jug allows for blending of warm ingredients. Ensure ingredients are not boiling hot to prevent pressure buildup and potential injury.

6. Cleaning and Maintenance

Regular cleaning ensures the longevity, hygiene, and optimal performance of your blender.

1. **Unplug:** Always unplug the blender from the power outlet before cleaning.
2. **Disassemble:** Carefully remove the glass jug from the motor unit. Detach the lid and the blade assembly from the jug.
3. **Wash Jug and Lid:** The glass jug and lid are dishwasher-safe. Alternatively, wash them in warm soapy water, rinse thoroughly, and dry.
4. **Clean Blade Assembly:** Exercise extreme caution when cleaning the blade assembly as the blades are very sharp. Wash under running water with a brush or place in the dishwasher.
5. **Clean Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse the motor unit in water or any other liquid.
6. **Storage:** Store the disassembled or assembled blender in a clean, dry place, away from direct sunlight and heat.

7. Troubleshooting

If you encounter issues with your Braun JB3060 Blender, refer to the following table for possible solutions:

Problem	Possible Cause	Solution
Blender does not start.	Not plugged in; Jug not correctly assembled or seated; Power outage.	Ensure power cord is securely plugged in; Check if jug is properly locked onto the motor unit; Check household fuse/circuit breaker.
Motor stops during operation.	Overloaded; Overheating protection activated.	Unplug the blender, remove some ingredients, and let it cool down for 15-20 minutes before restarting. Reduce load for future use.
Ingredients are not blending smoothly.	Insufficient liquid; Ingredients too large; Speed setting too low.	Add more liquid; Cut ingredients into smaller pieces; Increase speed setting or use pulse function.
Leakage from the jug.	Lid not properly secured; Blade assembly not tightened.	Ensure lid is firmly in place; Check that the blade assembly is securely fastened to the jug.
Unusual noise or odor.	Foreign object in jug; Motor strain; Initial use odor.	Immediately stop and unplug. Check for foreign objects. If odor persists after initial uses, contact customer support.

8. Specifications

Feature	Detail
Brand	Braun
Model Number	JB 3060
Power / Wattage	800 W
Voltage	230 V
Capacity	1.75 Liters
Jug Material	Thermo-resist Glass

Feature	Detail
Blade Material	Stainless Steel
Number of Speeds	5 + Pulse Function
Product Dimensions (L x W x H)	20 x 18.5 x 38 cm
Item Weight	3.25 kg
Special Features	Unique triangular jug, Turbo function

9. Warranty and Support

For warranty information, service, or support, please refer to the warranty card included with your product or visit the official Braun website. Keep your purchase receipt as proof of purchase for any warranty claims.

Contact Information: Please refer to your local Braun service center details provided in the product packaging or on the official Braun website for assistance.

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00MFMHUPY

More documents and user manuals: **https://manuals.plus/**