Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool AWOD 4927

Whirlpool AWOD 4927 Washing Machine User Manual

Brand: Whirlpool | Model: AWOD 4927

Introduction

This user manual provides essential information for the safe and efficient operation of your new Whirlpool AWOD 4927 Washing Machine. Please read these instructions carefully before using the appliance for the first time and keep them for future reference. This appliance is designed for domestic use only.

Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the appliance is properly grounded.
- Do not allow children to play on or in the appliance.
- Do not install or store the appliance where it will be exposed to the weather or to freezing temperatures.
- Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in this manual.
- Always unplug the washing machine from the power supply before cleaning or performing maintenance.
- Do not use flammable liquids near the appliance.

Product Overview

The Whirlpool AWOD 4927 is a front-loading washing machine with a 9 kg capacity, designed for efficient and thorough

cleaning of your laundry.



This image shows the front of the Whirlpool AWOD 4927 washing machine, featuring the control panel at the top, the central loading door, and the detergent dispenser drawer.



This image displays the energy label for the Whirlpool AWOD 4927 washing machine, indicating an A+++ energy efficiency class, 215 kWh/annum energy consumption, 10800 L/annum water consumption, 9 kg capacity, and noise levels of 59 dB during wash and 77 dB during spin.

Setup and Installation

Unpacking

1. Remove all packaging materials, including the polystyrene base and any protective film.
2. Remove the transport bolts from the rear of the machine. Keep them for future transport.

Positioning

1. Place the washing machine on a firm, level floor.
2. Adjust the feet to ensure the machine is perfectly level and stable.
3. Ensure there is adequate space around the machine for ventilation and access.

Water Connection

1. Connect the water inlet hose to a cold water tap with a 3/4" thread.
2. Ensure the hose is securely tightened to prevent leaks.
3. Position the drain hose into a standpipe or over the edge of a sink, ensuring it is securely fixed to prevent displacement during operation.

Electrical Connection

1. Plug the power cord into a properly grounded electrical outlet.
2. Do not use extension cords or adapters.
3. Ensure the voltage and frequency match the specifications on the rating plate of the appliance.

Operating Instructions

Control Panel

The control panel consists of a program selector knob, function buttons, and a display screen. Refer to the diagram in your physical manual for specific button layouts.

First Use

1. Before washing laundry for the first time, run a wash cycle without laundry and detergent to clean the drum.
2. Select a short program (e.g., Quick Wash) and start the cycle.

Loading Laundry

Sort laundry by fabric type, color, and degree of soiling. Open the door and load items one by one, ensuring not to overload the drum. Leave enough space for the laundry to tumble freely.

Adding Detergent

Pull out the detergent dispenser drawer. Add the appropriate amount of detergent to the main wash compartment and, if desired, fabric softener to its designated compartment. Close the drawer gently.

Selecting a Program

Turn the program selector knob to choose the desired wash program (e.g., Cotton, Synthetics, Delicates, Wool, Quick Wash). The display will show the default temperature and spin speed for the selected program. You can adjust these settings using the corresponding buttons.

Starting a Wash Cycle

1. After selecting the program and adjusting options, press the Start/Pause button.

2. The machine will begin filling with water and the wash cycle will start.

Ending a Wash Cycle

At the end of the cycle, the machine will signal with an audible sound and/or a message on the display. The door will unlock automatically after a short delay. Remove the laundry promptly to prevent creasing.

Maintenance and Care

Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Cleaning the Detergent Dispenser

Periodically remove the detergent dispenser drawer and rinse it under running water to remove any detergent residue. Use a brush if necessary.

Cleaning the Pump Filter

The pump filter should be cleaned regularly to prevent blockages. Refer to your physical manual for the exact location and procedure for removing and cleaning the filter.

Care for the Door Seal

After each wash, wipe the door seal and glass to remove any lint or residue. Leave the door slightly ajar when not in use to allow the drum to air out and prevent odors.

Winter Storage

If the machine is to be stored in an area subject to freezing temperatures, drain all water from the hoses and pump to prevent damage.

Troubleshooting

Before contacting customer service, check the following common issues and solutions:

Problem	Possible Cause	Solution
Machine does not start	No power supply	Check if the plug is inserted correctly and the fuse is intact.
Water not filling	Water tap closed or hose kinked	Open the water tap fully. Straighten the water inlet hose.
Machine vibrates excessively	Transport bolts not removed or machine not level	Remove transport bolts. Adjust the machine's feet to level it.

Problem	Possible Cause	Solution
Water not draining	Drain hose kinked or pump filter blocked	Straighten the drain hose. Clean the pump filter.
Detergent residue in dispenser	Insufficient water pressure or clogged dispenser	Check water pressure. Clean the detergent dispenser.

Technical Specifications

Feature	Value
Brand	Whirlpool
Model	AWOD 4927
Capacity	9 kg
Maximum Spin Speed	1400 rpm
Energy Efficiency Class	A+++
Annual Energy Consumption	215 kWh/year
Annual Water Consumption	10800 Liters/year
Noise Level (Washing)	59 dB
Noise Level (Spinning)	77 dB
Installation Type	Freestanding
Weight	75 kg (approx. 165.35 lbs)
Depth (Worktop)	57.5 cm

Warranty and Customer Support

Your Whirlpool AWOD 4927 Washing Machine comes with a manufacturer's warranty. Please refer to the warranty card provided with your appliance for specific terms and conditions, including the duration and coverage.
For technical assistance, spare parts, or to schedule a service appointment, please contact Whirlpool customer support. You can usually find contact information on the Whirlpool official website for your region or on the warranty card.
When contacting support, please have your appliance's model number (AWOD 4927) and serial number ready. This information is typically found on a label inside the door or on the back of the appliance.

© 2023 Whirlpool. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00MNIHYB0

More documents and user manuals: **https://manuals.plus/**