Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun FS 3000

Braun FS3000 Electric Steamer User Manual

Model: FS 3000

1. Important Safety Instructions

Please read all instructions carefully before using the appliance and keep them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged from the power outlet before cleaning or when not in use.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Use only genuine Braun accessories and parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Avoid contact with hot surfaces. Use handles or knobs. Steam is very hot and can cause burns.
- Ensure the water reservoir is filled to the appropriate level before operation.
- The appliance features non-slip feet for stable operation. Ensure it is placed on a stable, level surface.

2. Product Overview

The Braun FS3000 Electric Steamer is designed for healthy and efficient steaming of vegetables, meats, and fish. It features a multi-tier design for cooking various foods simultaneously.



Figure 2.1: Front view of the Braun FS3000 Electric Steamer, showing the base unit with control knob, two steaming baskets, and a transparent lid.

Components:

- **Base Unit:** Contains the heating element and water reservoir. Features a power indicator light and a timer knob.
- **Water Reservoir:** Located within the base unit, for filling water.
- **Steaming Baskets:** Multiple stackable baskets for cooking different food items.
- **Lid:** Transparent lid to cover the top steaming basket.
- **Drip Tray:** Collects condensation and food juices.

- **Timer Knob:** Used to set the steaming time.
- **Power Indicator Light:** Illuminates when the appliance is operating.

3. Setup

1. **Unpack:** Carefully remove all packaging materials and accessories from the box.
2. **Initial Cleaning:** Before first use, wash all removable parts (steaming baskets, lid, drip tray) in warm soapy water or in a dishwasher. Wipe the base unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Place the Base Unit:** Position the base unit on a stable, flat, heat-resistant surface, away from walls or cabinets to allow for steam ventilation. The non-slip feet will help secure the unit.
4. **Fill Water Reservoir:** Fill the water reservoir in the base unit with clean water up to the maximum fill line. The appliance features an XXL 75mm chimney for easy water filling. Do not overfill.
5. **Assemble:** Place the drip tray onto the base unit. Then, stack the desired number of steaming baskets on top of the drip tray.

4. Operating Instructions

Follow these steps to operate your Braun FS3000 Electric Steamer:

1. **Prepare Food:** Wash and cut your food items (vegetables, fish, meat) into appropriate sizes for steaming. Place them evenly in the steaming baskets. For best results, place foods requiring longer cooking times in the lower basket.
2. **Stack Baskets:** Place the steaming baskets onto the drip tray, ensuring they are properly seated. Place the lid securely on the top basket.
3. **Connect Power:** Plug the power cord into a suitable electrical outlet.
4. **Set Timer:** Turn the timer knob to the desired steaming time. The power indicator light will illuminate, indicating that the steaming process has begun. Steam will start to generate within minutes.



Figure 4.1: The Braun FS3000 Electric Steamer in use, with prepared food items like salmon, broccoli, and potatoes on a cutting board nearby.

5. **Monitor Water Level:** If steaming for extended periods, you may need to add more water to the reservoir. Use caution when adding water during operation due to hot steam.
6. **Completion:** Once the set time has elapsed, the steamer will automatically switch off, and the power indicator light will extinguish.
7. **Serve:** Carefully remove the lid, using oven mitts to protect from hot steam. Lift the steaming baskets and serve the cooked food.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your steamer. Most removable parts are dishwasher-safe.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Empty Drip Tray:** Carefully remove and empty the drip tray.
3. **Clean Removable Parts:** Wash the steaming baskets, lid, and drip tray in warm, soapy water or place them in the dishwasher. A cleaning brush is included for convenience.
4. **Clean Base Unit:** Wipe the exterior of the base unit with a damp cloth. Do not immerse the base unit in water.
5. **Descaling:** Over time, mineral deposits may build up in the water reservoir. To descale, fill the reservoir with a mixture of water and white vinegar (1:1 ratio). Run the steamer for 20-30 minutes. Then, rinse thoroughly with clean water. Perform descaling regularly, depending on water hardness and frequency of use.
6. **Storage:** Ensure all parts are dry before storing. The baskets can be nested for compact storage.

6. Troubleshooting

Problem	Possible Cause	Solution
Steamer does not turn on.	Not plugged in; power outlet not working; timer not set.	Ensure the appliance is securely plugged into a working outlet. Turn the timer knob to the desired cooking time.
No steam is being produced.	Water reservoir is empty or too low.	Fill the water reservoir with water up to the maximum fill line.
Food is not cooking evenly.	Food items are too crowded; unevenly cut; placed in wrong baskets.	Do not overcrowd baskets. Cut food into uniform sizes. Place foods requiring longer cooking times in the lower basket.
Excessive mineral buildup.	Hard water usage; infrequent descaling.	Perform descaling as described in the Maintenance section. Use filtered water if your tap water is very hard.

7. Specifications

- **Model Number:** FS 3000
- **Brand:** Braun
- **Color:** Black (Note: Product may also be available in White/Green)
- **Power:** 850 Watts
- **Capacity:** 2 Liters
- **Material:** Steel
- **Dimensions (L x W x H):** 31 x 33 x 19.5 cm (12.2 x 13 x 7.7 inches)
- **Weight:** 2.3 Kilograms (5.1 lbs)
- **Origin:** China
- **Features:** Non-slip feet, Anti-splash system, XXL 75mm chimney, Dishwasher-safe accessories.

8. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Braun website.
Spare Parts Availability: Information regarding the availability of spare parts for this model is currently unavailable.

© 2024 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00MRS971Q

More documents and user manuals: **https://manuals.plus/**