**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Zanussi DST3570384069

# Zanussi Oven/Stove Lamp Holder, Glass Cover, and Bulb Instruction Manual

Model: DST3570384069

## Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Zanussi replacement oven/stove lamp holder, glass cover, and bulb. This product is designed to restore proper illumination within your appliance. Please read these instructions carefully before proceeding with installation or maintenance.

## Safety Information

Always prioritize safety when working with electrical appliances. Failure to follow these safety guidelines may result in electric shock, injury, or damage to the appliance.

- **Disconnect Power:** Always ensure the appliance is completely disconnected from the main power supply before attempting any installation, removal, or maintenance.
- **Allow Cooling:** Ensure the oven and existing lamp assembly have cooled down completely before handling to prevent burns.
- **Use Correct Parts:** Only use replacement parts that match the specifications of your appliance. This kit is specifically designed for Zanussi ovens/stoves.
- **Handle with Care:** Glass components can break. Handle the glass cover and bulb carefully to avoid injury.
- **Professional Installation:** If you are unsure about any step, consult a qualified technician.

## Product Overview

This replacement kit includes a complete lamp holder, a protective glass cover, and a 15W E14 bulb, designed for direct replacement in compatible Zanussi oven and stove models.



Image: The Zanussi replacement kit, showing the lamp holder, glass cover, and bulb components.

## Installation Instructions

### Before You Begin

- Ensure the oven is unplugged or the circuit breaker for the oven is switched off.
- Allow the oven cavity and existing lamp assembly to cool completely.
- Gather any necessary tools, such as a screwdriver or gloves, if required for your specific oven model.

### Step-by-Step Installation

1. **Locate the Lamp Assembly:** Open the oven door and locate the existing lamp assembly, typically on the rear or side wall of the oven cavity.
2. **Remove Old Glass Cover:** Carefully unscrew or unclip the old glass cover. Some covers may twist counter-clockwise, while others may pull straight off.
3. **Remove Old Bulb:** Unscrew the old bulb counter-clockwise from the lamp holder. Dispose of the old bulb responsibly.
4. **Remove Old Lamp Holder (if replacing the entire unit):** If your existing lamp holder is damaged and you are replacing the entire assembly, disconnect any wiring and unscrew the lamp holder from its mounting. Note the wiring configuration before disconnecting.
5. **Install New Lamp Holder (if applicable):** If replacing the holder, connect the wiring to the new lamp holder and secure it in place. Ensure connections are firm and correct.
6. **Install New Bulb:** Carefully screw the new 15W E14 bulb into the lamp holder clockwise until it is snug. Do not overtighten.
7. **Attach New Glass Cover:** Place the new glass cover over the bulb and secure it by twisting clockwise or clipping it into place. Ensure it is firmly seated to protect the bulb from heat and food splashes.
8. **Reconnect Power:** Plug the oven back into the power outlet or switch the circuit breaker back on.
9. **Test the Light:** Open the oven door or activate the oven light function to ensure the new bulb illuminates correctly.

## Operation

Once correctly installed, the oven light will operate according to your specific Zanussi oven model's design. Typically, the light will turn on automatically when the oven door is opened, or it can be manually activated via a dedicated oven light button on the control panel.

## Maintenance

### Cleaning the Glass Cover

- Ensure the oven is cool and disconnected from power.
- Remove the glass cover as described in the installation steps.
- Wash the glass cover with warm, soapy water. Avoid abrasive cleaners that could scratch the glass.
- Rinse thoroughly and dry completely before reattaching.

### Replacing the Bulb

If only the bulb needs replacement, follow steps 1-3 and 6-9 from the "Step-by-Step Installation" section. Always use a replacement bulb with the correct specifications (E14/SES fitting, 15W, 240V) to ensure proper function and safety.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Oven light does not turn on. | No power to the oven. | Check if the oven is plugged in and the circuit breaker is on. |
| | Bulb is faulty or not screwed in correctly. | Ensure the bulb is screwed in tightly. Replace the bulb with a new one if necessary. |
| | Lamp holder connections are loose or damaged. | With power disconnected, check the wiring connections to the lamp holder. If damaged, professional repair may be required. |
| Light flickers. | Loose bulb or faulty connection. | Ensure the bulb is screwed in tightly. Check lamp holder connections. |

## Specifications

- **Part Number:** 3570384069 (also referred to as DST3570384069)
- **Brand:** Zanussi
- **Bulb Fitting:** E14/SES (Small Edison Screw)
- **Bulb Wattage:** 15 W
- **Voltage:** 240V
- **Approximate Package Dimensions:** 11.3 x 10.4 x 9 cm
- **Approximate Package Weight:** 120 g
- **Compatible Models:** ZOS5, ZBM878B, ZOB141W, ZCM661NM, ZOU141W, and many other Zanussi oven and stove

models. Refer to your appliance's manual or the product listing for a comprehensive list of compatible models.

## Warranty and Support

Specific warranty information for this replacement part is not provided in the product details. For any warranty claims or technical support, please contact the retailer from whom you purchased the product or refer to the official Zanussi customer support channels for your region.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question



**Open the live page**

**https://manuals.plus/asin/B00N9U0WBU**

More documents and user manuals: **https://manuals.plus/**