Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GARDENA ErgoJet 2500

GARDENA ErgoJet 2500 Electric Leaf Blower and Vacuum

INSTRUCTION MANUAL

1. Important Safety Instructions

Read all safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.

- **Personal Protective Equipment:** Always wear safety glasses, hearing protection, and sturdy footwear when operating the device. Long pants are recommended.
- **Electrical Safety:** Ensure the power supply matches the specifications on the product label. Do not operate in wet conditions or rain. Inspect the power cord for damage before each use.
- **Operation Area:** Keep children, bystanders, and pets away from the operating area. Clear the area of any objects that could be thrown by the air stream or sucked into the device.
- **Handling:** Never point the blower nozzle at people or animals. Do not use the vacuum function to pick up hot, burning, or hazardous materials.
- **Maintenance:** Disconnect the power plug before cleaning, maintenance, or storage.

2. Package Contents

Verify that all components are present and undamaged upon unpacking:

- GARDENA ErgoJet 2500 Main Unit
- Blower Nozzle
- Vacuum Tube
- Collection Bag (45 Liters)
- Instruction Manual

3. Assembly and Setup

The GARDENA ErgoJet 2500 can be used as a leaf blower or a leaf vacuum with shredding function. Follow these steps for assembly.

3.1. Blower Mode Assembly

1. Ensure the device is unplugged from the power source.
2. Attach the blower nozzle to the main unit's outlet. Ensure it clicks securely into place.



Image 1: The GARDENA ErgoJet 2500 configured for blower operation. The long, narrow nozzle is attached to the front of the main unit, ready to direct a powerful stream of air.

3.2. Vacuum Mode Assembly

1. Ensure the device is unplugged from the power source.
2. Remove the blower nozzle if attached.
3. Attach the vacuum tube to the main unit's intake opening. Secure it firmly.
4. Attach the collection bag to the exhaust port of the main unit. Ensure the bag's opening is securely fastened to prevent debris leakage.



Image 2: The GARDENA ErgoJet 2500 configured for vacuum operation. The wider vacuum tube is attached to the front, and the black collection bag is connected to the side exhaust port.



Image 3: A user demonstrating the attachment of the collection bag to the GARDENA ErgoJet 2500. The bag is being secured to the device's exhaust port, ensuring a tight seal for effective vacuuming.

4. Operating Instructions

4.1. Connecting to Power

Plug the power cord into a suitable outdoor-rated electrical outlet. Ensure the cord is routed safely to avoid tripping hazards or damage.

4.2. Starting and Stopping

- To start the device, press the ON/OFF switch.
- To stop the device, release or press the ON/OFF switch again, depending on the switch type.

4.3. Adjustable Speed Control

The ErgoJet 2500 features adjustable speed control. Use the speed dial or lever to select the desired air speed for blowing or suction power for vacuuming. Lower speeds are suitable for delicate areas, while higher speeds are for stubborn debris.

4.4. Blower Operation

Hold the device firmly with both hands. Sweep the blower nozzle from side to side, directing leaves and debris into piles. Avoid directing air towards loose gravel or delicate plants.

4.5. Vacuum Operation and Shredding

With the vacuum tube and collection bag attached, guide the vacuum tube over the leaves and debris. The device will suck in the material, and the integrated shredder will reduce its volume before it enters the collection bag. Empty the collection bag regularly to maintain optimal performance.

5. Maintenance

Regular maintenance ensures the longevity and efficient operation of your GARDENA ErgoJet 2500.

- **Cleaning:** Disconnect from power. Clean the exterior of the device with a damp cloth. Remove any debris from the air intake and exhaust vents.
- **Collection Bag:** Empty and clean the collection bag after each use. Inspect for tears or damage.
- **Impeller:** Periodically check the impeller for any lodged debris or damage.**Always disconnect power before inspecting the impeller.**
- **Storage:** Store the device in a dry, secure place, out of reach of children.

6. Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

- **Device does not start:**
  - Check if the power cord is securely plugged into a working outlet.
  - Ensure the ON/OFF switch is fully engaged.
  - Check for tripped circuit breakers or blown fuses.
- **Low blowing/suction power:**
  - Ensure the collection bag is not full (in vacuum mode).
  - Check for blockages in the blower nozzle, vacuum tube, or impeller.**Disconnect power before clearing blockages.**
  - Verify that the speed control is set to an appropriate level.

- **Excessive vibration or unusual noise:**
  - Disconnect power and inspect the impeller for damage or lodged debris.
  - Ensure all attachments (nozzle, tube, bag) are securely fastened.

If problems persist, contact GARDENA customer support.

7. Specifications

Model	ErgoJet 2500
Model Number	G9334-20
Power	2500 W
Air Speed	Up to 310 km/h
Suction Capacity	605 m^3/h
Shredding Ratio	16:1
Collection Bag Volume	45 Liters
Product Dimensions (L x W x H)	54 x 28.5 x 35 cm
Weight	6.22 kg
Special Feature	Adjustable Speed
Power Source	Electric

8. Warranty and Support

GARDENA products are manufactured to high quality standards. For warranty information, please refer to the warranty card included with your product or visit the official GARDENA website. For technical support, spare parts, or service inquiries, please contact your local GARDENA service center or authorized dealer.

Please retain this instruction manual for future reference.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00NHDQKW4

More documents and user manuals: **https://manuals.plus/**