Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO 18925

TRESKO XXL 48-Liter Universal Scooter and Motorcycle Top Case Instruction Manual

Introduction

Thank you for choosing the TRESKO XXL 48-Liter Universal Top Case. This manual provides essential information for the safe and proper installation, operation, and maintenance of your new top case. Please read these instructions carefully before use and retain them for future reference.

Safety Information

- Ensure the top case is securely mounted to your vehicle's luggage rack before each use.
- Do not exceed the maximum load capacity of 5 kg. Overloading can affect vehicle stability and safety.
- Always distribute weight evenly inside the top case.
- Regularly check all mounting hardware for tightness. Vibrations during travel can loosen fasteners.
- Be aware that adding a top case can alter your vehicle's center of gravity and handling characteristics, especially at higher speeds or in windy conditions. Adjust your riding style accordingly.
- Keep keys in a safe place and ensure the top case is locked when unattended.

Package Contents

Please verify that all items listed below are included in your package:

- 1x TRESKO XXL 48-Liter Top Case
- 1x Universal Mounting Plate
- 2x Security Keys
- 1x Set of Installation Hardware (bolts, washers, clamps)



Figure 1: Included universal mounting plate and hardware components.

Setup and Installation

The TRESKO XXL Top Case is designed for universal fitment on most scooters, motorcycles, mopeds, and ATVs equipped with a luggage rack (porter). The quick-mount system allows for easy installation and removal.

Required Tools (Not Included):

- Wrench or socket set (appropriate sizes for included bolts)
- Screwdriver (if applicable for your luggage rack)

Installation Steps:

1. **Prepare the Luggage Rack:** Ensure your vehicle's luggage rack is clean, sturdy, and free from obstructions.
2. **Position the Mounting Plate:** Place the universal mounting plate (Figure 1) onto your vehicle's luggage rack. Align the holes on the plate with suitable attachment points on your rack. You may need to adjust the position to achieve optimal balance and clearance.
3. **Secure the Mounting Plate:** Use the provided clamps, bolts, and washers to firmly attach the mounting plate to the luggage rack. Ensure all fasteners are tightened securely. Periodically check the tightness of these fasteners, especially after initial use.



Figure 2: Universal mounting plate secured to a luggage rack.

4. **Attach the Top Case:** Align the bottom of the TRESKO top case with the secured mounting plate. The top case features a quick-release mechanism that locks it onto the plate. Press down firmly until you hear a click, indicating it is securely latched.



Figure 3: Underside of the top case showing the quick-release mechanism.

5. **Verify Security:** Gently pull upwards on the top case to ensure it is firmly attached to the mounting plate and does not wobble.
6. **Lock the Top Case:** Use one of the provided keys to lock the top case to the mounting plate. This prevents unauthorized removal.

Operating Instructions

Opening the Top Case:

1. Insert the key into the lock cylinder located on the front of the top case.
2. Turn the key to the unlock position.
3. Press the release button (usually integrated with the lock mechanism) to unlatch the lid.

4. Lift the lid. The integrated hinge limiters will prevent the lid from opening too far.



Figure 4: TRESKO Top Case with lid partially open.



Figure 5: TRESKO Top Case fully open, revealing the spacious interior.

Closing and Locking the Top Case:

1. Gently lower the lid until it closes completely. Ensure no items are obstructing the closing mechanism.
2. Press down firmly on the lid until you hear a click, indicating it is latched.
3. Insert the key and turn it to the lock position. Remove the key.
4. Verify the lid is securely locked by attempting to lift it without the key.



Figure 6: TRESKO Top Case securely closed and locked with the key.

Removing the Top Case from the Mounting Plate:

The top case can be removed from the mounting plate without tools in approximately 15 seconds for convenient carrying.

1. Unlock the top case using the key.
2. Locate the quick-release lever or button, typically found near the lock mechanism or on the underside of the case.
3. Activate the quick-release mechanism and lift the top case off the mounting plate.

Maintenance

Cleaning:

- Clean the exterior of the top case with a soft cloth and mild soap and water.
- The special coating allows splashes to be easily wiped away.
- Avoid abrasive cleaners or solvents, as these can damage the plastic surface.
- Ensure the lock mechanism is free from dirt and debris.

Regular Checks:

- Periodically inspect the mounting hardware for tightness. Retighten if necessary.
- Check the lock mechanism for smooth operation. If it becomes stiff, a small amount of silicone-based lubricant can be applied (avoid oil-based lubricants as they can attract dirt).
- Inspect the top case for any signs of damage, cracks, or wear. Replace if structural integrity is compromised.

Troubleshooting

Problem: Top case feels unstable or wobbly.

Solution: Check all mounting bolts and clamps securing the mounting plate to the luggage rack. Ensure they are fully tightened. Verify that the top case is correctly latched onto the mounting plate. If the issue persists, inspect your vehicle's luggage rack for damage or excessive flex.

Problem: Key is difficult to turn or lock mechanism is stiff.

Solution: The lock mechanism may have accumulated dirt or debris. Try cleaning it with a small brush and then apply a small amount of silicone-based lubricant into the keyhole. Avoid forcing the key. If the lock is damaged, contact customer support.

Problem: Lid does not close properly.

Solution: Ensure no items inside the top case are obstructing the lid from closing completely. Check the latch mechanism for any foreign objects or damage. Apply gentle pressure to close the lid until it clicks.

Specifications

Feature	Detail
Brand	TRESKO
Model	18925 (Tresko Topcase)
Capacity	Approximately 48 Liters
Maximum Load	5 kg
External Dimensions (L x W x H)	58 cm x 43 cm x 32 cm
Internal Dimensions (L x W x H)	56 cm x 39 cm x 29 cm
Material	Durable Matte Black Plastic
Compatibility	Universal fit for scooters, motorcycles, mopeds, ATVs with a luggage rack
Special Features	Large reflective strip, hinge limiters, quick-release mounting system, splash-resistant coating

Warranty and Support

Specific warranty information for the TRESKO XXL Top Case is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to your purchase documentation or contact the retailer where the product was purchased. You may also visit the official TRESKO website for further assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00NW6BB4I

More documents and user manuals: **https://manuals.plus/**