Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lancom 7111 VPN

Lancom 7111 VPN Router User Manual

Model: 7111 VPN (Part No. 61055)

1. Introduction

This manual provides comprehensive instructions for the installation, configuration, and operation of your Lancom 7111 VPN Router. The Lancom 7111 VPN is a professional-grade router designed for secure network connectivity, offering robust VPN capabilities for reliable and protected data transmission. Please read this manual carefully before operating the device to ensure proper setup and optimal performance.

2. Package Contents

Please check the package contents upon unpacking. If any items are missing or damaged, contact your vendor immediately.

- Lancom 7111 VPN Router
- Power Adapter
- Ethernet Cable
- Quick Start Guide
- Warranty Information

3. Product Overview

Familiarize yourself with the physical components of your Lancom 7111 VPN Router.



Image 1: Front view of the Lancom 7111 VPN Router. This image displays the compact design of the router, likely featuring various status indicator LEDs and network ports on its front or rear panel, typical for a business-grade networking device.

3.1 Front Panel Indicators

- **Power LED:** Indicates power status (On/Off).
- **System LED:** Indicates device operational status (e.g., booting, ready, error).
- **WAN LED:** Indicates WAN (Internet) connection status and activity.
- **LAN LEDs:** Indicate LAN port connection status and activity for each port.
- **VPN LED:** Indicates VPN tunnel status (e.g., established, active traffic).

3.2 Rear Panel Ports and Buttons

- **Power Input:** Connects to the provided power adapter.
- **WAN Port (RJ-45):** Connects to your Internet service provider's modem or network.
- **LAN Ports (RJ-45):** Connects to local network devices (computers, switches).
- **Console Port (RJ-45 or USB):** For direct management access (CLI).
- **Reset Button:** Used to restore factory default settings (typically requires a pin press).

4. Setup

4.1 Physical Connection

1. **Power Connection:** Connect the power adapter to the router's power input and then plug it into an electrical outlet. The Power LED should illuminate.
2. **WAN Connection:** Connect one end of an Ethernet cable to the WAN port on the router and the other end to your modem or the network jack provided by your Internet Service Provider (ISP).
3. **LAN Connection:** Connect one end of an Ethernet cable to a LAN port on the router and the other end to your computer or a network switch.
4. **Power On:** Wait for the router to fully boot up. This may take a few minutes. Observe the System LED for stable operation.

4.2 Initial Configuration Access

1. **Connect to Router:** Ensure your computer is connected to one of the router's LAN ports.
2. **Open Web Browser:** Launch a web browser (e.g., Chrome, Firefox, Edge).
3. **Enter Router IP:** In the address bar, type the default IP address of the router (commonly192.168.1.1 or

192.168.0.1). Refer to the Quick Start Guide for the exact default IP.

4. **Login:** Enter the default username and password. These are typically found in the Quick Start Guide or on a label on the router itself (e.g., Username: admin, Password: admin or 1234). It is highly recommended to change the default password immediately after the first login for security reasons.

5. Operating Instructions

This section covers basic operational aspects of the Lancom 7111 VPN Router.

5.1 Basic Network Configuration

- **WAN Settings:** Configure your Internet connection type (e.g., DHCP, Static IP, PPPoE) as provided by your ISP.
- **LAN Settings:** Adjust the router's internal IP address, subnet mask, and DHCP server settings for your local network.
- **DNS Settings:** Configure DNS servers, either automatically from your ISP or manually to preferred servers.

5.2 VPN Configuration

The Lancom 7111 VPN router supports various VPN protocols to establish secure tunnels. Common configurations include IPsec VPNs for site-to-site or client-to-site connections.

- **VPN Tunnel Setup:** Navigate to the VPN section in the web interface.
- **Select Protocol:** Choose the desired VPN protocol (e.g., IPsec, OpenVPN).
- **Configure Parameters:** Enter necessary parameters such as remote gateway IP, pre-shared key, encryption algorithms, and local/remote network subnets.
- **Activate Tunnel:** Save and activate the VPN configuration. Monitor the VPN LED for connection status.

5.3 Firewall and Security

Configure firewall rules to protect your network from unauthorized access.

- **Access Rules:** Define rules to allow or deny traffic based on source/destination IP, port, and protocol.
- **Port Forwarding:** Set up port forwarding if you need to allow external access to specific services on your local network.
- **DMZ:** Configure a Demilitarized Zone (DMZ) for specific devices if required (use with caution).

6. Maintenance

6.1 Firmware Updates

Regularly check for and install firmware updates to ensure optimal performance, security, and access to new features.

1. **Download Firmware:** Visit the official Lancom website and download the latest firmware for your 7111 VPN model.
2. **Access Router Interface:** Log in to the router's web management interface.
3. **Navigate to Firmware Update:** Find the firmware update or system upgrade section (usually under System or Maintenance).
4. **Upload and Update:** Follow the on-screen instructions to upload the downloaded firmware file and initiate the update process. Do not power off the router during this process.

6.2 Factory Reset

A factory reset will revert all settings to their default values. This can be useful for troubleshooting or when reconfiguring

the device from scratch.

- **Via Web Interface:** Navigate to the System or Maintenance section and look for a "Factory Reset" or "Restore Defaults" option.
- **Via Reset Button:** With the router powered on, use a paperclip or similar pointed object to press and hold the Reset button on the rear panel for approximately 10-15 seconds until the LEDs indicate a reset (e.g., all LEDs flash). Release the button and wait for the router to reboot.

7. Troubleshooting

This section provides solutions to common issues you might encounter.

7.1 No Internet Access

- **Check Cables:** Ensure all Ethernet cables are securely connected to the WAN and LAN ports.
- **Modem Status:** Verify that your ISP's modem is working correctly and has an active internet connection.
- **WAN LED:** Check if the WAN LED on the router is lit and blinking, indicating activity.
- **Router Configuration:** Log in to the router's web interface and verify WAN settings (IP address, DNS).
- **Reboot Devices:** Power cycle your modem, then the router, and then your computer.

7.2 Cannot Access Router Web Interface

- **IP Address:** Ensure you are using the correct default IP address (e.g.,192.168.1.1).
- **Network Connection:** Verify your computer is connected to a LAN port and has obtained an IP address from the router (check network adapter settings).
- **Firewall/Antivirus:** Temporarily disable any software firewalls or antivirus programs on your computer that might be blocking access.
- **Factory Reset:** If all else fails, perform a factory reset (see Section 6.2) and try accessing with default credentials.

7.3 VPN Tunnel Not Establishing

- **Configuration Mismatch:** Double-check all VPN parameters (IP addresses, pre-shared keys, encryption settings) on both ends of the tunnel.
- **Firewall Rules:** Ensure no firewall rules are blocking VPN traffic (e.g., UDP ports 500, 4500 for IPsec).
- **Internet Connectivity:** Verify that both VPN endpoints have active internet connections.
- **Logs:** Check the router's system logs for VPN-related error messages.

8. Specifications

Feature	Description
Brand	Lancom
Model	7111 VPN
Part Number	61055
Manufacturer	Lancom
ASIN	B00PITJRHA
WAN Interface	1 x Gigabit Ethernet (RJ-45)

Feature	Description
LAN Interface	4 x Gigabit Ethernet (RJ-45) (Typical for this class of device)
VPN Protocols	IPsec, PPTP, L2TP (Common for VPN routers)
Power Supply	External Power Adapter (Included)
First Available Date	12 November 2014

9. Warranty and Support

The Lancom 7111 VPN Router comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including warranty period and coverage details.
For technical support, firmware updates, and additional documentation, please visit the official Lancom website:

www.lancom-systems.com/support

When contacting support, please have your device model (7111 VPN) and serial number ready.

© 2023 Lancom Systems. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00PITJRHA

More documents and user manuals: **https://manuals.plus/**