Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Briggs & Stratton 820467

Briggs & Stratton 820467 Swivel Clamp Instruction Manual

Genuine Original Equipment Manufacturer (OEM) Part

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your Briggs & Stratton 820467 Swivel Clamp. This component is a genuine Original Equipment Manufacturer (OEM) part designed to ensure optimal performance and compatibility with your Briggs & Stratton equipment. Please read this manual thoroughly before attempting any installation or maintenance procedures.

2. Safety Information

WARNING:

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling parts or performing maintenance.
- Ensure the equipment is turned off, disconnected from its power source, and cooled down before installing or replacing any parts.
- Refer to your equipment's main instruction manual for specific safety precautions related to its operation and maintenance.
- This product may expose you to chemicals known to the State of California to cause cancer and reproductive harm. For more information, visit www.P65Warnings.ca.gov.

3. Product Overview

The Briggs & Stratton 820467 Swivel Clamp is a small, yet critical, component used to secure and allow rotational movement for various parts within Briggs & Stratton engines or equipment. Its design ensures a secure fit while facilitating necessary articulation. This OEM part guarantees the exact fit and material specifications required for your equipment.



Figure 1: Briggs & Stratton 820467 Swivel Clamp. This image shows the small, metallic swivel clamp, typically used for securing hoses or cables while allowing movement.

4. Setup and Installation

Installation of the 820467 Swivel Clamp typically involves replacing an existing worn or damaged clamp. Follow these general steps:

1. **Preparation:** Ensure the equipment is off, cooled, and any relevant fuel or power sources are disconnected.
2. **Locate Old Clamp:** Identify the existing swivel clamp that needs replacement.
3. **Remove Old Clamp:** Carefully remove the old clamp using appropriate tools (e.g., screwdriver, pliers). Note its orientation and how it secures the component.
4. **Position New Clamp:** Place the new Briggs & Stratton 820467 Swivel Clamp in the exact position and orientation as the old one.
5. **Secure Clamp:** Fasten the clamp securely, ensuring the component it holds is properly seated and can swivel as intended without excessive play or binding. Do not overtighten.
6. **Verify:** Double-check that the clamp is firmly attached and the component it secures functions correctly.

Always refer to your specific equipment's service manual for detailed, model-specific installation instructions.

5. Operating Principles

The swivel clamp itself does not have an "operating" procedure in the traditional sense, as it is a static component once installed. Its function is to provide a secure mounting point that allows for controlled rotational movement of an attached component (e.g., a cable, hose, or linkage). Proper installation ensures that the component can move freely within its intended range without becoming dislodged or damaged.

6. Maintenance

The Briggs & Stratton 820467 Swivel Clamp requires minimal maintenance. Periodically inspect the clamp for the following:

- **Corrosion:** Check for any signs of rust or corrosion, especially if the equipment is exposed to moisture.

- **Damage:** Look for cracks, bends, or other physical damage that could compromise its integrity.
- **Security:** Ensure the clamp remains tightly fastened and does not show signs of loosening.
- **Functionality:** Verify that the component secured by the clamp can still swivel freely without excessive friction or play.

If any issues are found, replace the swivel clamp with a new genuine Briggs & Stratton 820467 part to maintain equipment safety and performance.

7. Troubleshooting

As a simple mechanical component, troubleshooting for the swivel clamp is straightforward:

- **Component Not Swiveling Freely:**
  - Check if the clamp is overtightened. Loosen slightly if necessary.
  - Inspect for debris or foreign objects obstructing movement.
  - Ensure the component itself is not bent or damaged.
- **Clamp Appears Loose:**
  - Tighten the fastening screw/bolt.
  - If the clamp itself is stretched or deformed, replace it.
- **Visible Damage (Cracks, Bends, Heavy Corrosion):**
  - Replace the swivel clamp immediately with a genuine Briggs & Stratton 820467 part.

8. Specifications

Attribute	Value
Part Number	820467
Brand	Briggs & Stratton
Product Type	Swivel Clamp (OEM)
Product Dimensions (L x W x H)	0.39 x 0.39 x 0.39 inches
Item Weight	0.16 ounces (approx. 0.01 Pounds)
Manufacturer	Briggs and Stratton
ASIN	B00PKED8NW
UPC	024847896077

9. Warranty and Support

For specific warranty information regarding your Briggs & Stratton 820467 Swivel Clamp, please refer to the documentation provided with your original equipment or contact Briggs & Stratton customer support directly. As an OEM part, its warranty coverage is typically tied to the warranty of the equipment it is installed in, or a standard parts warranty provided by the manufacturer.
For technical support or to purchase additional genuine Briggs & Stratton parts, please visit the official Briggs & Stratton website or contact an authorized service dealer.

© 2026 Briggs & Stratton. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00PKED8NW

More documents and user manuals: **https://manuals.plus/**