Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Briggs & Stratton 710307

Briggs & Stratton Model 710307 Screw Instruction Manual

Model: 710307

1. Introduction

This manual provides essential instructions for the proper use and handling of the Briggs & Stratton OEM Screw, part number 710307. This screw is designed as a genuine replacement part for various Briggs & Stratton equipment, ensuring optimal performance and fit. Please read this manual thoroughly before installation and use.

Safety Information

- Always wear appropriate personal protective equipment (PPE), such as safety glasses, when working with tools and fasteners.
- Ensure the correct tool is used for installation to prevent damage to the screw head or the component.
- Do not overtighten screws, as this can strip threads or damage parts.
- Keep small parts, like screws, out of reach of children and pets.

2. Setup and Installation

The Briggs & Stratton Model 710307 screw is intended for specific applications within Briggs & Stratton equipment. Verify that this screw is the correct replacement part for your particular model before proceeding with installation.

1. **Identify the Location:** Locate the area on your equipment where the screw needs to be installed or replaced.
2. **Prepare the Area:** Clean any debris or old threadlocker from the receiving hole if replacing an existing screw.
3. **Position the Screw:** Align the screw with the threaded hole.
4. **Initial Engagement:** Hand-tighten the screw a few turns to ensure it is properly seated and not cross-threaded.
5. **Final Tightening:** Use the appropriate screwdriver or wrench to tighten the screw. Refer to your equipment's specific service manual for torque specifications, if available. Avoid overtightening.



Figure 1: Briggs & Stratton Model 710307 Screw. This image displays the screw, highlighting its head and threaded shaft, typical of an OEM replacement part.

3. Operating Considerations

Once installed, the screw functions as a fastener, securing components together. No specific "operation" is required beyond its proper installation. Ensure that the screw remains tight during equipment operation. Periodically check fasteners for tightness, especially after initial use or maintenance.

4. Maintenance

Proper maintenance ensures the longevity and effectiveness of the screw and the components it secures.

- **Inspection:** Regularly inspect the screw for signs of wear, corrosion, or damage. Replace if any issues are observed.
- **Cleaning:** Keep the screw and surrounding area clean from dirt, grease, and debris.
- **Storage:** Store unused screws in a dry environment to prevent rust and corrosion.

5. Troubleshooting

This section addresses common issues that may arise with fasteners.

Problem	Possible Cause	Solution
Screw will not tighten	Stripped threads in the receiving component or on the screw itself.	Inspect both the screw and the receiving hole. Replace the screw if its threads are damaged. If the receiving hole's threads are stripped, consider using a larger screw (if appropriate) or a thread repair kit.
Screw head strips	Incorrect screwdriver/wrench size or excessive torque applied.	Ensure you are using the correct tool size. Apply appropriate torque. If the head is already stripped, use a screw extractor tool to remove it.

Problem	Possible Cause	Solution
Screw is loose after installation	Insufficient tightening, vibration, or incorrect screw type for application.	Re-tighten to specifications. Consider using a thread-locking compound (e.g., Loctite) if vibration is an issue and it's safe for the application.

6. Specifications

Part Number: 710307

Manufacturer: Briggs & Stratton

Product Dimensions: 1 x 7 x 8 inches (*Note: These dimensions typically refer to packaging. Actual screw dimensions will be smaller.*)

Item Weight: 0.16 ounces

Material: (Standard fastener material, specific composition not provided)

Type: OEM Replacement Screw

7. Warranty and Support

As an OEM replacement part, this Briggs & Stratton screw is typically covered under the standard warranty terms for genuine Briggs & Stratton parts. For specific warranty details, please refer to the documentation provided with your original Briggs & Stratton equipment or visit the official Briggs & Stratton website.
For technical support or further assistance, please contact Briggs & Stratton customer service or an authorized service dealer. You can find contact information and dealer locators on the official Briggs & Stratton website: www.briggsandstratton.com

© 2024 Briggs & Stratton. All rights reserved.

This manual is for informational purposes only. Briggs & Stratton is not responsible for any damage or injury caused by improper installation or use of this product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00PKEGL1S

More documents and user manuals: **https://manuals.plus/**