Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire 5300808579

Frigidaire 5300808579 Dishwasher Owner Manual

Comprehensive Guide for Your Frigidaire Dishwasher

Introduction

This manual serves as a comprehensive guide for the Frigidaire 5300808579 Dishwasher. It provides essential information regarding the installation, operation, maintenance, and troubleshooting of your appliance. Please read this manual thoroughly before using your dishwasher to ensure safe and efficient operation and to prolong the life of the appliance.
This document is a genuine replacement owner's manual for the specified Frigidaire dishwasher model.

Product Overview



Image Description: This image displays the front cover of a dishwasher operating instructions and guide manual. The cover features a stylized drawing of dishes and glassware on the left, with text on the right. The title "Dishwasher Operating Instructions and Guide" is prominently displayed. Below the title, several model numbers are listed, indicating the manual covers multiple dishwasher types (Undercounter and Portable). The bottom of the cover shows a small diagram of a dishwasher interior and spaces to fill in model, serial, and purchase date information. The manual is identified as "Part No. 808579".

The Frigidaire 5300808579 Dishwasher is designed for efficient and thorough cleaning of your dishes. It incorporates advanced features to ensure optimal performance and user convenience. Familiarize yourself with the various components and controls outlined in this manual.

Setup and Installation

Proper installation is crucial for the safe and efficient operation of your Frigidaire dishwasher. It is recommended that installation be performed by a qualified technician.

Unpacking

- Carefully remove all packaging materials, including any tape or protective film.
- Inspect the dishwasher for any shipping damage. Report any damage immediately to your dealer.
- Ensure all accessories and components listed in the packing list are present.

Location Requirements

- The dishwasher must be installed on a level, stable floor capable of supporting its weight.
- Ensure adequate clearance for door opening and proper ventilation.
- Avoid installing the dishwasher near heat sources or in direct sunlight.

Electrical and Plumbing Connections

All electrical and plumbing connections must comply with local codes and ordinances. Refer to the detailed wiring diagram and plumbing instructions provided in the full manual for specific requirements.

Operating Instructions

Follow these steps for optimal performance and longevity of your Frigidaire dishwasher.

Loading the Dishwasher

- Scrape off large food particles from dishes before loading.
- Place dishes securely in racks, ensuring water can reach all surfaces.
- Load silverware with handles down in the basket, except for knives and sharp objects which should be handles up.
- Avoid overcrowding the dishwasher.

Adding Detergent and Rinse Aid

- Use only automatic dishwasher detergent. Do not use liquid dish soap.
- Fill the detergent dispenser according to the cycle selected and water hardness.
- Ensure the rinse aid dispenser is filled to prevent spots and improve drying.

Selecting a Wash Cycle

Your dishwasher offers various wash cycles tailored to different soil levels and dish types. Common cycles include:

- **Normal Wash:** For regularly soiled dishes.
- **Heavy Wash:** For heavily soiled pots, pans, and casseroles.
- **Light Wash/Quick Wash:** For lightly soiled dishes or quick cleaning.
- **Rinse Only:** To rinse dishes that will be washed later.

Refer to the control panel and the full manual for specific cycle descriptions and options available on your model.

Maintenance

Regular maintenance helps ensure the longevity and optimal performance of your dishwasher.

Cleaning the Interior

- Periodically clean the interior with a dishwasher cleaner or a mixture of vinegar and baking soda.
- Wipe down the door gasket to remove food particles and residue.

Cleaning the Filters

Some models feature removable filters that should be cleaned regularly to prevent clogs and ensure proper drainage. Consult your full manual for instructions on accessing and cleaning these filters.

Exterior Care

- Wipe the exterior surfaces with a soft, damp cloth.
- For stainless steel finishes, use a specialized stainless steel cleaner.

We Service What We Sell



"We Service What We Sell" is our assurance to your that you can depend on Sears for service . . . and Sears service is nationwide. Your Sears dishwasher has added value when you consider that Sears has service units nationwide, staffed with Sears-trained technicians . . . professional technicians specifically trained on Sears appliances having the parts, tools, and equipment to insure that we meet our pledge to you . . . "We Service What We Sell."

Sears Maintenance Agreement

Sears Maintenance Agreement . . . your way to buy tomorrow's service at today's prices . . . and Sears Service is nationwide.

Maintain the value of your Kenmore Dishwasher with a Sears Maintenance Agreement. Sears dishwashers are designed, manufactured, and tested for years of dependable operation. Yet, any modern appliance may require service from time to time.

Sears Maintenance Agreement

- Eliminates large or small repair bills resulting from normal use.
- Allows for as many service calls as required.
- Provides for service by professional Sears Trained Technicians.
- Even if you don't need repairs, the Maintenance Agreement offers an annual preventative maintenance check-up at your request!

This Maintenance Agreement does not cover original installation, reinstallation, or damage resulting from external causes such as acts of abuse, theft, fire, flood, wind, lightening, freezing, power failure, power reduction, etc.

Sears, Roebuck and Co. Chicago, Illinois 60684 U.S.A.

To Build In Portable Models

Your portable Kenmore dishwasher can be installed under the counter. All that is needed is conversion kit no. 15001 and instructions purchased from your local Sears store or Service Center. A 18½" opening is required. After installation, the front of your dishwasher will protrude approximately 1" further than a regular built-in dishwasher. This is due to the depth of the cabinet on portable dishwashers.

Kit For Wood Panels

You can replace the color panels on your Kenmore undercounter dishwasher with wood panels to match your kitchen cabinets. All that is needed, besides the wood panels, is Kit #7668 which contains the necessary parts and instructions. This kit can be purchased from your local Sears store or Service Center.

Image Description: This image shows a page from a service manual titled "We Service What We Sell". It describes service agreements and maintenance programs offered by a service provider. The text emphasizes the benefits of professional technicians and regular check-ups. A graphic of a service van with a technician is visible on the left side of the page. This page illustrates the importance of professional service and maintenance for appliances.

TROUBLESHOOTING

Before calling for service, refer to the following common issues and their solutions.

Problem	Possible Cause	Solution
Dishwasher not starting	Door not latched, power issue, cycle not selected.	Ensure door is fully closed and latched. Check power supply and circuit breaker. Select a wash cycle.
Dishes not clean	Improper loading, insufficient detergent, clogged spray arms, low water temperature.	Reload dishes correctly. Use recommended amount of detergent. Clean spray arm nozzles. Ensure hot water supply.
Dishwasher not draining	Clogged drain hose, clogged filter, air gap issue.	Check and clear drain hose. Clean filter. Inspect air gap for blockages.
Excessive noise	Dishes interfering with spray arm, foreign object in pump.	Rearrange dishes. Inspect pump area for debris (unplug first).

For issues not listed here or if solutions do not resolve the problem, please contact customer support.

Specifications

The following specifications apply to the Frigidaire 5300808579 Dishwasher:

Model Number: 5300808579

Brand: Frigidaire

Product Type: Dishwasher Owner Manual (for model 5300808579)

Item Weight: Approximately 1.2 pounds

Product Dimensions: Approximately 11 x 8.5 x 1 inches

ASIN: B00PU0VA4K

Date First Available: May 20, 2010



Image Description: This image shows a person holding the dishwasher operating instructions manual, providing a visual reference for its physical dimensions. A ruler graphic on the left indicates the manual is approximately 11 inches (28 cm) in height. This image helps to convey the physical size and format of the manual.

Warranty Information

This product, being a genuine replacement owner's manual, does not typically carry a separate warranty beyond the standard return policy for physical goods. For information regarding the warranty of the Frigidaire 5300808579 Dishwasher itself, please refer to the warranty section within the original appliance purchase documentation or contact Frigidaire customer service directly.
For details on returns or replacements of this manual, please refer to the retailer's return policy where it was purchased. For purchases made on Amazon, the standard return policy is typically 30 days for refund/replacement.

Customer Support

Should you require further assistance or have questions not covered in this manual, please contact Frigidaire customer support. Have your model number (5300808579) and serial number ready when contacting support.

Frigidaire Official Website: www.frigidaire.com

Customer Service Phone: Refer to the official Frigidaire website for the most current contact numbers.

For service inquiries related to the actual dishwasher appliance, it is recommended to contact authorized Frigidaire service centers.

© 2024 Frigidaire. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00PU0VA4K

More documents and user manuals: **https://manuals.plus/**