Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BLACK+DECKER SL1050

BLACK+DECKER SL1050 Lean Prep Machine Food Processor User Manual

Model: SL1050

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. Read all instructions before using the appliance.
2. To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
5. Avoid contact with moving parts.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer service for examination, repair, or electrical or mechanical adjustment.
7. The use of attachments not recommended or sold by the appliance manufacturer may cause fire, electric shock, or injury.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
12. Do not use appliance for other than intended use.
13. Be careful when handling sharp blades.

Product Overview

The BLACK+DECKER SL1050 Lean Prep Machine is a versatile appliance designed for both food processing and creating frozen desserts. It features interchangeable attachments to handle various kitchen tasks efficiently.



Image: The BLACK+DECKER SL1050 Lean Prep Machine, illustrating its dual functionality as a food processor and a frozen dessert maker.

Components

- **Motor Base:** The main power unit.
- **Food Processing Attachment:** For slicing and shredding.
- **Frozen Dessert Attachment:** For blending frozen fruits into desserts.
- **Food Pusher:** Used with the food processing attachment to guide ingredients.
- **Blades (4 options):** Coarse Shredding, Fine Shredding, Thick Slicing, Thin Slicing.
- **Wide Mouth Feed Chute:** For easy loading of ingredients.
- **Folding Handle:** For compact storage.



Image: The four interchangeable blades for various processing needs.



Image: The food pusher, used to safely guide ingredients into the chute.



Image: The wide mouth feed chute, designed for larger ingredients.



Image: The frozen dessert attachment, featuring an auger for blending.

Setup and Assembly

Before First Use

- Remove all packing materials, stickers, and plastic bands from the appliance.
- Wash all removable parts (blades, food pusher, attachments) in warm, soapy water, then rinse and dry thoroughly. The motor base should be wiped with a damp cloth.

Assembling the Food Processing Attachment

1. Place the motor base on a clean, dry, and stable surface.
2. Align the food processing attachment with the motor base and twist until it locks securely into place.
3. Select the desired blade (slicing or shredding) and carefully insert it into the attachment's chute. Ensure it is seated correctly.
4. Place a bowl directly under the output chute to collect processed food.

Assembling the Frozen Dessert Attachment

1. Place the motor base on a clean, dry, and stable surface.
2. Align the frozen dessert attachment with the motor base and twist until it locks securely into place.
3. Ensure the auger is properly seated within the attachment.
4. Place a bowl directly under the output chute to collect the frozen dessert.

Operating Instructions

Using the Food Processing Attachment

1. Ensure the appliance is assembled correctly with the desired blade and a collection bowl in place.
2. Prepare ingredients by cutting them into pieces that fit comfortably into the wide mouth feed chute.
3. Plug the appliance into a standard electrical outlet.
4. Turn the appliance ON.
5. Carefully place ingredients into the feed chute. Use the food pusher to gently guide them towards the rotating blade. **Never use your fingers or other utensils to push food.**
6. Continue processing until all ingredients are done.
7. Turn the appliance OFF and unplug it from the outlet before disassembling or removing processed food.

Using the Frozen Dessert Attachment

1. Ensure the appliance is assembled correctly with the frozen dessert attachment and a collection bowl in place.
2. Prepare frozen fruits (e.g., bananas, berries, mangoes) by cutting them into smaller pieces if necessary. For best results, use fruits that are frozen solid but not rock-hard.
3. Plug the appliance into a standard electrical outlet.
4. Turn the appliance ON.
5. Gradually feed the frozen fruit pieces into the chute. The auger will process them into a smooth, soft-serve consistency.
6. You can combine different frozen fruits or add small amounts of frozen yogurt, chocolate chips, or other mix-ins for varied flavors.
7. Turn the appliance OFF and unplug it from the outlet before disassembling or serving.

Maintenance and Cleaning

Proper cleaning and maintenance will ensure the longevity and optimal performance of your BLACK+DECKER SL1050 Lean Prep Machine.

Cleaning Instructions

1. **Always unplug the appliance** from the electrical outlet before cleaning.
2. Disassemble all removable parts: food pusher, blades, and attachments.
3. **Removable Parts:** All removable parts are top-rack dishwasher-safe. Alternatively, they can be washed by hand in warm, soapy water. Use a brush to clean around blades carefully. Rinse thoroughly and dry completely before storing.
4. **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
5. Do not use abrasive cleaners or scouring pads on any part of the appliance, as they may scratch surfaces.
6. Ensure all parts are completely dry before reassembling or storing the appliance.

Storage

Store the appliance in a clean, dry place. The folding handle allows for more compact storage. Keep blades in a safe

place to prevent accidental injury.

Troubleshooting

If you encounter issues with your appliance, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet not working; appliance not assembled correctly.	Check power cord connection; test outlet with another appliance; ensure attachments are securely locked onto the motor base.
Food is not processing efficiently.	Incorrect blade used; ingredients too large; too much pressure applied with food pusher.	Ensure correct blade is installed for the task; cut ingredients into smaller, manageable pieces; apply gentle, even pressure with the food pusher.
Frozen dessert is not smooth.	Fruits are too hard or not fully frozen; too many ingredients added at once.	Allow very hard frozen fruits to thaw slightly; ensure fruits are frozen solid but not icy; feed ingredients gradually.
Appliance stops during operation.	Overload protection activated.	Turn off and unplug the appliance. Remove some ingredients. Let the motor cool down for 10-15 minutes before restarting.

Specifications

Feature	Specification
Model Number	SL1050
Brand	BLACK+DECKER
Wattage	550 watts
Material	Plastic
Color	Green
Item Weight	4.5 pounds
Included Components	Coarse Shredding Blade, Fine Shredding Blade, Thick Slicing Blade, Thin Slicing Blade, Food Pusher, Frozen Dessert Attachment

Warranty and Support

This product is covered by a limited warranty. For detailed warranty information, product registration, or technical support, please visit the official BLACK+DECKER website or contact their customer service department.

Please retain your proof of purchase for warranty claims.
Online Support: www.blackanddecker.com/support

© 2024 BLACK+DECKER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00PY000LA

More documents and user manuals: **https://manuals.plus/**