Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GOgroove GGBSBX0100BRUS

GOgroove BlueSYNC BX Portable Wireless Bluetooth Speaker User Manual

Model: GGBSBX0100BRUS | Brand: GOgroove

Introduction

Thank you for purchasing the GOgroove BlueSYNC BX Portable Wireless Bluetooth Speaker. This manual provides detailed instructions on how to set up, operate, and maintain your speaker to ensure optimal performance and longevity. The BlueSYNC BX offers versatile audio playback options including Bluetooth, AUX, and USB, delivering clear and powerful sound in a compact design.

Package Contents

- GOgroove BlueSYNC BX Portable Wireless Bluetooth Speaker
- Rechargeable Battery
- USB Charging Cable

Please ensure all items are present before proceeding.

Product Overview



Figure 1: Front and side view of the GOgroove BlueSYNC BX speaker, highlighting the control panel and speaker grille.

The GOgroove BlueSYNC BX is designed for portability and high-quality audio. It features a robust build with a wood-brown finish and a black control panel. Key components include:

- **Speaker Grille:** Located on the side, protecting the 50mm full-range drivers.
- **Control Panel:** Features a central volume knob, playback control buttons (Previous, Play/Pause/Mode, Next), and NFC pairing area.
- **Input Ports:** USB port for flash media playback, 3.5mm AUX input, and a mini USB charging port.
- **Integrated Microphone:** For hands-free calling.

Setup

1. Charging the Speaker

Before first use, fully charge the BlueSYNC BX speaker. Connect the supplied USB charging cable to the speaker's mini USB port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will illuminate. A full charge typically takes 2-3 hours and provides 4-6 hours of playback time.

2. Powering On/Off

Locate the power switch, typically on the back or side of the unit. Slide the switch to the "ON" position to power on the speaker. Slide it to "OFF" to power off.

3. Bluetooth Pairing

The BlueSYNC BX will automatically enter Bluetooth pairing mode when powered on for the first time or if no device is

connected. The Bluetooth indicator light will flash.

1. **Standard Pairing:**
    a. Ensure the speaker is powered on and in pairing mode.
    b. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
    c. Select "BlueSYNC BX" from the list of found devices.
    d. Once paired, the Bluetooth indicator light will become solid, and you will hear a confirmation tone.
2. **NFC Pairing (Near Field Communication):**
    a. Ensure NFC is enabled on your compatible device.
    b. Tap your NFC-enabled device gently against the NFC logo area on the speaker's control panel.
    c. Confirm the pairing request on your device.
    d. The devices will connect automatically.

4. AUX Input Connection

For devices without Bluetooth, use the 3.5mm AUX input. Connect one end of a 3.5mm audio cable (not included) to your audio device's headphone jack and the other end to the AUX input port on the BlueSYNC BX. The speaker will automatically switch to AUX mode, or you may need to press the Mode button (often combined with Play/Pause) to select AUX.

5. USB Flash Drive Playback

Insert a USB flash drive (up to 32GB) containing MP3 audio files into the USB port on the speaker. The speaker will automatically detect the drive and begin playing audio files. Use the playback controls to navigate tracks.

Operating Instructions

Controls:

Button/Control	Function
Volume Knob	Rotate clockwise to increase volume, counter-clockwise to decrease volume.
K<< (Previous)	Short press to go to the previous track.
>II/M (Play/Pause/Mode)	Short press to Play or Pause audio. Long press to switch between Bluetooth, AUX, and USB modes.
>>I (Next)	Short press to go to the next track.
NFC Area	Tap NFC-enabled device for quick Bluetooth pairing.

Hands-Free Calling:

When connected via Bluetooth, the integrated microphone allows for hands-free calls.

- **Answer Call:** Short press the Play/Pause button.
- **End Call:** Short press the Play/Pause button during a call.
- **Reject Call:** Long press the Play/Pause button when a call comes in.

Maintenance

To ensure the longevity and optimal performance of your GOgroove BlueSYNC BX speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the speaker. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** If the speaker will not be used for an extended period, charge it fully every 3-6 months to preserve battery life.
- **Avoid Moisture:** The speaker is not waterproof. Keep it away from water, rain, and excessive humidity.

Troubleshooting

Problem	Possible Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB cable. Check the power switch is in the "ON" position.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode (flashing Bluetooth indicator). Make sure Bluetooth is enabled on your device. Move the speaker closer to your device. Forget "BlueSYNC BX" from your device's Bluetooth list and try pairing again.
No sound or low volume.	Increase the volume on both the speaker and your connected device. Ensure the correct input mode (Bluetooth, AUX, USB) is selected. Check if the audio cable is fully inserted for AUX mode. For USB, ensure files are in MP3 format and the drive is properly inserted.
Sound distortion or buzzing.	Move the speaker away from other electronic devices that may cause interference. Ensure the battery is properly inserted (as per a review, missing battery can cause buzzing on AUX). Reduce the volume if it's too high.
USB flash drive not recognized.	Ensure the flash drive is formatted correctly (FAT32) and contains MP3 files. The maximum supported size is 32GB. Try a different USB flash drive.

Specifications

Feature	Detail
Model Name	BlueSYNC BX
Speaker Type	Portable Bluetooth Speaker
Connectivity Technology	Bluetooth, NFC, Auxiliary (3.5mm), USB
Wireless Communication	Bluetooth, NFC
Bluetooth Range	Up to 33 Feet (10 meters)
Audio Output Mode	Stereo
Speaker Power Output	3W x 2; 12W Peak

Feature	Detail
Driver Size	50mm Full-range Drivers
Battery Life	4-6 Hours (Playback time)
Power Source	Battery Powered
Integrated Microphone	Yes
USB Input	Supports USB flash drives up to 32GB (MP3 format)
Product Dimensions	5.1"D x 4.5"W x 6.6"H
Item Weight	1.55 pounds
Color	Wireless - Brown
UPC	637836582471

Warranty and Support

The GOgroove BlueSYNC BX Portable Wireless Bluetooth Speaker comes with a**3-Year Manufacturer Warranty**. For warranty claims, technical support, or further assistance, please contact GOgroove customer service. Refer to the GOgroove official website for the most up-to-date contact information and support resources.
GOgroove Official Website: Visit the GOgroove Store on Amazon

© 2023 GOgroove. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00Q3D0AGW

More documents and user manuals: **https://manuals.plus/**