Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EcoAqua EFF-6011A

EcoAqua EFF-6011A Refrigerator Water Filter Instruction Manual

Model: EFF-6011A

Introduction

Thank you for choosing the EcoAqua EFF-6011A Refrigerator Water Filter. This filter is designed to provide clean, fresh-tasting water by reducing chlorine, taste, and odor, and is certified to NSF/ANSI 42 and 372 standards. This manual provides essential information for the proper installation, operation, and maintenance of your new water filter.



Image: Three EcoAqua EFF-6011A water filters, showcasing the product packaging and design.

Product Features and Certifications

- **Certified Performance:** NSF/ANSI 42 certified to reduce 97% of chlorine, taste, and odor. NSF 372 certified for lead-free material.
- **High-Quality Filtration:** Utilizes 100% superior coconut shell carbon block for effective impurity removal.
- **Lead-Free and Food-Grade Materials:** Constructed with safe, lead-free, and food-grade materials.
- **Easy Installation:** Designed for quick and easy installation and replacement.
- **Optimal Lifespan:** Recommended replacement every 6 months or 300 gallons for best performance.



Image: The EcoAqua filter highlighting its WRAS, NSF, and BPA-Free certifications, indicating high quality and safety standards.



Image: The WRAS Approved Product logo, confirming compliance with UK water regulations.

Package Contents

Upon opening your EcoAqua EFF-6011A Refrigerator Water Filter package, you should find the following items:

- 3 x EcoAqua Refrigerator Water Filter Replacements
- 1 x User's Manual (this document)
- Month Install Stickers (for tracking replacement dates)

Setup and Installation

Follow these steps to properly install your new EcoAqua water filter. It is recommended to refer to your refrigerator's specific user manual for exact filter location and removal instructions, as models may vary.

1. **Locate the Filter Compartment:** The water filter is typically located in the upper right corner of the refrigerator

compartment, or within the base grille.

2. **Prepare for Removal:** Before removing the old filter, it is advisable to dispense a small amount of water from the dispenser to relieve pressure. This can make removal easier.
3. **Remove Old Filter:** Twist the old filter counter-clockwise until it unlocks and can be pulled straight out. Some water may drip, so have a towel ready.
4. **Prepare New Filter:** Remove the protective cap from the new EcoAqua filter.
5. **Install New Filter:** Insert the new filter into the housing and twist it clockwise until it locks securely into place. Ensure it is fully seated to prevent leaks and ensure proper filtration. You may hear a click.
6. **Flush the System:** After installation, dispense approximately 2-3 gallons of water through the refrigerator's water dispenser to flush out air and any carbon fines from the new filter. This will ensure clear, fresh-tasting water.
7. **Reset Filter Indicator:** Most refrigerators have a filter change indicator light. Refer to your refrigerator's manual for instructions on how to reset this light. This usually involves pressing and holding a specific button (e.g., "Filter," "Water," or "Ice Type") for a few seconds.
8. **Apply Month Sticker:** Use the provided month install sticker to mark the installation date on your refrigerator or calendar, helping you remember when to replace the filter next.



Image: A close-up of the EcoAqua water filter, illustrating the twisting motion required for proper installation, emphasizing its OEM fit.

Operating Instructions

Once installed, the EcoAqua EFF-6011A filter operates automatically to provide filtered water and ice. No further user interaction is required for daily operation.
For optimal performance and water quality, ensure the filter is replaced regularly as outlined in the Maintenance section.



Image: A cross-section diagram illustrating how water passes through the activated carbon block, removing contaminants to provide cleaner drinking water.

Maintenance

Regular replacement of your EcoAqua water filter is crucial for maintaining water quality and refrigerator performance.

- **Replacement Cycle:** Replace the filter every **6 months** or after filtering **300 gallons** of water, whichever comes first. This ensures continued reduction of impurities and prevents potential flow rate issues.
- **Monitoring:** Pay attention to your refrigerator's filter indicator light (if equipped) and any noticeable changes in water taste or flow rate, which may indicate the need for an earlier replacement.
- **Storage:** Store new, unused filters in a cool, dry place away from direct sunlight.



Image: A visual summary of the filter's key features, including its economical nature, ability to provide cleaner water for up to 6 months or

1100 liters, and ease of installation.

Troubleshooting

If you encounter issues with your EcoAqua water filter, consider the following common problems and solutions:

Problem	Possible Cause	Solution
Water tastes bad or unfiltered.	◦ Filter not fully seated. ◦ New filter not flushed adequately. ◦ Filter needs replacement.	◦ Ensure filter is twisted fully clockwise until it locks. ◦ Flush 2-3 gallons of water through the dispenser. ◦ Replace the filter if it's been 6 months or 300 gallons.
Slow water flow from dispenser.	◦ Clogged filter. ◦ Air trapped in the system.	◦ Replace the filter. ◦ Flush the system by dispensing water until flow improves.
Water leaking from filter area.	◦ Filter not installed correctly. ◦ Damaged O-rings on filter.	◦ Remove and re-install the filter, ensuring it's fully seated. ◦ Inspect the O-rings on the filter. If damaged, replace the filter.

If problems persist after attempting these solutions, please contact EcoAqua customer support.

Specifications

Attribute	Detail
Model Number	EFF-6011A
Compatible Refrigerator Models	Samsung DA29-00003G, Aqua-Pure Plus, DA29-00003A, DA97-06317A, RF267AERS, HAFIN2, FMS-1, RF268ABRS, DA61-00159, DA29-00003D, HAFCU1/XAA, HAFIN2/EXP, DA29-00003, DA29-00003A-B, DA61-00159A, DA61-00159A-B, DA61-159, AP4444333, WF-DA29-00003G, RWF1010, RWF1100A, GF-03G, PL-700, CWMF022, MB-F11B, AQF-FF11B, WD-F11B, FL-RF11, WS611B, WF289, CLCH103. Also compatible with many Samsung models including RB215BSBB, RF265ACBP, RFG238AZRS, etc. (See product description for full list).
Material	Lead-Free Material, Food-Grade Material, Advanced Activated Coconut Carbon Block
External Testing Certification	NSF 42/372, WRAS Approved
Product Dimensions	6"D x 9"W x 3"H
Item Weight	1.94 Pounds (for the pack of 3)
Recommended Replacement Cycle	Every 6 months or 300 gallons

Attribute	Detail
Product Benefits	Perfect fit, Deep filtration, Fresh-tasting water, Easy to install, No leaks

Warranty and Support

For warranty information or technical support regarding your EcoAqua EFF-6011A Refrigerator Water Filter, please refer to the contact information provided on the product packaging or visit the official EcoAqua website. Keep your purchase receipt for warranty claims.

EcoAqua Store: Visit the EcoAqua Store on Amazon

© 2024 EcoAqua. All rights reserved.
This manual is for informational purposes only. EcoAqua is a registered trademark.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00QFVF3B4

More documents and user manuals: **https://manuals.plus/**