Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic SD-YD205

Panasonic Bread Machine SD-YD205

Instruction Manual and Recipes

1. Introduction

Thank you for purchasing the Panasonic Bread Machine Model SD-YD205. This manual provides essential information for the safe and efficient operation of your bread maker, including setup instructions, operating procedures, maintenance tips, troubleshooting, and a selection of recipes.

Important Safety Instructions

- Read all instructions before using the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

2. Setup

Unpacking and Initial Cleaning

1. Carefully remove the bread machine and all accessories from the packaging.
2. Wash the bread pan, kneading blade, and measuring utensils in warm, soapy water. Rinse thoroughly and dry completely.
3. Wipe the exterior of the bread machine with a damp cloth. Do not use abrasive cleaners.
4. Ensure all parts are dry before assembly.

Assembly

- Insert the kneading blade onto the shaft inside the bread pan. Ensure it is securely seated.
- Place the bread pan into the baking chamber of the bread machine. Press down firmly until it clicks into place.
- Close the lid.

3. Operating Instructions

Adding Ingredients

Always add ingredients in the order specified in the recipe. Typically, liquids are added first, followed by dry ingredients, with yeast added last on top of the dry ingredients, away from liquids and salt.

1. Add all liquid ingredients to the bread pan.
2. Add dry ingredients, including sugar and salt.
3. Make a small indentation in the center of the dry ingredients and add the yeast. Ensure yeast does not come into direct contact with liquids or salt initially.
4. Close the lid securely.

Program Selection

The SD-YD205 offers various baking programs. Refer to the control panel for specific program names and numbers.

- **Basic:** For white and mixed breads.
- **Whole Wheat:** For breads made with whole wheat flour.
- **French:** For light, crispy crust breads.
- **Dough:** Prepares dough for baking in a conventional oven.
- **Bake Only:** For baking pre-made dough or reheating.

Use the 'Menu' button to cycle through the available programs. Select your desired crust color (light, medium, dark) and loaf size (medium, large) using the respective buttons.

Starting and Stopping

- Press the 'Start' button to begin the selected program.
- To stop a program, press and hold the 'Stop' button for a few seconds.

4. Recipes

The following recipes are designed for the Panasonic SD-YD205 bread machine. Always use fresh ingredients and accurate measurements for best results.

Basic White Bread (Large Loaf)

- Water: 1 1/4 cups
- Bread Flour: 3 cups
- Sugar: 2 tablespoons
- Salt: 1 1/2 teaspoons
- Dry Milk Powder: 2 tablespoons
- Butter (softened): 2 tablespoons
- Active Dry Yeast: 2 teaspoons

Instructions: Add ingredients to the bread pan in the order listed. Select 'Basic' program, 'Large' loaf size, and desired crust color. Press 'Start'.

Whole Wheat Bread (Large Loaf)

- Water: 1 1/2 cups
- Whole Wheat Flour: 3 cups
- Brown Sugar: 3 tablespoons

- Salt: 1 1/2 teaspoons
- Vegetable Oil: 2 tablespoons
- Active Dry Yeast: 2 teaspoons

Instructions: Add ingredients to the bread pan in the order listed. Select 'Whole Wheat' program, 'Large' loaf size, and desired crust color. Press 'Start'.

5. Maintenance

Cleaning the Bread Machine

- Always unplug the bread machine and allow it to cool completely before cleaning.
- **Bread Pan and Kneading Blade:** Remove the bread pan and kneading blade. Wash them in warm, soapy water. Use a soft brush to remove any stuck-on dough. Do not use abrasive cleaners or metal scouring pads. Rinse and dry thoroughly.
- **Exterior:** Wipe the exterior of the bread machine with a damp cloth. Do not immerse the main unit in water.
- **Interior:** Wipe the interior of the baking chamber with a damp cloth. Remove any crumbs or flour residue.

Storage

Store the bread machine in a clean, dry place when not in use. Ensure the bread pan and kneading blade are clean and dry before storing.

6. Troubleshooting

Problem	Possible Cause	Solution
Bread does not rise	Expired yeast, incorrect water temperature, too much salt.	Check yeast expiration date. Use lukewarm water (105-115°F / 40-46°C). Measure salt accurately.
Bread is too dense	Too much flour, not enough liquid, old yeast.	Measure flour accurately (spoon into cup, level off). Ensure correct liquid amount. Use fresh yeast.
Crust is too dark/light	Incorrect crust setting selected.	Adjust the 'Crust Color' setting for your next loaf.
Kneading blade stuck in bread	Common occurrence.	Allow bread to cool slightly, then carefully remove the blade using a non-metallic utensil.

7. Specifications

- **Model:** SD-YD205
- **Power Supply:** AC 120V, 60Hz
- **Power Consumption:** 550W (approx.)
- **Loaf Sizes:** Medium, Large
- **Dimensions (approx.):** 14.6" (W) x 10.2" (D) x 13.4" (H)
- **Weight (approx.):** 15 lbs

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00QJTRGN0

More documents and user manuals: **https://manuals.plus/**