Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fiskars 100580-1010

Fiskars ProCision 12-Inch Folding Rotary Bypass Paper Cutter Instruction Manual

Model: 100580-1010

1. Product Overview

The Fiskars ProCision Rotary Bypass Trimmer is designed for precise cutting of various materials, including thick items like cork, magnet, chipboard, and EVA foam sheets up to 3mm. Its unique dual-rail system ensures stable and accurate cuts. The self-sharpening rotary bypass blade eliminates the need for replacements, offering long-lasting performance. The trimmer features grid line measurements in both English and metric units, suitable for both right- and left-handed users. A convenient folding design allows for easy storage and transport.



Image 1.1: The dual-rail system of the Fiskars ProCision Rotary Bypass Paper Cutter, designed to eliminate blade wiggle for precise cuts through thick materials.



Image 1.2: A user cutting a sheet of cork material with the Fiskars ProCision Rotary Bypass Paper Cutter, demonstrating its capability with thick materials.

▶ **Watch video online**
Fiskars Procision Rotary Bypass Trimmer, 12-Inch

Video 1.1: An official manufacturer video demonstrating the features and use of the Fiskars ProCision Rotary Bypass Trimmer, 12-Inch.

2. Setup

1. **Unpacking:** Carefully remove the paper cutter from its packaging. Retain packaging for future storage or transport.
2. **Unfolding the Base:** The cutter features a folding design. Gently unfold the base until it locks into place, extending the measuring area. Ensure the base is fully extended and stable on a flat surface before use.



Image 2.1: The foldable base of the Fiskars ProCision Rotary Bypass Paper Cutter, illustrating its compact storage capability.

3. **Surface Placement:** Place the cutter on a stable, flat, and clean work surface to ensure accurate cuts and prevent movement during operation.

3. Operating Instructions

1. **Prepare Material:** Ensure your material (paper, cardstock, cork, etc.) is flat and free of creases.
2. **Position Material:** Lift the clear smudge guard. Place your material against the desired measurement line on the cutting base. The grid lines are marked in both inches and centimeters for convenience.



Image 3.1: Detailed view of the cutting base with both English (inches) and metric (centimeters) measurements for precise alignment.

3. **Secure Material:** Lower the clear smudge guard to hold the material firmly in place. This prevents shifting during the cut.
4. **Perform Cut:** Hold the material securely with one hand. With the other hand, grasp the rotary blade carriage. Apply firm, even pressure and slide the blade carriage along the dual rails from one end of the material to the other. For thicker materials, a slower, consistent motion may yield better results.
5. **Remove Material:** Once the cut is complete, lift the smudge guard and remove the trimmed material.
6. **Cutting Capacity:** The trimmer can cut up to 20 sheets of 20# bond/75 gsm paper simultaneously. For thicker materials, adjust the number of sheets accordingly to avoid straining the blade or compromising cut quality.



Image 3.2: A visual representation of the 20-sheet cutting capacity for standard paper.

4. Maintenance

- **Blade Maintenance:** The Fiskars ProCision Rotary Bypass Paper Cutter features a self-sharpening blade. This means the blade is designed to maintain its sharpness with regular use and does not require manual sharpening or replacement under normal operating conditions.



Image 4.1: A close-up view of the self-sharpening rotary bypass blade, highlighting its design for continuous sharpness.

- **Cleaning:** Periodically wipe down the cutting base and rails with a soft, dry cloth to remove any paper dust or debris. Avoid using abrasive cleaners or solvents, as these may damage the surface or markings.
- **Storage:** When not in use, fold the base for compact storage. Store the cutter in a clean, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

- **Crooked Cuts:**
  - Ensure the material is firmly pressed against the measurement guide and held securely by the smudge guard.
  - Verify that the cutter's base is fully unfolded and stable on a flat surface.
  - Apply consistent, even pressure when sliding the blade carriage.
- **Rough or Frayed Edges:**
  - While the blade is self-sharpening, excessive force or cutting too many sheets at once can affect cut quality. Reduce the number of sheets.

- Ensure the material is not damp or excessively fibrous, which can lead to tearing.
- Clean any accumulated debris from the blade and cutting track.

- **Blade Sticking or Difficulty Sliding:**
  - Check the dual rails for any obstructions or debris. Clean them thoroughly.
  - Ensure the blade carriage is properly seated on both rails.
  - Avoid forcing the blade; apply steady, firm pressure.

6. Specifications

Feature	Detail
Model Number	100580-1010
Cut Length	12 inches
Material	Metal, Plastic
Blade Material	Titanium
Item Weight	6.4 pounds
Cutting Capacity	Up to 20 sheets (20# bond/75 gsm paper)
Measurements	English (inches) and Metric (centimeters)
Special Features	Dual-rail system, Self-sharpening blade, Folding base, Smudge guard



Image 6.1: A diagram illustrating the dimensions (19.52" x 8.81" x 16.39") and weight (5.28 lbs) of the paper cutter.

7. Warranty Information

The Fiskars ProCision Folding Rotary Bypass Paper Cutter comes with a**Lifetime Manufacturer Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the official Fiskars website or contact their customer support.

8. Support

For further assistance, product inquiries, or to access additional resources, please visit the official Fiskars website: www.fiskars.com

You may also refer to theFiskars Store on Amazon for more product information and related items.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00QY1FDGU

More documents and user manuals: **https://manuals.plus/**